


# iGarden



## **iGarden R290 ATW Heat Pump X7**

— **INSTALLER MANUAL** —

Please read this manual carefully before installing and operating your ATW Heat Pump, and keep this manual for future reference to ensure safe and effective use.

# Contents

1 About this document .....	7
1.1 Meaning of warnings and symbols .....	7
1.2 Installer reference guide at a glance .....	8
2 General safety precautions .....	9
2.1 General .....	9
2.2 Installation location .....	13
2.3 Refrigerant-R290 .....	14
2.4 Water quality .....	16
2.5 Electrical .....	17
3 Unit handling .....	19
3.1 Unit transportation .....	19
3.2 Unpacking the unit .....	21
3.3 Removing accessories from the unit .....	22
4 About the unit .....	23
4.1 Identification .....	23
4.2 Layout of functional components .....	24
4.3 Heating&Cooling Operation range .....	26
4.4 The data sheet of unit .....	27
5 Application guidelines .....	28
5.1 Capacity and load curve .....	28
5.2 DHW tank (field supply) .....	28
5.3 Buffer tank (field supply) .....	30
5.4 Expansion tank(field supply) .....	31
5.5 Hydraulic performance curve .....	33
5.6 Filter(field supply) .....	34
5.7 Safety valve(field supply) .....	34
5.8 Secondary water pump(field supply) .....	35
5.9 Typical applications .....	36
6 Unit installation .....	44
6.1 Precautions for installation .....	44
6.1.1 Precautions for installation on a ground .....	44
6.1.2 Precautions for installation on a flat roof .....	44
6.1.3 Occupational safety .....	45
6.2 Installation site requirements for the outdoor unit .....	45
6.3 Installation distance requirement for the outdoor unit .....	46
6.3.1 Single installation requirements .....	47
6.3.2 Cascade installation requirements .....	48
6.4 Special requirements for the outdoor unit .....	49
6.4.1 In cold climate .....	49
6.4.2 Strong wind .....	51
6.4.3 Seaside installation .....	52
6.4.4 Others .....	53
6.5 Foundation and installing the outdoor unit .....	53
6.5.1 Foundation .....	53

6.5.2 Unit mounting .....	54
6.6 Drainage .....	55
6.6.1 Drain hole position .....	56
6.6.2 Drainage layout .....	56
7 Hydraulic installation .....	59
7.1 Precautions for hydraulic installation .....	59
7.2 Water circuit requirements .....	60
7.3 Connecting water piping .....	62
7.3.1 About connecting the water piping .....	62
7.3.2 To connect the water piping .....	62
7.4 Filling water circuit .....	63
7.5 Freeze protection .....	63
7.5.1 Protected by software .....	63
7.5.2 Protected by glycol .....	63
7.5.3 Protected by anti-freeze valve .....	65
7.5.4 Others .....	65
7.6 Filling the domestic hot water tank .....	65
7.7 Water pipe insulation .....	66
8 Electrical installation .....	67
8.1 Opening the electrical box cover .....	67
8.2 Precautions for electrical wiring .....	67
8.3 Guidelines for connecting electrical wires .....	69
8.3.1 Field wiring guidelines .....	69
8.3.2 Circuit protector selection .....	69
8.3.3 Tightening torque .....	70
8.3.4 Back plate layout for connection .....	70
8.4 Connection with power supply .....	71
8.4.1 Precautions .....	71
8.4.2 Wiring of main power supply .....	72
8.5 Installation of wired controller .....	73
8.5.1 Materials and requirements for installing the wire controller .....	73
8.5.2 Dimensions .....	73
8.5.3 Wired controller installation and connection .....	74
8.6 Connection of other components .....	76
9 Display Operation Guide .....	77
9.1 Main Interface .....	77
9.1.1 ON/OFF .....	79
9.1.2 Adjusting Temperature .....	79
9.1.3 Air conditioning mode settings .....	80
9.1.4 Screen unlock .....	80
9.1.5 Power Mode Settings .....	81
9.2 Main menu .....	81
9.2.1 Analog Input Query Interface .....	82
9.2.2 Load Output Query Interface .....	83
9.3 Display Setting .....	84
9.3.1 Language Setting .....	84
9.3.2 Brightness setting .....	84

9.3.3	Screen saver .....	85
9.3.4	Alarm Sound Setting .....	85
9.3.5	Keypad buzzer .....	86
9.4	Time and Date .....	86
9.5	Timer setting .....	86
9.5.1	Timer on/off .....	87
9.5.2	Disinfection Function .....	89
9.5.3	Silent timer .....	90
9.5.4	DHW Pump Timer .....	90
9.6	WiFi Setup .....	91
9.7	User Parameter Settings .....	91
9.8	Manual Defrost .....	93
9.9	Force Open Function .....	94
9.9.1	Floor Heating Drying Function .....	94
9.9.2	Forced open auxiliary electric heater .....	94
9.9.3	Force open water tank heater .....	94
9.9.4	Forced open DHW mode .....	94
9.9.5	Force open external heat source .....	95
9.10	Holiday Mode .....	95
9.10.1	Holiday Away Mode .....	95
9.10.2	Holiday Stay-at-Home Mode .....	96
9.11	Fault Inquiry Interface .....	96
9.11.1	Current fault .....	97
9.11.2	Historical faults .....	97
10	Configuration.....	98
10.1	Overview: Configuration .....	98
10.2	Check before configuration .....	98
11	Commissioning.....	100
11.1	Overview: Commissioning .....	100
11.2	Precautions during commissioning .....	100
11.3	Checklist before commissioning .....	100
11.4	Checklist during commissioning .....	101
11.4.1	Minimum flow rate .....	101
11.4.2	Water pressure adjustment requirements .....	102
11.4.3	Air purge .....	102
11.4.4	Actuator test run .....	105
11.4.5	Unit test run .....	107
12	Hand-over to the user.....	108
12.1	Energy saving tips .....	108
13	Control and function.....	109
13.1	Temperature control .....	109
13.1.1	Heating/Cooling mode .....	109
13.1.2	DHW mode .....	109
13.2	DHW function .....	110
13.2.1	Whether DHW mode is enabled .....	110
13.2.2	Whether DHW PRIORITY is enabled .....	110
13.2.3	DHW mode ambient restriction .....	111

13.3	Cooling function .....	111
13.3.1	Whether cooling mode is enabled .....	111
13.3.2	Cooling mode ambient restriction .....	111
13.3.3	Cooling on/off operation .....	112
13.4	Heating function .....	112
13.4.1	Whether heating mode is enabled .....	112
13.4.2	Heating mode ambient restriction .....	112
13.4.3	Heating on/off operation .....	113
13.5	Automatic function .....	113
13.6	External heat source control logic .....	114
13.7	Electric heater control logic .....	115
13.7.1	Auxiliary electric heater control logic .....	115
13.7.2	DWH tank electric heater control logic .....	116
13.8	Water pump control logic .....	117
13.8.1	Main Circulation Pump Control .....	117
13.8.2	Secondary Circulation Pump Control .....	117
13.8.3	Mixing Pump Control .....	118
13.8.4	DHW Pump Control .....	118
13.8.5	Solar Water Pump Control .....	118
13.9	Three way valve control logic .....	118
13.9.1	DWH three-way valve control logic .....	118
13.9.2	Cooling three-way valve control logic .....	118
13.9.2	Mixing three-way valve control logic .....	118
13.10	Others .....	119
13.10.1	Scheduled disinfection function .....	119
13.10.2	Holiday away mode .....	119
13.10.3	Holiday stay mode .....	119
13.10.4	Crankcase electric heater control .....	119
13.10.5	Pan electric heater control .....	120
13.10.6	Water circuit anti-freeze function .....	120
13.10.7	Anti-freeze function in cooling mode .....	121
13.10.8	Defrost control .....	121
13.10.9	Photovoltaic-linked function .....	123
14	Technical data.....	124
14.1	Refrigerant diagram .....	124
14.1.1	Heating/DHW Mode .....	124
14.1.2	Cooling/Defrosting .....	125
14.1.3	Key components .....	126
14.2	Electronic system .....	128
14.2.1	Electric wiring diagram .....	128
14.2.2	Control board interface diagram .....	130
15	Maintenance and service.....	138
15.1	Safety precautions for maintenance .....	138
15.2	Tools used for maintenance .....	139
15.3	Yearly maintenance .....	143
15.3.1	Overview: Yearly maintenance outdoor unit .....	143
15.3.2	Maintenance checklist .....	143

15.4	Disassembly of structural components .....	144
15.4.1	Safety Precautions for maintenance .....	144
15.4.2	Removing the top cover .....	144
15.4.3	Removing the service panel .....	145
15.4.4	Removing the front frame .....	145
15.4.5	Removing the fan grille .....	146
15.4.6	Removing the support plate .....	146
15.4.7	Removing the water Inlet panel .....	147
15.5	Replacement of electrical components .....	148
15.5.1	Replacing the main board .....	148
15.5.2	Replacing the expansion board .....	149
15.5.3	Replacing the drive board .....	150
15.6	Service information .....	151
15.6.1	Label for refrigerant presence .....	151
15.6.2	Leak detection methods .....	151
15.6.3	Check of refrigeration equipment .....	151
15.6.4	Check of electrical devices .....	152
15.6.5	Repair of sealed components .....	152
15.6.6	Repair of intrinsically safe components .....	152
15.6.7	Transportation and marking .....	152
15.7	Repair of refrigerant cycle/brazing points .....	153
15.7.1	Preparation for refrigerant cycle/brazing repair .....	153
15.7.2	Pressure adjustment for vacuum pump .....	153
15.7.3	Checks to gas supply .....	154
15.7.4	Flame adjustment .....	154
15.7.5	Flame types .....	155
15.7.6	Shutting off the flame .....	155
15.7.7	Flux requirements .....	156
15.7.8	Nitrogen requirements .....	156
15.7.9	Checking brazing (insertion) points .....	156
15.7.10	Brazing and heating .....	157
15.7.11	Brazing terminology .....	158
15.7.12	Selection of brazing materials .....	158
16	Troubleshooting.....	159
16.1	Overview: troubleshooting .....	159
16.2	Precautions when troubleshooting .....	159
16.3	Solving problems based on symptoms .....	159
16.3.1	Symptom: The unit is NOT heating or cooling as expected .....	159
16.3.2	Symptom: Hot water does NOT reach the desired temperature .....	160
16.3.3	Symptom: The compressor does NOT start .....	160
16.3.4	Symptom: The system is making gurgling noises after commissioning .....	160
16.3.5	Symptom: The pump is making noise (cavitation) .....	161
16.3.6	Symptom: The pressure relief valve opens .....	161
16.3.7	Symptom: The water pressure relief valve leaks .....	162
16.3.8	Symptom: Insufficient space heating capacity at low outdoor temperature. ....	162
16.3.9	Symptom: The pressure at the tapping point is temporarily unusually high. ....	162
16.4	Troubleshooting Based on error codes .....	163

16.4.1 E1 Troubleshooting .....	166
16.4.2 E7 Troubleshooting .....	167
16.4.3 E12, E80 Troubleshooting .....	168
16.4.4 E104, E105, E182 Troubleshooting .....	170
16.4.5 E101, E102, E108, E109, E161, E168, E171 Troubleshooting .....	172
16.4.6 E83 Troubleshooting .....	174
16.4.7 E124 Troubleshooting .....	176
16.4.8 E178 Troubleshooting .....	178
16.4.9 E103 Troubleshooting .....	180
16.4.10 E106 Troubleshooting .....	182
16.4.11 E107 Troubleshooting .....	184
16.4.12 E115 Troubleshooting .....	186
16.4.13 E118 Troubleshooting .....	188
16.4.14 E164 Troubleshooting .....	190
16.4.15 E166 Troubleshooting .....	192
16.4.16 E167 Troubleshooting .....	194
16.4.17 E10 Troubleshooting .....	196
16.4.18 E169 Troubleshooting .....	198
16.4.19 E174 Troubleshooting .....	203
16.4.20 Fault recovery ways .....	205
17 Disposal.....	206
17.1 General .....	206
17.2 Packaging .....	206
17.3 Refrigerant Handling .....	206
17.3.1 Removal and evacuation .....	206
17.3.2 Charging procedures .....	206
17.3.3 Recovery .....	206
17.3.4 Decommissioning .....	207
18 Check list.....	208
ANNEX.....	214
ANNEX A. Factory default settings .....	214
ANNEX B. Resistance table .....	230
ANNEX C. AT Compensation Curve .....	237

# 1 About this document

## 1.1 Meaning of warnings and symbols



### **DANGER**

Indicates a high-risk situation that may lead to death or serious injury.



### **DANGER: RISK OF ELECTROCUTION**

Indicates a situation which may lead to electric shock.



### **DANGER: RISK OF EXPLOSION**

Indicates a situation which may lead to an explosion.



### **DANGER: RISK OF BURNING/SCALDING**

Indicates a situation that may lead to burning/scalding due to extremely hot or cold temperatures.



### **WARNING**

Indicates a situation that may lead to death or serious injury.



### **WARNING: FLAMMABLE MATERIAL**

This symbol shows that this appliance used a flammable refrigerant. If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire.



### **CAUTION**

Indicates a situation that may lead to mild to moderate injuries.



### **NOTICE**

Indicates a situation that could result in equipment or property damage.



### **INFORMATION**

Indicates useful tips or additional information.

Symbol	Description
	This symbol shows that information is available such as the operating manual or installation manual.
	This symbol shows that only a competent service personnel should be handling this equipment with reference to the technical manual.

	This symbol shows that the manual should be read carefully.
	This symbol shows that the unit contains rotating parts. Be careful when servicing or inspecting the unit.

## 1.2 Installer reference guide at a glance

Chapter	Description
About This Document	Tell the installer what information they can get.
General Safety Precautions	Safety instructions that you must read before installing
Unit Handling	- How to transport the unit - How to unpack the units and remove their accessories
About The Unit	Learn about the basic information of the unit
Application guidelines	Various installation setups of the system
Unit Installation	What to do and know to install the system, including information on how to prepare for an installation
Hydraulic Installation	What to do and know to install the piping of the system, including information on how to prepare for an installation
Electrical Installation	What to do and know to install the electrical components of the system, including information on how to prepare for an installation
Configuration	What to do and know to configure the system after it is installed
Commissioning	What to do and know to commission the system after it is configured
Hand-over to the user	What to give and explain to the user
Control and Function	Introduction to the functions and control logic of the unit
Technical Data	More detailed information about the unit
Maintenance and Service	How to maintain and service the units
Troubleshooting	What to do in case of problems
Disposal	How to dispose of the system
Check list	Checklist after completing all steps of unit installation

# 2 General safety precautions

## 2.1 General

- Please carefully read the following "Safety Precautions" when installation, service, maintenance, repair and decommissioning of appliances using flammable refrigerant.
- This appliance employed A3 flammable refrigerant R290 and shall be stored in such a way that it does not cause mechanical damage.
- The precautions specified here must be observed as they contain important safety-related information. The meaning of each indication used is shown below. Incorrect installation resulting from disregarding or neglecting the instructions may cause injury or damage, the severity of which is classified according to the following indications.
- Perform a test run to confirm that no abnormalities occur after installation. Then, explain to the user about operation, care, and maintenance as described in the instructions. Remind the customer to keep the operating instructions for future reference.
- If you are in doubt about the installation process or operation, please contact your authorized distributor for advice and information.

 <b>DANGER</b>
1. These instructions are exclusively intended for qualified contractors and authorized installers.
2. Work on the refrigerant circuit with flammable refrigerant in safety group A3 may only be carried out by authorized heating contractors. These heating contractors must be trained in accordance with EN 378 Part 4 or IEC 60335-2-40, Section HH. The certificate of competence from an industry accredited body is required.
3. Brazing/soldering work on the refrigerant circuit may only be carried out by personnel certified in accordance with ISO 13585 and AD 2000, Datasheet HP 100 R. And only contractors qualified and certified for the processes can perform brazing/soldering work. The work must fall within the range of applications purchased and be carried out in accordance with the prescribed procedures. Soldering/brazing work on accumulator connections requires certification of personnel and processes by a notified body according to the Pressure Equipment Directive (2014/68/EU).
4. Only a qualified electrician can perform the work on the electrical equipment.
5. Before initial commissioning, all safety-related points must be checked by the particular certified heating contractors. The system must be commissioned by the system installer or a qualified person authorized by the installer.
6. Risk of explosion: The leakage of refrigerant can create a combustible or explosive atmosphere in the surrounding air. The following precautions shall be taken to prevent fire and explosion within the security area: <ul style="list-style-type: none"><li>– Keep ignition sources away from naked fires, plug sockets, hot surfaces, light switches, lamps, electric appliances that do not have an ignition source, mobile appliances with built-in batteries (for example, cell phones and fitness watches).</li><li>– Do not use any sprays or other flammable gases in the safe area.</li></ul>
7. Contact with live components can lead to serious injuries. Some components on PCBs may remain live even after the power supply is turned off. Before removing the appliance covers, wait at least 4 minutes to allow the voltage to drop completely. <ul style="list-style-type: none"><li>– Prevent the system from being reconnected.</li><li>– Wear appropriate personal protective equipment when performing any work.</li><li>– Never touch switches or electrical parts with wet fingers, as this could cause electric shock and damage</li></ul>

the system.
<p>8. Hot surfaces and fluids can cause burns or scalds, while cold surfaces may lead to frostbite.</p> <ul style="list-style-type: none"> <li>- Before performing servicing or maintenance, turn off the equipment and let it cool down or warm up.</li> <li>- Do not touch hot or cold surfaces on the appliance, its fittings, or pipework.</li> </ul>
<p>9. Escaping refrigerant may cause fires and explosions, potentially leading to severe injuries or even death.</p> <ul style="list-style-type: none"> <li>- Do not drill into or apply heat to a refrigerant circuit that contains refrigerant.</li> <li>- Do not operate Schrader valves unless a fill valve or extraction equipment is connected. Take steps to prevent electrostatic charges.</li> <li>- Do not smoke. Avoid open flames and sparks. Never switch lights or electrical appliances on or off in environments where open flames or sparks are present.</li> <li>- Components that contain or have contained refrigerant must be labeled and stored in well-ventilated areas, following relevant regulations and standards.</li> </ul>
<p>10. Direct contact with liquid or gaseous refrigerant can cause serious health harm, such as frostbite and/or burns. Inhaling liquid or gaseous refrigerant also carries a risk of asphyxiation.</p> <ul style="list-style-type: none"> <li>- Avoid direct contact with liquid or gaseous refrigerant.</li> <li>- Wear personal protective equipment when handling liquid or gaseous refrigerant.</li> <li>- Never inhale refrigerant vapor.</li> </ul>
<p>11. Refrigerant is under pressure: mechanical loading of lines and components can cause leaks in the refrigerant circuit. Do not apply loads to the lines or components, such as supporting or placing tools.</p>
<p>12. The hot or cold metallic surfaces of the refrigerant circuit can cause burns or frostbite upon skin contact. Wear personal protective equipment to guard against such injuries.</p>
<p>13. Damage to the refrigerant circuit can allow refrigerant to enter the hydraulic system. After completing the work, properly vent the hydraulic system. When doing so, ensure the area is adequately ventilated.</p>
<p>14. Refrigerant leaks can cause fires and explosions, potentially resulting in severe injuries or death. Inhaling refrigerant may also lead to asphyxiation.</p> <ul style="list-style-type: none"> <li>- Ensure excellent ventilation, particularly in the floor area around the outdoor unit.</li> <li>- Do not smoke. Avoid open flames and sparks. Never switch lights or electrical appliances on or off in environments where open flames or sparks are present.</li> <li>- Evacuate all people from the hazardous area.</li> <li>- From a safe location, turn off the power supply for all system components.</li> <li>- Remove ignition sources from the hazardous area.</li> <li>- System users should be aware that no ignition sources may be brought into the hazardous area during repairs.</li> <li>- Repair work must be performed by an authorized contractor.</li> <li>- Do not recommission the system until it has been repaired.</li> </ul>
<p>15. If water leaks from the appliance, there is a risk of electric shock. Turn off the heating system via the external isolator (e.g., fuse box, domestic distribution board).</p>
<p>16. If water leaks from the appliance, scalding could occur. Under no circumstances should you touch hot water.</p>
<p>17. Refrigerant leaks can trigger fires and explosions, leading to severe injuries or even death. Inhaling refrigerant may also cause asphyxiation. Store the outdoor unit under the following conditions:</p> <ul style="list-style-type: none"> <li>- A storage explosion prevention plan must be established.</li> <li>- Ensure the storage area is well-ventilated.</li> <li>- Keep it away from ignition sources (avoid exposure to heat and smoking).</li> <li>- Storage temperature range: -25°C to 70°C</li> </ul>

<ul style="list-style-type: none"> <li>- The outdoor unit must be stored only in its original factory protective packaging.</li> <li>- Protect the outdoor unit from damage.</li> <li>- The maximum number of outdoor units that can be stored in one location is determined based on local conditions.</li> </ul>
18. It is strongly recommended to install a residual current device (RCD) on-site according to respective national wiring rules or country-specific safety measures for residual current.
19. This heat pump is designed for use solely with closed water systems. Using it in an open water system may cause excessive corrosion of water pipes and raise the risk of bacterial growth in the water, particularly Legionella.
20. If you have any doubts about the installation process or operation, always consult an authorized dealer for guidance and information.
21. Choose a suitable location where, in case of water leakage, no damage will be inflicted on other property.
22. In line with electrical installation standards, when installing electrical equipment on wooden buildings with metal lath or metal wire lath, no electrical contact between the equipment and the building is permitted. Insulators must be installed between them.
23. This installation may require approval under country-specific building regulations, and it may be necessary to notify local authorities prior to installation.
24. Any work done on the heat pump after removing the screw-secured front panel must be conducted under the supervision of an authorized dealer and a licensed installation contractor.
25. The heat pump must be properly grounded. Electrical ground connections must not be linked to gas pipes, water pipes, lightning rods, or telephone ground wires. Otherwise, if the heat pump suffers insulation breakdown or grounding failure, there will be a risk of electric shock.
 <b>WARNING</b>
1. Do not use any methods to accelerate defrosting or clean the appliance other than those recommended by the manufacturer.
2. The appliance shall be stored in a room with no continuously operating ignition sources (such as open flames, a running gas appliance, or a running electric heater).
3. Be aware that refrigerants might not contain an odour.
4. Any work procedure that affects safety devices shall only be carried out by competent persons. Examples of such work procedures include: <ul style="list-style-type: none"> <li>– Breaking into the refrigeration circuit;</li> <li>– Opening sealed components;</li> <li>– Opening ventilated enclosures.</li> </ul>
5. Protective devices, piping, and fittings shall be protected to the greatest extent possible against adverse environmental effects, such as the risk of water pooling and freezing in relief pipes, or the buildup of dirt and debris.
6. Measures must be taken to accommodate expansion and contraction in long pipe runs.
7. Piping in refrigeration systems must be designed and installed to minimize the risk of hydraulic shock causing damage to the system.
8. Steel pipes and components must be protected from corrosion with a rustproof coating prior to applying any insulation.
9. Sealed electrical components must not be repaired.
10. If electrical cables are short, a leak in the refrigerant circuit could allow gaseous refrigerant to enter the building. Minimum length of electrical connecting cables between the indoor and outdoor units: 3 m.


11. To avoid potential risks from refrigerant leaks, always maintain a 2-meter distance from the unit—especially for children—whether the unit is in operation or not.
12. Installation work requires four or more people. If moved by fewer than four people, the heat pump's weight could cause injury.
 <b>CAUTION</b>
1. Servicing shall be carried out only as recommended by the manufacturer.
2. Oxygen-free nitrogen (OFN) shall be purged through the system both before and during the brazing process.
3. An inert gas—specifically dry oxygen-free nitrogen (OFN)—shall be used to flush the system to render the unit safe. This process may need to be repeated several times.
4. This operation is absolutely critical when performing brazing work on the pipework.
5. Any form of improper use is prohibited: <ul style="list-style-type: none"> <li>– Do not rinse the unit.</li> <li>– Do not place any objects or equipment on top of the unit (top plate).</li> <li>– Do not climb, sit, or stand on top of the unit.</li> </ul>
6. Permissible tools: All tools used in the safety zone must be designed and explosion-protected in compliance with applicable standards and regulations for refrigerants in safety groups A2L and A3. Examples include brushless machines (such as cordless tools, disposal containers, installation aids, and screwdrivers), extraction equipment, vacuum pumps, conductive hoses, and non-sparking mechanical tools.
7. Tools must also be suitable for the pressure ranges in use and maintained in proper working condition. <ul style="list-style-type: none"> <li>– Electrical equipment must meet the requirements for explosive-risk areas (Zone 2).</li> <li>– Do not use flammable materials such as sprays or other flammable gases. Before starting work, discharge static electricity by touching earthed objects (e.g., heating or water pipes).</li> <li>– Do not remove, block, or bridge safety devices.</li> <li>– No modifications are permitted: Do not alter the outdoor unit, inlet/outlet lines, electrical connections/cables, or surrounding areas. Do not remove any components or seals.</li> </ul>
8. When working on systems using flammable refrigerants, technicians should identify certain locations as "temporary flammable zones." These are typically areas where refrigerant emissions are expected during normal operations (e.g., recovery, charging, or evacuation), such as points where hoses are connected or disconnected.
9. In case of accidental refrigerant release that could form a flammable mixture with air, technicians must ensure a 3-meter safety working area (with the unit as the center).
10. For the primary water circulation loop: <ul style="list-style-type: none"> <li>– Do not install air vent valves indoors. If indoor installation is unavoidable, ensure no ignition sources are present near the valve.</li> <li>– Ensure the outlet of the indoor safety valve leads outdoors, with no ignition sources nearby.</li> </ul>
11. For the secondary water circulation loop (e.g., domestic hot water/DHW loop): Follow general rules for installing air vent valves and safety valves. For outdoor installations, two scenarios must be considered to prevent system damage, refrigerant releases, and other adverse effects: <ul style="list-style-type: none"> <li>– Equipment located in public-access areas;</li> <li>– Equipment located in restricted areas, accessible only to authorized personnel.</li> </ul>
12. Freezing can damage the heat pump. <ul style="list-style-type: none"> <li>– Thermally insulate all hydraulic lines.</li> <li>– Antifreeze may be added to the secondary circuit in compliance with local regulations and standards.</li> </ul>

<p>13. Repairing components with safety functions may compromise the system's safe operation.</p> <ul style="list-style-type: none"> <li>– Replace faulty components only with genuine manufacturer-supplied spare parts.</li> <li>– Do not repair inverters; replace them if defective.</li> <li>– Repair work must not be performed on-site. Units should be repaired at a designated location.</li> </ul>
<p>14. Spare and wearing parts that have not been tested alongside the system may impair the system's functionality. Installing unauthorized components or making unapproved modifications or conversions can compromise safety and may void our warranty. Only use original spare parts supplied or approved by the manufacturer for replacements.</p>
<p>15. Direct contact with liquid or gaseous refrigerant can cause severe health damage, such as frostbite and/or burns. Inhaling liquid or gaseous refrigerant may result in asphyxiation.</p> <ul style="list-style-type: none"> <li>– Avoid direct contact with liquid or gaseous refrigerant.</li> <li>– Never inhale refrigerant vapors.</li> </ul>
<p>16. Ice buildup in the condensate pan and fan area of the outdoor unit can damage the equipment.</p> <ul style="list-style-type: none"> <li>– Do not use mechanical tools or aids to remove ice.</li> <li>– Before using electrical heating appliances, check the refrigerant circuit for leaks using an appropriate measuring device. The heating appliance must not be an ignition source and must comply with the requirements of EN 60335-2-30.</li> <li>– If ice regularly forms on the outdoor unit (e.g., in areas with frequent frost and heavy fog), install a fan ring heater suitable for refrigerant R290 and/or an electric ribbon heater in the condensate pan.</li> </ul>
<p>17. Fires involving R290 must be extinguished only with CO<sub>2</sub> or dry powder extinguishers.</p>

## 2.2 Installation location

1. The unit must be installed outdoors only.
2. Avoid installing the unit in areas where the ambient temperature may drop below -30°C.
3. The heat pump must be installed on a flat and solid surface.
4. Avoid locations with heat sources or steam that could affect the heat pump's operation.
5. Ensure sufficient space is provided around the unit for servicing and air circulation.
6. Ensure the installation site can withstand the unit's weight and vibration.
7. Ensure the area is well-ventilated. Do NOT block any ventilation openings.
8. Ensure the unit is level.
9. Select a location with easy drainage.
10. Select a location where the heat pump's operating noise will not cause discomfort to users.
11. Select a location convenient for maintenance.
12. Maintain the minimum required distances from walls, ceilings, or other obstacles.
13. Select a location where flammable gas leakage is unlikely to occur.
14. Select a location where the heat pump's piping and wiring lengths are within reasonable limits.
15. If installing an awning over the heat pump to protect it from direct sunlight or rain, take care not to block heat radiation from the heat exchanger.
16. Do NOT install the unit in the following locations:
  - In potentially explosive atmospheres.
  - In locations with machinery that emits electromagnetic waves, as such waves may interfere with the control system and cause equipment malfunction.
  - In locations with a fire risk due to leakage of flammable gases (e.g., thinner or gasoline), carbon fiber, or ignitable dust.
  - In locations where corrosive gases (e.g., sulfurous acid gas) are generated, as corrosion of copper pipes or soldered components could cause refrigerant leakage.
17. Avoid installing the heat pump in locations where the intake side may be directly exposed to wind.

- 18. If the heat pump is installed near the sea (a high-sulfur area) or in oil-containing environments (e.g., areas with machine oil), its service life may be shortened.
- 19. When the heat pump is installed in locations subject to typhoons or strong winds—such as between buildings, on rooftops, or in open areas without surrounding structures—secure the unit with anti-toppling wires or similar measures.
- 20. The heat pump becomes extremely heavy when filled with water. Install the unit on a solid concrete surface, considering the combined weight of the unit and the water.
- 21. Secure the unit to the concrete floor at 4 points using M12 anchor bolts.
- 22. The pull-out strength of these anchor bolts must exceed 15,000 N.



**Illustration of grip type and embedded type anchor bolt**

## 2.3 Refrigerant-R290

 <b>DANGER: RISK OF EXPLOSION</b>
<p><b>Pump down-Refrigerant leakage.</b> If you want to pump down the system, and there is a leak in the refrigerant circuit:</p> <ul style="list-style-type: none"> <li>– Do NOT use the unit's automatic pump down function, which is designed to collect all refrigerant from the system into the outdoor unit.</li> </ul> <p><b>Possible consequence:</b> Self-combustion and explosion of the compressor because of air going into the operating compressor.</p> <ul style="list-style-type: none"> <li>– Use a separate recovery system to avoid operating the unit's compressor.</li> </ul>
 <b>DANGER</b>
<ol style="list-style-type: none"> <li>1. Due to lower working pressure than that of R32 or R410A refrigerants, some pipes and installation and service tools are specialized.</li> <li>2. Mixing different refrigerants in a system is prohibited.</li> <li>3. Ensure no foreign substances (such as oil, water, etc.) enter the piping.</li> <li>4. Operation, maintenance, repair, and refrigerant recovery must be performed by trained and certified</li> </ol>

<p>personnel familiar with the use of flammable refrigerants, as recommended by the manufacturer. Any individual operating, servicing, or maintaining the system or its associated parts must be trained and certified.</p>
<p>5. No part of the refrigeration circuit (including evaporators, air coolers, AHUs, condensers, or liquid receivers) or piping shall be positioned near heat sources, open flames, operating gas appliances, or operating electric heaters.</p>
<p>6. The user/owner or their authorized representative shall regularly inspect alarms, mechanical ventilation, and detectors—at least once a year (in accordance with national regulations)—to ensure they function properly.</p>
<p>7. A logbook must be maintained, and the results of these inspections shall be recorded in it.</p>
<p>8. Ventilation in occupied spaces shall be inspected to confirm there are no obstructions.</p>
<p>9. Before a new refrigeration system is put into service, the person responsible for commissioning the system must ensure that trained and certified operators receive instruction (based on the instruction manual) on the system's construction, supervision, operation, and maintenance, as well as the safety measures to be observed. They must also be familiarized with the properties and handling methods of the refrigerant used.</p>
<p>10. Trained and certified personnel must meet the following general requirements:</p> <ul style="list-style-type: none"> <li>– Knowledge of laws, regulations, and standards related to flammable refrigerants;</li> <li>– Detailed knowledge and skills in handling flammable refrigerants, using personal protective equipment, preventing refrigerant leaks, handling cylinders, charging, leak detection, recovery, and disposal;</li> <li>– Ability to understand and apply national laws, regulations, and standards in practice;</li> <li>– Participation in regular ongoing training to maintain this expertise.</li> </ul>
<p>11. Protect the refrigeration system from accidental damage (e.g., rupture) caused by moving furniture or renovation activities.</p>
<p>12. To ensure tightness, technicians must test field-fabricated refrigerant joints for leaks indoors using a method with a sensitivity of 5 grams per year or better. Testing shall be conducted at a pressure of at least 0.25 times the maximum allowable pressure (&gt;1.04 MPa, maximum 4.15 MPa), with no leakage permitted.</p>
<p>13. Take adequate precautions against refrigerant leaks. If refrigerant gas leaks, ventilate the area immediately. Potential risks include:</p> <ul style="list-style-type: none"> <li>– Excessive refrigerant concentration in an enclosed space may cause oxygen depletion;</li> <li>– Toxic gases may form if refrigerant gas comes into contact with fire.</li> </ul>
<p>14. Refrigerant must always be recovered; do not release it directly into the environment. Use a vacuum pump to evacuate the installation.</p>
<p>15. Ensure no oxygen is present in the system. Refrigerant may only be charged after completing the leak test and vacuum drying.</p> <p><b>Possible consequence:</b> Self-combustion and explosion of the compressor because of oxygen going into the operating compressor.</p>
<p>16. Immediately close the refrigerant tank valve when finishing or pausing the charging process. Failure to close the valve promptly may result in additional refrigerant being charged due to residual pressure.</p> <p><b>Possible consequence:</b> Incorrect refrigerant amount.</p>
 <b>NOTICE</b>
<p>1. If recharging is required, refer to the unit's nameplate, which specifies the refrigerant type and required quantity.</p>
<p>2. To prevent compressor failure, do not charge more refrigerant than the specified amount.</p>
<p>3. When opening the refrigerant system, refrigerant must be handled in compliance with applicable laws</p>

and regulations.
4. Ensure refrigerant piping installation meets applicable regulations. In Europe, the relevant standard is EN378.
5. Ensure field piping and connections are not subjected to stress.
6. After all piping is connected, check for gas leaks using nitrogen for leak detection.
7. The unit is factory-charged with refrigerant; some systems may require additional charging based on pipe size and length.
8. Use only tools designed exclusively for the refrigerant type in the system to ensure pressure resistance and prevent foreign materials from entering the system.

## 2.4 Water quality

 <b>CAUTION</b>
If a potable water source is used to supply water to the equipment, a backsiphonage prevention device should be installed between the potable water source and the equipment.
 <b>NOTICE</b>
1. Ensure water quality complies with EU Directive 2020/2184.
2. If necessary, install a water softener to reduce water hardness.
3. Circulators operate effectively only with clean, high-quality tap water.
4. Poor-quality water poses a risk of material damage.
5. The most common factors that can affect circulators and the system include oxygen, limescale, sludge, acidity levels, and other substances (such as chlorides and minerals).
6. In addition to water quality, proper installation is also crucial. The heating system must be airtight, and materials should be selected that are resistant to oxygen diffusion (to prevent corrosion...).

### Cleanliness

Before connecting the unit to a water supply, thoroughly clean the system using specific products effective at removing residues or impurities that could impair its functionality. Existing systems must be free of sludge and contaminants, and protected against build up.

### New systems

For new installations, it is essential to flush the entire system (with the circulator uninstalled) before commissioning the central system. This removes residues from the installation process (such as welding debris, waste, and joint compounds) and preservatives (including mineral oil). The system must then be filled with clean, high-quality tap water.

### Existing systems

If a new boiler or heat pump is installed in an existing heating system, the system must be rinsed to eliminate particles, sludge, and debris. Drain the system before installing the new unit. Dirt can only be removed with an adequate water flow; each section must then be flushed separately. Special attention must also be paid to "blind spots" where dirt tends to accumulate due to reduced water flow. The system must then be filled with clean, high-quality tap water. If water quality remains unsatisfactory after rinsing, measures must be taken to prevent issues. One option is to install a strainer: various types are available, including mesh strainers (designed to catch large dirt particles, typically placed in areas with higher flow) and tissue strainers (for capturing finer particles).

The water quality standards applicable to this unit are shown in the figure below.

Corrosion resistance of stainless steel and brazed materials in tap water at room temperature

Attention: + :Good corrosion resistance under normal conditions

0 :There may be corrosion problems

- :Not recommended

Condition			Plate material			Brazing material		
Moisture	Concentration	Time limit	AISI 304	AISI 316	254 SMO	Copper	Nickel	SS
Alkalinity (HCO <sub>3</sub> )	<70	24h	+	+	+	0	+	+
	70-300		+	+	+	+	+	+
	>300		+	+	+	0/+	+	+
Sulfate (So <sub>4</sub> <sup>2-</sup> )	<70	unlimited	+	+	+	+	+	+
	70-300		+	+	+	0/-	+	+
	>300		+	+	+	-	+	+
HCO-/SO <sub>2</sub> -	>1.0	unlimited	+	+	+	+	+	+
	<1.0		+	+	+	0/-	+	+
Electrical conductivity	<10	unlimited	+	+	+	0	+	+
	10-500		+	+	+	+	+	+
	>500		+	+	+	0	+	+
pH	<6.0	24h	0	0	0	0	+	0
	6.0-7.5		+	+	+	0	+	+
	7.5-9		+	+	+	+	+	+
	>9		+	+	+	0	+	+
Ammonium (NH <sub>4</sub> <sup>+</sup> )	<2	24h	+	+	+	+	+	+
	2-20		+	+	+	0	+	+
	>20		+	+	+	-	+	+
Chloride (Cl <sup>-</sup> )	<10	unlimited	+	+	+	+	+	+
	100-200		0	+	+	+	+	+
	200-300		-	+	+	+	+	+
	>300		-	-	+	0/+	+	-

## 2.5 Electrical

 <b>DANGER: RISK OF ELECTROCUTION</b>
1. Before removing the switch box cover, connecting electrical wiring, or touching electrical components, turn off all power supplies.
2. Before servicing, disconnect the power supply for more than 10 minutes and measure the voltage at the terminals of main circuit capacitors or electrical components. You may only touch electrical components if the voltage is less than 50 V DC. Refer to the wiring diagram for the terminal locations.
3. Do not touch electrical components with wet hands.
4. Do not leave the unit unattended when the service cover is removed.
 <b>WARNING</b>
1. If not factory-installed, a main switch or other disconnection device must be installed in the fixed wiring. This device must provide contact separation in all poles to ensure full disconnection under overvoltage

category III conditions.
2. Ensure on-site wiring complies with applicable regulations.
3. All on-site wiring must be carried out in accordance with the wiring diagram supplied with the product.
4. Never squeeze bundled cables, and ensure they do not come into contact with piping or sharp edges. Also, ensure no external pressure is applied to terminal connections.
5. Be sure to install earthing wiring. Do not earth the unit to a utility pipe, surge absorber, or telephone earth. Inadequate earthing may cause electric shock.
6. Use a dedicated power circuit. Never use a power supply shared with another appliance.
7. Install the required fuses or circuit breakers.
8. Install an earth leakage protector. Failure to do so may result in electric shock or fire.
9. When installing the earth leakage protector, ensure it is compatible with the inverter (resistant to high-frequency electrical noise) to prevent unnecessary tripping.
10. After completing electrical work, verify that all electrical components and terminals inside the electrical component box are securely connected.
11. Ensure all covers are closed before starting the unit.
 <b>CAUTION</b>
1. When connecting the power supply: First connect the earth cable, then make the current-carrying connections.
2. When disconnecting the power supply: First disconnect the current-carrying cables, then separate the earth connection.
3. The length of the conductors between the power supply stress relief and the terminal block must be such that if the power supply is pulled loose from the stress relief, the current-carrying wires will be tightened before the earth wire.
 <b>NOTICE</b>
1. Precautions when laying power wiring:
  
2. Do not connect wires of different thicknesses to the power terminal block (looseness in the power wiring may cause abnormal heating).
3. When connecting wires of the same thickness, follow the method shown in the figure above.
4. For wiring, use the designated power wire, connect it firmly, and then secure it to prevent external pressure from being exerted on the terminal board.
5. Use an appropriate screwdriver to tighten the terminal screws. A screwdriver with an overly small head will damage the screw head, making proper tightening impossible.
6. Over-tightening the terminal screws may cause them to break.
7. Install power cables at least 1 meter away from televisions or radios to prevent interference. Depending on the radio waves, a 1-meter distance may not be sufficient.

# 3 Unit handling

Please note the following:



- Upon delivery, the equipment must be inspected for damage and completeness. Any damaged or missing parts must be reported immediately to the carrier's claims agent.
- Move the packed unit as close as possible to its final installation position to prevent damage during transport.
- Prepare the path in advance that you plan to use to move the equipment to its final installation location.

## 3.1 Unit transportation

 CAUTION
1. To avoid injury, do not touch the unit's air intake or aluminum fins.
2. Ensure the outdoor unit remains stable during transportation to prevent it from falling.


### Crane

Keep the slings within the marked area to not damage the unit.




### Forklift or pallet truck

Enter the pallet from the heavy side.







### Manually

After unpacking, carry the unit using the slings attached to the unit.



## 3.2 Unpacking the unit



- ①: Cut the straps around the outer packaging of the carton.
- ②: Remove the outer packaging straps.
- ③: Take out the accessory box.
- ④: Unpacking is complete.



### 3.3 Removing accessories from the unit


The accessory box contains:

- a: User manual x1
- b: Rubber feet x4
- c: Drain connector x1
- d: Display extension cable x1
- e: Water tank sensor x2
- f: Display x1
- g: Screws x2
- h: Wall-mounted panel x1
- i: Anti-freeze Valve (option) x1

Accessories of the unit			
Name	Illustration	Quantity	Specification
User Manual		1	-
Rubber Feet		4	-
Drain Connector		1	-
Display Extension Cable		1	10m
Water Tank Sensor		2	10m
Display		1	-
Screws		2	-
Wall-mounted panel		1	-
Anti-freeze Valve (option)		1	-

# 4 About the unit



## 4.1 Identification



Example: iGXC11


Code	Explanation
iG	iGarden Brand
X	X-Series
C	With better cooling function
11	Rated capacity under standard operating conditions is 11 kW

## 4.2 Layout of functional components



No.	Name	Explanation
①	Fan	Force airflow accelerates heat exchange between the heat exchanger and air in the heat pump system.
②	Compressor	Compress the refrigerant from low-temperature and low-pressure gas into high-temperature and high-pressure gas.
③	All-in-one inverter board	Drive the fan and compressor, and receives signals from sensors and switches.
④	Terminal block	It serves as an electrical connection hub, gathering and routing wires from controllers, sensors, and other components to ensure reliable circuit connections and facilitate convenient maintenance.
⑤	Four-way valve	It can alter the refrigerant's circulation path between the evaporator and condenser, enabling the transition between cooling and heating mode.
⑥	Reactor	Reactors are primarily used to store and release electromagnetic energy, regulate current phase, filter out harmonics, and ensure the stable and efficient operation of motor loads such as compressor.
⑦	Water flow switch	When water flow is insufficient or interrupted, a signal is triggered to cut off power to critical components such as the compressor, ensuring safe system operation.
⑧	Plate heat exchanger	Used to realize heat exchange between refrigerant and water.
⑨	Water pump	Used to drive the circulation of water between the plate heat exchanger and the end load.
⑩	Fin heat exchanger	Used to realize heat exchange between refrigerant and air.
⑪	Refrigerant storage tank	It serves as the refrigerant storage and gas-liquid separation component, balancing refrigerant demand under different operating conditions while preventing liquid refrigerant from entering the compressor and causing liquid slugging, thereby ensuring system safety.
⑫	Gas separator	When there is an emergency involving R290 refrigerant leaking into water, it can separate the R290 refrigerant from the water and discharge it outdoors, preventing the R290 refrigerant from accumulating indoors.

### 4.3 Heating&Cooling Operation range




Specifications-Air source heat pump-Fairland brand M+											
Air to water heat pump	Model	IGXC08	IGXC11	IGXC13	IGXC16	IGXC11T	IGXC13T	IGXC16T			
	Power supply	220-240V~/50Hz						380-415V/3N~/50Hz			
A7°C/M35°C	Normal capacity	KW	8.00	11.00	13.00	16.00	11.00	13.00	16.00		
	Heating capacity range	KW	2.11~10.04	3.75~13.45	4.05~15.10	6.39~20.61	3.77~13.46	4.05~15.15	6.41~20.64		
	Power consumption range	KW	0.33~3.01	0.57~3.77	0.66~4.01	1.01~6.05	0.55~3.74	0.66~4.00	1.06~6.03		
	COP range	W/W	4.13~7.00	4.11~7.00	4.09~6.57	4.01~6.41	4.13~6.95	4.09~6.58	4.05~6.45		
	Normal capacity	KW	7.50	10.50	12.50	15.60	10.50	12.50	15.60		
A2°C/M35°C	Heating capacity range	KW	2.05~10.01	3.45~13.30	3.55~14.50	5.57~18.31	3.44~13.21	3.55~14.55	5.55~18.33		
	Power consumption range	KW	0.41~3.07	0.69~3.74	0.87~3.96	1.20~6.00	0.67~3.79	0.87~3.93	1.15~5.96		
	COP range	W/W	2.33~4.75	2.26~4.67	2.50~4.56	2.41~4.48	2.25~4.66	2.50~4.59	2.45~4.51		
	Normal capacity	KW	7.60	10.60	12.70	15.80	10.50	12.70	15.80		
	Heating capacity range	KW	2.27~10.22	3.32~13.06	3.92~14.56	5.30~20.08	3.33~13.08	3.92~14.60	5.32~20.12		
A7°C/M55°C	Power consumption range	KW	0.43~3.25	0.75~4.05	0.96~4.65	1.11~6.77	0.76~4.08	0.96~4.64	1.13~6.75		
	COP range	W/W	2.25~4.15	2.15~4.03	2.04~4.01	2.02~3.97	2.15~4.02	2.04~4.04	2.06~4.00		
	Normal capacity	KW	7.00	10.00	12.00	15.00	10.00	12.00	15.00		
	Cooling capacity range	KW	1.89~9.15	2.74~12.55	3.63~13.76	4.94~17.62	2.73~12.50	3.63~13.79	4.93~17.65		
	Power consumption range	KW	0.47~2.89	0.84~3.56	0.77~3.88	1.13~5.79	0.81~3.57	0.77~3.85	1.10~5.75		
A35°C/M18 °C	EER range	W/W	2.21~4.33	2.10~4.21	2.01~4.16	2.08~4.14	2.08~4.20	2.01~4.20	2.05~4.20		
	Average climate, W35 °C	/	A+++								
	Average climate, W55 °C	/	A+++								
	Rated current	A	10.6	17.7	19.0	24.3	8.4	9.1	11.1		
	Max current	A	16.0	24.8	26.5	38.0	14.6	15.2	18.3		
Electrical data	Maximum power consumption	KW	4.2	5.8	6.2	9.0	5.9	6.5	9.5		
	Sound pressure level (1 m)	dB(A)	43	44	45	47	44	45	47		
	Sound pressure level (3 m)	dB(A)	29	30	32	35	30	32	35		
	Sound power level	dB(A)	56	57	58	61	57	58	61		
	Maximum temperature	°C	75								
Temperature & Flow	Environment requirement	°C	-25~43								
	Hot water flow rate	m³/h	1.50	1.80	2.20	3.00	1.80	2.20	3.00		
	Water pipe in-out spec	Inch	G1"	G1"	G1"	G1 1/4"	G1"	G1"	G1 1/4"		
	Refrigerant	/	R290								
	GWP	/	3								
Refrigerant circuit	Compressor	/	Twin rotary								

## 4.4 The data sheet of unit

# 5 Application guidelines

## 5.1 Capacity and load curve

Match the load with appropriate capacity of the unit based on the curve below.



- ① Heat pump capacity
- ② Required heating capacity (site-dependent)
- ③ Additional heating capacity provided by backup heaters

For further details, consult with your supplier.

## 5.2 DHW tank (field supply)

A domestic hot water (DHW) tank (with or without a booster heater) can be connected to the unit; it is typically heated via an internal coil, so the selection of internal coil specifications directly impacts the unit's heating performance and operational reliability.

The material specifications for the internal coil in the tank are shown in the following table:

Material	SUS 316L	20# steel + surface enameling
----------	----------	-------------------------------

Based on experience, the heat exchange rate per unit area for smooth tubes is 3 kW, while for corrugated tubes it is 6 kW.

$$S = \frac{Q}{q}$$

In the formula:

S – External surface area of the internal coil, unit:  $m^2$

Q – Rated heating capacity of the unit, unit: kW

q – Heat exchange rate per unit area, unit:  $kW/m^2$

Calculation of coil length

$$L = \frac{S}{\pi \times d}$$

In the formula:

S – External surface area of the internal coil, unit: m<sup>2</sup>

π – Pi (take 3.14)


d – Diameter of the coil, unit: m

Calculate the appropriate pipe length for selecting the tank coil using the above formula.

Note: If corrugated internal coils are used, the resistance loss in the water system increases. Please adjust the water pump head accordingly.

Model		8-10kW	12-16kW
Tank volume/L	Recommended	150~300	200~500
Heat exchange area/m <sup>2</sup> (stainless steel coil)	Minimum	1.4	1.6
Heat exchange area/m <sup>2</sup> (enamel coil)	Minimum	2.0	2.5

(Tips: Selection shall be based on actual DHW demand. The above selection recommendations are only for the usage needs of a family of three, the above calculation formula is for reference only.)



The booster heater should be installed below the temperature probe (T5).  
The heat exchanger (coil) should be installed below the temperature probe.

## 5.3 Buffer tank (field supply)

Installing a balance tank in the system can effectively reduce the unit's startup frequency, achieve efficient defrosting, and mitigate fluctuations in room temperature.

Heat Demand Calculation Formula for Defrosting:

$$Q_d = P_d \times t_d$$

In the formula:

$Q_d$ : Total heat demand during defrosting, in kJ.

$P_d$ : Defrosting power, in kW (typically 20%-30% of the heat pump's heating power).

$t_d$ : Defrosting time, in hours (h) (usually 5-10 minutes, i.e., 0.083-0.167 h).

Example: If the heat pump's heating capacity  $Q_h = 10kW$ , the defrosting power is 25%, and the defrosting time  $t_d = 0.1h$ , then:

$$Q_d = 0.25 \cdot 10 \cdot 0.1 = 0.25kWh = 900kJ$$

During the defrosting process, the heat pump stops heating and absorbs heat from the system for defrosting. At this time, the buffer tank must provide sufficient heat to ensure that the water temperature does not drop by more than 3°C.

Buffer Tank Capacity Calculation Formula:

$$V = \frac{Q_d}{\rho \cdot c \cdot \Delta T}$$

$V$ : Buffer tank capacity, in liters (L).

$Q_d$ : Total heat demand during defrosting, in kJ.

$\rho$ : Density of water, taken as 1kg/L.

$c$ : Specific heat capacity of water, taken as .

$\Delta T$ : Allowable temperature drop of water, in °C (as required,  $\Delta T = 3^\circ C$ )

Example: If  $Q_d = 900kJ$  and  $\Delta T = 3^\circ C$ , then:

$$V = \frac{900}{1 \cdot 4.18 \cdot 3} = \frac{900}{12.54} \approx 71.8L$$

When defrosting, in addition to the heat provided by the buffer tank, the system itself (e.g., pipes, terminal equipment, etc.) also has some thermal inertia, which can provide part of the heat. Therefore, the capacity of the buffer tank can be appropriately reduced.

Revised Formula:

$$V_{actual} = V \cdot (1 - \eta)$$

$V_{actual}$ : Actual required buffer tank capacity.

$\eta$ : Thermal inertia coefficient of the system, typically taken as 0.1-0.3 (i.e., the system can provide 10%-30% of the heat).

Example: If  $V = 71.8L$  and  $\eta = 0.2$ , then:

$$V_{\text{actual}} = 71.8 \cdot (1 - 0.2) = 57.4L$$

Based on the calculation results, select a buffer tank with a standard capacity. For example, if the calculated required capacity is 57.4 L, a 60 L or 80 L standard model can be selected.

No.	Model	Tank volume/L
1	8-10kW	≥25
2	12-16kW	≥40
3	Cascade system	≥40*n
n: Quantity of outdoor units		

(Tips: The above calculation is for reference only.)

## 5.4 Expansion tank(field supply)

 NOTICE
1. It is recommended to install an expansion tank on the tap water side.
2. Check that the total water volume in the system, excluding the internal water volume of the unit, is at least 40 L.

$$V = \frac{C \times e}{1 - \frac{P1 + 1}{P2 + 1}}$$

In the formula: V = volume of the expansion tank, unit: L

C = total water volume of the system (including boiler, pipes)

e = thermal expansion coefficient of water (see table below)

P1 = pre-charge pressure of the expansion tank (unit: bar)

P2 = maximum operating pressure of the system (unit: bar)

Thermal Expansion Coefficient of Water			
Water Temperature	Expansion Coefficient	Water Temperature	Expansion Coefficient
0	0.00013	55	0.01447
10	0.00025	60	0.01704
15	0.00085	65	0.01979
20	0.00180	70	0.02269
25	0.00289	75	0.02575
30	0.00425	80	0.02898
35	0.00582	85	0.03236
40	0.00782	90	0.03590
45	0.00984	95	0.03958
50	0.01207	100	0.04342

**Installation notes:**


1. In a heating system, the expansion tank is typically installed on the return water side (where the water temperature is relatively lower) or at the cold water inlet of the hot water storage tank.
2. Generally, expansion tanks of 35L (or 24L) and smaller can be directly connected to the system piping. Those of 35L (or 24L) and larger usually come with a triangular support to avoid placing excessive load on the system piping due to the tank's weight during operation. Use metal hoses to connect the expansion tank to the system's reserved interface. It is strictly prohibited to use rigid plastic pipes for this connection—if there is vibration in the piping, the joint between rigid plastic pipes and the expansion tank interface may leak water or even crack. Secure the expansion tank's base with anchor bolts to ensure stability during use.
3. A safety valve must be installed near the expansion tank to prevent damage to the expansion tank and other system components in the event of abnormal system pressure.
4. In closed-loop heating systems, the expansion tank must not be installed at the water pump's outlet, as this could cause cavitation in the pump.
5. In thermal systems such as air conditioning, boilers, and heat pumps, the expansion tank is typically installed on the system's return water side.
6. Before replacing the expansion tank, first shut down the system or isolate the expansion tank from the system to prevent leakage of system media through the expansion tank interface. The replacement tank should ideally match the original in terms of volume, temperature resistance, and pressure resistance.

**Application notes:**

1. The expansion tank is factory-precharged with pressure. Generally, for tanks of 150L or less, the pre-charge pressure is 1.5 bar; for those over 150L, it is 2 bar. If this pressure is unsuitable, adjustments can be made under the supplier's guidance.
2. When testing the expansion tank's air bladder, it is recommended to use water pressure directly. Never touch the air bladder with sharp objects.
3. If the expansion tank is to be used in special circumstances, inform the supplier to ensure appropriate membranes are provided.
4. The working medium for expansion tanks is typically water or a mixture of water and antifreeze (with the water proportion not less than 50%).
5. The expansion tank's pre-charge pressure must be checked regularly. If a pressure drop is detected, it should be replenished promptly to avoid affecting normal operation.
6. The working temperature and maximum working pressure are indicated on the expansion tank's label. Exceeding these ranges is strictly prohibited.
7. The volume of the expansion tank must be strictly calculated using the specified formula. An undersized tank will cause frequent activation of the safety valve and frequent water replenishment by the automatic water replenishment valve.
8. The maximum working pressure of the expansion tank corresponds to the pre-charge pressure marked on its body. If the pre-charge pressure needs to be adjusted for use, the maximum working pressure will change accordingly, following this general rule: a decrease in pre-charge pressure will result in a decrease in maximum working pressure (the specific reduction requires calculation); an increase in pre-charge pressure will leave the maximum working pressure unchanged.
9. Check the expansion tank's pre-charge pressure every 6 months (or annually). If insufficient air pressure is found, replenish it promptly.

(Tips: The above calculation is for reference only.)

## 5.5 Hydraulic performance curve



## 5.6 Filter(field supply)

A water filter must be installed at the water inlet of the heat pump unit. This prevents impurities from entering the unit from the piping, thereby protecting its normal operation.

Basic requirements: The water filter is generally made of brass or stainless steel. If stainless steel is selected for the filter, it is suitable for water-based media containing ethylene glycol (at concentrations below 30%).

Filter Standards				
Connection Diameter	1"F	1 1/4"F	1 1/2"F	2"F
Filter Mesh Count	40	40	40	40

### Selection recommendations:

The filter is used to collect impurities in the system, preventing them from interfering with the system's normal operation. A larger mesh size allows the filter to trap smaller impurities, while a smaller mesh size is designed to capture larger impurities. The filter size should be the same as or one size larger than the outer diameter of the system's main water supply pipe.

### Installation recommendations:

1. The filter must be installed in a proper position. The direction of water flow inside the valve stem must align with the arrow direction marked on the filter. For filters equipped with a drain valve, the drain valve must face downward. Incorrect installation may prevent impurities from being discharged from the filter. Over time, the accumulation of these impurities inside the unit will reduce the filter's effectiveness, increase resistance, decrease water flow in the system, and thus impair the unit's heat exchange efficiency.
2. Ensure there are sufficient straight pipe sections before and after the Y-strainer to guarantee the filtering effect.
3. To facilitate maintenance and cleaning of impurities in the filter, it is recommended to install a globe valve both upstream and downstream of the filter.

### The effect of different mesh counts on water resistance:

The higher the mesh count of a Y-strainer's screen, the higher its filtration precision, and the greater its inherent water resistance.

### Methods for cleaning the filter and determining cleaning intervals:

1. The Y-strainer screen should be cleaned once every 3 months. This prevents the buildup of filtered impurities on the screen, which could increase fluid resistance and disrupt the system's normal circulation.
2. When cleaning, first close the inlet and outlet manual valves, then disassemble the filter and clean it thoroughly. After cleaning, open the inlet manual valve to flush out sediment in the pipeline, allowing water to discharge until the turbidity of the discharged water is close to that of the main pipeline water. After this, repeat the same steps to clean the section of the outlet manual valve.
3. After cleaning, carefully check for water leakage from the filter gasket. If leakage is found, replace the sealing gasket promptly.

(Tips: The above selection is for reference only.)

## 5.7 Safety valve(field supply)

The safety valve is usually installed on the return water side of systems such as air conditioning, boilers, and heat pumps.

Basic requirements: Safety valves are typically constructed from brass or stainless steel, and they are also suitable for media containing ethylene glycol (with a concentration below 30%).

Safety valve specifications	
Design Pressure (bar)	1.5/2.5/3

### Selection recommendations:

The safety valve functions as a safety protection device in the system. When the system pressure exceeds the maximum limit, the safety valve opens to discharge part of the hot water from the system, ensuring the system pressure does not exceed this limit and thus keeping the system within the safe pressure range. The set pressure of the safety valve should match the maximum working pressure of the system. Typically, the parameters provided by the equipment supplier are adequate.

### Installation position of the safety valve:

1. The safety valve should be installed at the highest point or the point of maximum pressure in the water pipeline to ensure smooth flow of the pipeline medium.
2. The safety valve must be installed vertically.
3. The safety valve should be installed in a location that is easy to inspect and adjust, with adequate operating space around it.
4. When the safety valve discharges fluid, it should be directed to an appropriate discharge location.

### Maintenance measures for safety valves:

1. Cleaning: Regularly clean the interior and exterior of the safety valve, and remove deposits from the valve seat and piston to prevent impurities from impairing the valve's sealing performance.
2. Seal inspection: Regularly check the safety valve's sealing performance, particularly the sealing condition of the valve seat and piston. If damage or severe wear is detected, replace the components promptly.
3. Valve lubrication: Apply an appropriate amount of lubricant to the safety valve's opening and closing components as needed to ensure smooth operation.
4. Regular calibration: In accordance with regulations, regularly calibrate the safety valve and inspect its opening/closing pressure and seat sealing performance. If any issues are found to be substandard, adjust or replace the valve promptly.

### Handling abnormal situations:

If abnormalities such as air leakage or valve sticking are detected during the safety valve's operation, promptly shut down the equipment for inspection, repair, or replacement of the safety valve.

(Tips: The above selection is for reference only.)

## 5.8 Secondary water pump(field supply)

Pump selection should satisfy the larger flow rate and head required by the system under both design heating conditions and summer cooling conditions.

If the head of the unit's built-in pump is insufficient to overcome the system resistance, a secondary pump should be added to supplement the head.

Hydraulic calculations must be performed using the water system circuit with the highest resistance. Based on the total pressure loss, and accounting for a safety margin, an appropriate circulation pump should be selected.

### Water head calculation:

The hydraulic calculation formula for floor heating pipes is:  $\Delta P = \Delta P_m + \Delta P_j$

Frictional resistance loss:  $\Delta P_m = R \cdot l$

Local resistance loss:  $\Delta P_j = \xi \frac{\rho v^2}{2}$

The above can be calculated in detail using relevant parameters from the hydraulic calculation verification table.

Alternatively, the following formula can be used for estimation:

Head  $H = K \times$  (height difference between pipes  $h$  (m) + unit water-side pressure loss + longest pipe length (m)  $\times 0.07$ )

Note:

$K$  is a safety factor of 1.1~1.2, take 1.1 for a single water system, and 1.2 for a multi-water system.

The water-side pressure loss unit is kPa, 10kPa = 1 m (H<sub>2</sub>O) head.

In the case of a unit with a built-in water pump, the head of the secondary water pump shall be calculated by subtracting the corresponding head of the unit's water pump.


### Calculation of water pump flow:

Calculate based on 1.2 times the total system flow.

Tips: The water pump should be selected based on the actual engineering installation application, the above calculation is for reference only.

## 5.9 Typical applications


### ① Radiator & Fan Coil(Cooling)



NO.	Item	NO.	Item
1	Heat pump	10	Buffer tank
2	Stop valve	11	Temp. sensor for buffer tank
3	Flexible pipe	12	Electric heater for buffer tank
4	Antifreeze valve	13	Water pump for Zoom C FCU
5	Check valve	14	Bypass valve
6	Y-filter	15	Cooling three-way valve
7	Safety valve	16	Magnetic filter
8	Expansion tank	17	Water pump for Zone A radiator
9	Vent valve		

Note: The installation diagram is for reference only and installation is subject to actual conditions.


②Radiator & Fan Coil(Cooling) & AHS(Boiler)



NO.	Item	NO.	Item
1	Heat pump	11	Vent valve
2	Stop valve	12	Buffer tank
3	Flexible pipe	13	Temp. sensor for buffer tank
4	Antifreeze valve	14	Electric heater for buffer tank
5	Check valve	15	Water pump for Zoom C FCU
6	Y-filter	16	Bypass valve
7	Water pump for AHS	17	Cooling three-way valve
8	AHS(Auxiliary Heating Source)	18	Magnetic filter
9	Safety valve	19	Water pump for Zone A radiator
10	Expansion tank		

Note: The installation diagram is for reference only and installation is subject to actual conditions.


③ Floor Heating & Fan Coil(Cooling) & AHS(Boiler)



NO.	Item	NO.	Item
1	Heat pump	12	Buffer tank
2	Stop valve	13	Temp. sensor for buffer tank
3	Flexible pipe	14	Electric heater for buffer tank
4	Antifreeze valve	15	Water pump for Zoom C FCU
5	Check valve	16	Bypass valve
6	Y-filter	17	Cooling three-way valve
7	Water pump for AHS	18	Magnetic filter
8	AHS(Auxiliary Heating Source)	19	Mixing valve
9	Safety valve	20	Water pump for Zone B floor heating
10	Expansion tank	21	Temp. sensor for after mixing water outlet
11	Vent valve		

Note: The installation diagram is for reference only and installation is subject to actual conditions.


④Radiator & Floor Heating & Fan Coil(Cooling) & AHS(Boiler)



NO.	Item	NO.	Item
1	Heat pump	12	Buffer tank
2	Stop valve	13	Temp. sensor for buffer tank
3	Flexible pipe	14	Electric heater for buffer tank
4	Antifreeze valve	15	Water pump for Zoom C FCU
5	Check valve	16	Bypass valve
6	Y-filter	17	Cooling three-way valve
7	Water pump for AHS	18	Magnetic filter
8	AHS(Auxiliary Heating Source)	19	Mixing valve
9	Safety valve	20	Water pump for Zone A radiator
10	Expansion tank	21	Water pump for Zone B floor heating
11	Vent valve	22	Temp. sensor for after mixing water outlet

Note: The installation diagram is for reference only and installation is subject to actual conditions.


⑤ Radiator & Fan Coil(Cooling) & DHW & Solar Water Heater



NO.	Item	NO.	Item
1	Heat pump	15	Bypass valve
2	Stop valve	16	Water pump for DHW
3	Flexible pipe	17	Cooling three-way valve
4	Antifreeze valve	18	Magnetic filter
5	Check valve	19	Water pump for Zone A radiator
6	Y-filter	20	Water pump for solar heater
7	Hot water three way valve	21	heat exchange coil for hot water tank
8	Safety valve	22	Hot water tank
9	Expansion tank	23	Temp. sensor for hot water tank
10	Vent valve	24	Domestic hot water, such as for bathrooms, etc.
11	Buffer tank	25	Return water pump
12	Temp. sensor for buffer tank	26	Temp. sensor for solar heater
13	Electric heater for buffer tank	27	Solar heater
14	Water pump for Zoom C FCU		

Note: The installation diagram is for reference only and installation is subject to actual conditions.


©Radiator & Fan Coil(Cooling) & DHW & Solar Water Heater & AHS(Boiler)



NO.	Item	NO.	Item
1	Heat pump	16	Water pump for Zoom C FCU
2	Stop valve	17	Bypass valve
3	Flexible pipe	18	Water pump for DHW
4	Antifreeze valve	19	Cooling three-way valve
5	Check valve	20	Magnetic filter
6	Y-filter	21	Water pump for Zone A radiator
7	Water pump for AHS	22	Water pump for solar heater
8	AHS(Auxiliary Heating Source)	23	heat exchange coil for hot water tank
9	Hot water three way valve	24	Hot water tank
10	Safety valve	25	Temp. sensor for hot water tank
11	Expansion tank	26	Domestic hot water, such as for bathrooms, etc.
12	Vent valve	27	Return water pump
13	Buffer tank	28	Temp. sensor for solar heater
14	Temp. sensor for buffer tank	29	Solar heater
15	Electric heater for buffer tank		

Note: The installation diagram is for reference only and installation is subject to actual conditions.


⑦ Floor Heating & Fan Coil(Cooling) & DHW & Solar Water Heater & AHS(Boiler)



NO.	Item	NO.	Item
1	Heat pump	17	Bypass valve
2	Stop valve	18	Water pump for DHW
3	Flexible pipe	19	Cooling three-way valve
4	Antifreeze valve	20	Magnetic filter
5	Check valve	21	Mixing valve
6	Y-filter	22	Water pump for Zone B floor heating
7	Water pump for AHS	23	Temp. sensor for after mixing water outlet
8	AHS(Auxiliary Heating Source)	24	Water pump for solar heater
9	Hot water three way valve	25	heat exchange coil for hot water tank
10	Safety valve	26	Hot water tank
11	Expansion tank	27	Temp. sensor for hot water tank
12	Vent valve	28	Domestic hot water, such as for bathrooms, etc.
13	Buffer tank	29	Return water pump
14	Temp. sensor for buffer tank	30	Temp. sensor for solar heater
15	Electric heater for buffer tank	31	Solar heater
16	Water pump for Zoom C FCU		

Note: The installation diagram is for reference only and installation is subject to actual conditions.

③Radiator & Floor Heating & Fan Coil(Cooling) & DHW & Solar Water Heater & AHS(Boiler)




NO.	Item	NO.	Item
1	Heat pump	17	Bypass valve
2	Stop valve	18	Water pump for DHW
3	Flexible pipe	19	Cooling three-way valve
4	Antifreeze valve	20	Magnetic filter
5	Check valve	21	Mixing valve
6	Y-filter	22	Water pump for Zone A radiator
7	Water pump for AHS	23	Water pump for Zone B floor heating
8	AHS(Auxiliary Heating Source)	24	Temp. sensor for after mixing water outlet
9	Hot water three way valve	25	Water pump for solar heater
10	Safety valve	26	heat exchange coil for hot water tank
11	Expansion tank	27	Hot water tank
12	Vent valve	28	Temp. sensor for hot water tank
13	Buffer tank	29	Domestic hot water, such as for bathrooms, etc.
14	Temp. sensor for buffer tank	30	Return water pump
15	Electric heater for buffer tank	31	Temp. sensor for solar heater
16	Water pump for Zoom C FCU	32	Solar heater

Note: The installation diagram is for reference only and installation is subject to actual conditions.

# 6 Unit installation

## 6.1 Precautions for installation



(A) Installation on a ground

(B) Installation on a flat roof

### 6.1.1 Precautions for installation on a ground

1. Avoid installing in room corners, between walls, or between fences.
2. Prevent air from the air outlet being drawn back into the intake.
3. Ensure no water accumulates on the base.
4. Ensure the base has good water absorption.
5. Prepare a bed of gravel and rubble for condensate drainage.
6. Choose an installation location with no significant snow accumulation in winter.
7. Select a location where the air inlet is not affected by strong winds, position the unit crosswise to the wind direction when possible.
8. If the installation location is not wind-protected, a protective wall is necessary.
9. Note noise emissions; avoid room corners, recesses, or locations between walls.
10. Choose an installation location with good sound absorption, such as areas with grass, hedges, or fencing.
11. Route hydraulic lines and electrical wires underground.
12. Install a safety pipe leading from the outdoor unit through the building wall.

### 6.1.2 Precautions for installation on a flat roof

1. Install the product only in buildings with a solid structural construction and full cast concrete ceilings.
2. Do not install the product in buildings with wooden structures or lightweight roofs.
3. Choose an easily accessible installation location to allow regular removal of foliage or snow from the product.
4. Select a location where the air inlet is not affected by strong winds; position the unit crosswise to the wind direction when possible.
5. If the installation location is not wind-protected, a protective wall is necessary.
6. Note noise emissions; maintain adequate clearance from adjacent buildings.
7. Route hydraulic lines and electrical wires appropriately.
8. Install a wall duct.

### 6.1.3 Occupational safety

1. Ensure safe access to the flat roof.
2. Maintain a 2-meter safety zone from fall edges, along with the clearance required for working on the product; this safety zone must be inaccessible.
3. If this is not feasible, install technical fall protections at fall edges (e.g., sturdy railings) or set up technical safety equipment such as scaffolding or safety nets.
4. Maintain adequate clearance from roof escape hatches and flat-roof windows. Use appropriate protective equipment (e.g., barriers) to prevent people from stepping on or falling through these hatches and windows.

## 6.2 Installation site requirements for the outdoor unit

 <b>CAUTION</b>	
1.	Be sure to distinguish between the unit's inlet and outlet.
2.	The unit should be stored in a room free of continuously operating ignition sources (e.g., open flames, operating gas appliances, or operating electric heaters).
3.	Refer to the unit's installation dimensions during installation.
4.	Do not install the unit in areas frequently used as workplaces. During construction work (e.g., grinding) that generates large amounts of dust, the unit must be covered.
5.	Take note of the unit's installation spacing.
 <b>NOTICE</b>	
1.	Never stack the units on top of one another.
2.	Do not hang the unit from a ceiling.

#### Environment

1. For safety and optimal unit performance, the installation site must have sufficient airflow.
2. For maintenance and service, the installation site should be easily accessible.
3. If the installation site has a high risk of impact (e.g., a vehicle shunting area), impact protection measures must be taken.
4. Keep the unit away from flammable substances and gases.
5. Keep the unit away from heat sources.
6. Keep the unit as protected from raindrops as possible. Do not expose the outdoor unit to dirty, dusty, or corrosive environments.
7. Keep the unit away from ventilation openings and ducts.

#### Nature

Be aware of the impact of nature:

- Vining plants may block the unit's air inlets and outlets as they grow.
- Fallen leaves may block the unit's air inlets or clog the air channels.
- Insects, snakes, or small animals may enter the unit. Wild animals may bite or damage the unit's piping and wiring.

#### Noise impact

1. Choose an installation site as far as possible from living rooms and bedrooms.
2. Note the noise emissions, choose an installation site as far as possible from the windows of adjacent buildings.


#### Altitude

The unit is designed for use at altitudes below 2,000 meters. If installed above this altitude, its performance and reliability cannot be guaranteed.


## 6.3 Installation distance requirement for the outdoor unit

Models: iGXC11

Unit: mm




### 6.3.1 Single installation requirements



- 1. Air inlet
- 2. Air outlet
- 3. Maintenance Panel


Installation space:

Unit: mm




It is recommended to maintain the installation distances shown in the figure when installing the heat pump outdoor.

Unit: mm




### 6.3.2 Cascade installation requirements

Outdoor units must be spaced to allow sufficient air to flow through each unit. Adequate airflow across the heat exchanger is essential for outdoor units to operate properly. The following figure illustrates the minimum distance required for a multi-unit installation setup.



Model	a(mm)	b(mm)	c(mm)	d(mm)
iGXC08	2500	800	5000	300
iGXC11	2500	800	5000	300
iGXC11T	2500	800	5000	300
iGXC13	2500	800	5000	300
iGXC13T	2500	800	5000	300
iGXC16	3000	1000	6000	300

Unit: mm



## 6.4 Special requirements for the outdoor unit

The outdoor unit contains an internal refrigerant circuit (R290), but no on-site refrigerant piping or charging is required.

Please note the following requirements and precautions:


 <b>WARNING</b>
1. Do not pierce or burn components of the refrigerant cycle.
2. Do not use any methods to accelerate defrosting or clean the equipment other than those
3. Note that R290 refrigerant has no odor.
4. The appliance must be protected from mechanical damage and stored in a well-ventilated room (e.g., away from open flames, gas appliances, or electric heaters).
5. Ensure that installation, service, maintenance, and repair comply with iGarden's instructions and applicable legal regulations, and are carried out solely by authorized personnel.

### 6.4.1 In cold climate


It is advisable to position the unit with its rear face flush against a wall. This setup not only boosts stability but also uses the wall to shield the rear components from direct exposure to wind, rain, or debris, helping to extend operational reliability.

A lateral snow canopy should be installed on top of the unit, specifically designed to prevent sideways snow buildup during extreme weather events—such as heavy snowstorms with strong crosswinds. The canopy's dimensions should extend far enough beyond the unit's sides to block drifting snow, stopping it from getting stuck in ventilation gaps or piling up on critical exterior surfaces.

Additionally, the unit must be installed on an elevated pedestal or wall-mounted to maintain a minimum 100mm clearance between the unit's base and any potential snow layer. This gap is vital to avoid direct contact with snow, which could cause moisture-induced corrosion, block bottom vents, or hinder heat dissipation. For pedestal installations, ensure the structure is sturdy enough to support the unit's weight and prevent shifting in icy conditions; for wall mounts, use heavy-duty brackets securely fastened to load-bearing walls to ensure stability.



- ① Canopy or alike
- ② Pedestal in case of installation on a ground



If there is a risk of snow slipping from the roof, a protective roof or cover must be erected to protect the heat pump, pipes, and wiring.


## 6.4.2 Strong wind

Strong winds ( $\geq 5$  m/s) blowing directly at the outdoor unit's air outlet can cause a short circuit (where discharged air is drawn back in).

This may lead to the following issues:

1. Reduced operational capacity.
2. Frequent accelerated frosting during heating operation;
3. Operational disruptions caused by high and low pressure abnormalities.
4. Fan damage (if strong winds blow continuously on the fan, it may spin excessively fast and eventually break).

It is recommended to install a baffle plate if the air outlet is exposed to wind and install the outdoor unit with its air inlet facing the wall, ensuring it is not directly exposed to wind.



- A Baffle plate
- B Prevailing wind direction
- C Air outlet


### 6.4.3 Seaside installation

If the installation site is in close proximity to a coastline, ensure the product is protected from water spray with an additional protective device.

Sea winds carry saline substances inland. Ensure the outdoor unit is not directly exposed to sea winds. This helps prevent corrosion caused by high salt levels in the air, which could shorten the unit's lifespan.


Install the outdoor unit away from direct sea winds. Below is a reference diagram for coastal installations, provided for reference only. To extend the unit's service life, consult professionals for a customized maintenance plan and follow it.

**Example:** Behind the building.



If the outdoor unit is exposed to direct sea winds, install a windbreaker.

1. The height of the windbreaker should be  $\geq 1.5 \times$  the height of the outdoor unit.
2. Ensure service space requirements are taken into account when installing the windbreaker.



## 6.4.4 Others

Do not install the unit in the following locations:

1. Noise-sensitive areas (e.g., near bedrooms) to avoid disturbances from operational noise.

**Note:** When measuring sound under actual installation conditions, the measured value may be higher than the sound pressure level listed in the "Sound Spectrum" section of the data book due to environmental noise and sound reflections.

2. Areas where mineral oil mist, spray, or vapor may be present in the air. Plastic components could deteriorate, fall off, or cause water leakage. The unit is not recommended for installation in the following locations as they may reduce its service life

- Locations with significant voltage fluctuations
- In vehicles or vessels
- Locations with long-term exposure to strong sunlight


**Note:** Prolonged exposure of the unit's ambient temperature sensor to sunlight may negatively affect the sensor and cause adverse impacts on the unit. Use a canopy or similar structure to shade the unit.

## 6.5 Foundation and installing the outdoor unit

### 6.5.1 Foundation

#### Installation on a soft ground

For installations on soft ground such as lawns and soil, construct a foundation as shown in the figure below.



- ① Downpipe for drainage
- ② Strip foundations
- ③ Water-permeable coarse rubble
- ④ Concrete strip foundations

1. Dig a hole in the ground. For the location of the downpipe, refer to 6.6.1 *Drain hole position*.
2. Insert a downpipe ① to divert the condensate.
3. Add a layer of water-permeable coarse rubble ③.
4. Calculate the depth (A) in accordance with local conditions.

5. Region with ground frost: minimum depth: 900 mm
6. Region without ground frost: minimum depth: 600 mm
7. Calculate the height (**B**) in accordance with local conditions. Such height should not be smaller than 100 mm.
8. Create three concrete strip foundations ④. The recommended dimensions can be found in the figure.
9. Make sure the three foundations are level. There are no restrictions on the width or length of the foundations, provided that the unit can be mounted on the foundation properly and the downpipe for drainage is not blocked.
10. Add a gravel bed between and beside the strip foundations ② to divert the condensate.


### Installation on a solid ground

For installations on solid ground (e.g., concrete), construct a concrete strip foundation similar to that described in the previous section. The strip foundation must have a height of at least 100 mm.

### 6.5.2 Unit mounting


Installation with a foundation: Secure the unit using foundation bolts. (Six  $\Phi 10$  expansion bolts, along with nuts and washers, are required and supplied on-site.) Drive the foundation bolts into the foundation to a depth of 20 mm.

Installation without a foundation: Install appropriate anti-vibration pads and ensure the unit is level.



## 6.6 Drainage

1. Ensure proper evacuation of condensation water.
2. Install the unit on a base to ensure adequate drainage and prevent ice accumulation.
3. Prepare a water drainage channel around the foundation to direct wastewater away from the unit.
4. Prevent drain water from flowing over footpaths to avoid slipperiness during freezing ambient temperatures.
5. If installing the unit on a frame, fit a waterproof plate within 150 mm of the unit's bottom to prevent water from entering the unit and to avoid drain water dripping (see the following figure).



### CAUTION


1. Exercise caution with condensate when removing the rubber plug from the additional drain hole.
2. Ensure condensate is properly drained. Collect and direct any condensate that may drip from the unit's base into a drain tray. Prevent water from dripping onto the floor, as this could create a slip hazard—especially in winter.
3. In cold climates, it is strongly recommended to install a belt heater to avoid unit damage caused by frozen drain water, particularly when drainage rates are low.




### NOTICE

1. If the unit is installed in a cold climate, take appropriate measures to prevent the drained condensate from freezing. We recommend the following:
  - Insulate the drain hose.
  - Install a drain tube heater (supplied on-site).
2. Provide at least 150 mm of clearance beneath the unit. Additionally, ensure the unit is positioned at least 100 mm above the expected snow level.

### 6.6.1 Drain hole position




### 6.6.2 Drainage layout



**Installation on a soft ground:**


**① Draining condensate into a gravel bed**

For ground installation, condensate must be discharged via a downpipe into a gravel bed located in a frost-free area.



The downpipe must lead into a sufficiently large gravel bed to allow the condensate to trickle away freely.

**② Draining condensate through a pump sump/soak away**



a-Outdoor unit


b-Concrete strip foundations

c-Foundation (See 5.3.1 Installation on a ground)

d-Drain pipe(at least DN 40)

e-Pump sump/soak away

### ③ Sewer



a-Outdoor unit

b-Concrete strip foundations

c-Foundation (See 5.3.1 Installation on a ground)

d-Drain pipe (at least DN 40)

e-Sewer

f-Stench trap in an area free from frosting risks

#### **Installation on a solid ground:**

Direct the condensation pipe to a sewer, pump sump, or soak away.

The drain plug included in the accessory pack cannot be bent to change direction. For this reason, use a hose to channel the condensate into a sewer, pump sump, or soak away via a gully, balcony runoff, or roof run-off.

Open gullies located within the safety zone do not pose any safety hazards.

# 7 Hydraulic installation

## 7.1 Precautions for hydraulic installation

 <b>CAUTION</b>	
1.	The heat exchanger may be damaged by freezing water due to low water flow.
2.	Incorrect orientation of the water outlet and inlet can lead to unit malfunction.
3.	Do not apply excessive force when connecting on-site supplied pipes, and ensure proper alignment. Deformation of water pipes can cause unit malfunction.
4.	The unit is intended for use solely in a closed water system.
5.	Sediment may damage the plate heat exchanger, and the absence of a strainer poses a risk of refrigerant leakage.
6.	If a potable water source is used as the equipment's water supply, a backsiphonage prevention device must be installed between the potable water source and the equipment.
7.	The installation of a Y-Type strainer at the water inlet is mandatory. To prevent metal particles from damaging the unit, it is recommended to install a magnetic filter before the Y-Type strainer.
 <b>NOTICE</b>	
1.	For plastic pipes, ensure they are completely oxygen diffusion-tight in accordance with DIN 4726. Oxygen diffusion into the piping can cause excessive corrosion.
2.	When circulation in each space heating or cooling loop is controlled by remotely operated valves, it is critical to guarantee a minimum water volume—even when all valves are closed.
3.	Oxygen diffusion into the piping can lead to excessive corrosion.
4.	When a 3-way valve is used in the water loop, a ball valve is recommended to ensure full separation between the domestic hot water loop and the floor heating water loop.
5.	To optimize unit efficiency, install the 3-way valve and domestic hot water tank as close to the unit as possible.
6.	The interior of the pipes must be clean.
7.	When using non-copper metallic piping, ensure two different materials are insulated from each other to prevent galvanic corrosion.
8.	Always use materials compatible with the water in the system and the materials used in the unit.
9.	Ensure that components installed in the field piping can withstand the system's water pressure and temperature.
10.	Drain taps must be installed at the lowest points of the system.
11.	Air vent valves must be installed at the highest points of the system.

## 7.2 Water circuit requirements

### 1. Connecting piping

- Legislation: All piping connections must adhere to applicable legislation and the instructions in the "Installation" chapter, with careful attention to the water inlet and outlet.
- Force: Do not apply excessive force when connecting piping. Piping deformation can cause unit malfunction.
- Tools: Use only suitable tools when handling brass (a soft material); improper tools will damage the pipes.
- Air, moisture, dust: Entry of air, moisture, or dust into the circuit may lead to problems.

### 2. Piping

- Length: It is recommended to avoid long pipe runs between the domestic hot water tank and hot water endpoints (e.g., showers, baths) and to eliminate dead ends.
- Diameter: Select the water pipe diameter based on the required water flow and the pump's available external static pressure.

### 3. Water

- Flow: The minimum water flow required for indoor unit operation is listed in the table below. This flow must be guaranteed in all cases; if it is insufficient, the outdoor unit will stop operating.

Model	Minimum required flow rate
iGXC08	1.05m <sup>3</sup> /h
iGXC11	1.26m <sup>3</sup> /h
iGXC11T	1.26m <sup>3</sup> /h
iGXC13	1.54m <sup>3</sup> /h
iGXC13T	1.54m <sup>3</sup> /h
iGXC16	2.10m <sup>3</sup> /h
iGXC16T	2.10m <sup>3</sup> /h

- Domestic hot water pressure: The maximum water pressure is 4 bar (=0.4 MPa). Adequate safeguards must be installed in the water circuit to prevent exceeding this maximum. The minimum operating water pressure is 1 bar (=0.1 MPa).
- Space heating/cooling circuit pressure: The maximum water pressure is 3 bar (=0.3 MPa). Adequate safeguards must be installed in the water circuit to prevent exceeding this maximum. The minimum operating water pressure is 1 bar (=0.1 MPa).
- Temperature: All installed piping and piping accessories (valves, connections, etc.) must be able to withstand the specified temperatures.

### 4. Field supply components

- Water compatibility: Use only materials compatible with the system's water and the materials of the indoor unit.
- Water pressure and temperature resistance: Ensure all components in the field piping can withstand the system's water pressure and temperature.

### 5. Drainage

- Low points: Install drain taps at all low points of the system to allow complete drainage of the water circuit.
- Pressure relief valve: Properly connect the drain hose to a drain to prevent water from dripping out of the unit.


### 6. Domestic hot water tank

- Capacity: To avoid water stagnation, the storage capacity of the domestic hot water tank must match the daily domestic hot water consumption.
- Post-installation flushing: Immediately after installation, flush the domestic hot water tank with fresh water. Repeat this flushing at least once daily for the first 5 consecutive days after installation.
- Extended standstills: If hot water is not used for an extended period, flush the equipment with fresh water before resuming use.
- Disinfection: For information on the domestic hot water tank's disinfection function, see???. (指向消毒逻辑介绍)

### 7. Others

- Insulation: Insulate piping up to the base of the heat exchanger.

- Freeze protection: Implement measures to protect against freezing.
- Closed circuit: The indoor unit must only be used in a closed water system. Use in an open water system will cause excessive corrosion.
- Air vents: Install air vents at all high points of the system, ensuring they are easily accessible for servicing. The indoor unit is equipped with two automatic air purges; ensure these are not over-tightened to allow automatic air release from the water circuit.
- Zinc-coated parts: Never use zinc-coated parts in the water circuit. The unit's internal water circuit uses copper piping, which can cause excessive corrosion if in contact with zinc-coated components.
- Non-brass metallic piping: When using non-brass metallic piping, insulate brass and non-brass components to prevent direct contact, thus avoiding galvanic corrosion.
- Thermostatic mixing valves: In accordance with applicable legislation, installation of thermostatic mixing valves may be required.
- Hygienic measures: The installation must comply with applicable legislation and may require additional hygienic installation measures.
- Recirculation pump: In accordance with applicable legislation, a recirculation pump may need to be connected between the hot water endpoint and the recirculation port of the domestic hot water tank.



- a** Recirculation connection
- b** Hot water connection
- c** Shower
- d** Recirculation pump

## 7.3 Connecting water piping

### 7.3.1 About connecting the water piping

#### Before connecting the water piping

Make sure the outdoor unit is mounted well.

#### Typical workflow

Connecting the water piping typically consists of the following stages:


1. Connecting the water piping to the outdoor unit.
2. Connecting the recirculation piping.
3. Connecting the drain hose to the drain.
4. Filling the water circuit.
5. Filling the domestic hot water tank (if available).
6. Insulating the water piping.

### 7.3.2 To connect the water piping



#### NOTICE

1. Do not apply excessive force when connecting field piping, and ensure proper alignment. Piping deformation can cause unit malfunction.
2. Install air purge valves at all local high points.



1. Connect the Y-shaped strainer to the water inlet of the unit, and seal the connection with thread sealant. (To provide access to the Y-shaped strainer for cleaning, an extension pipe can be connected between the strainer and the water inlet depending on the field conditions)
2. Connect the pipe provided on the site to the water outlet of the unit.
3. Connect the outlet of the safety valve with a hose with a suitable size and length, and guide the hose to the condensate, please refer to 6.6.2 *Drainage layout*.

## 7.4 Filling water circuit

 NOTICE
1. Ensure both air purge valves are open.
2. All automatic air purge valves must remain open after commissioning.

1. To fill the water circuit, use a field-supplied filling kit, ensuring compliance with applicable legislation.
2. Ensure the automatic air vent valve is open.
3. Maintain a water pressure of approximately 0.2 MPa (2 bar). Use the air vent valves to remove as much air from the loop as possible, as air in the water loop may cause malfunction of the backup electric heater.
4. The maximum water pressure for the water circuit must be less than 0.3 MPa (3 bar).

## 7.5 Freeze protection

### 7.5.1 Protected by software

 CAUTION
1. In the event of a power failure, the aforementioned protective features will not function to safeguard the unit from freezing. Therefore, the unit should always remain powered on.
2. If the unit's power supply is to be switched off for an extended period, the water in the system pipes must be drained to prevent freezing-related damage to the unit and pipeline system.
3. In case of a power failure, add glycol to the water—glycol lowers the water's freezing point.

The software includes specific functions to protect the entire system from freezing, utilizing the heat pump and backup heater (if available).

When the temperature of the water flow in the system drops to a specific value, the unit will heat the water using the heat pump, electric heating tape, or backup heater.

### 7.5.2 Protected by glycol

 WARNING
1. Ethylene glycol is toxic.
2. The presence of glycol can lead to system corrosion. Uninhibited glycol becomes acidic when exposed to oxygen, and this process is accelerated by the presence of copper and high temperatures. This acidic uninhibited glycol attacks metal surfaces and forms galvanic corrosion cells, causing severe damage to the system. Therefore, the following measures are critical: <ul style="list-style-type: none"><li>- Water treatment must be properly performed by a qualified water specialist.</li><li>- A glycol containing corrosion inhibitors must be selected to counteract acids formed by glycol oxidation.,</li><li>- Automotive glycol must not be used, as its corrosion inhibitors have a limited lifespan and it contains silicates that can foul or clog the system.</li><li>- Galvanized pipes must not be used in glycol systems, as they may cause precipitation of certain components in the glycol's corrosion inhibitors.</li></ul>



### CAUTION

1. In the event of a power failure, all software features will fail to protect the unit from freezing. Therefore, always keep the unit powered on.

1. In freezing weather, if water is not drained from the system when the unit is not in use, the frozen water may damage the water circulation components.



### NOTICE

1. Ethylene glycol absorbs moisture from the air. Therefore, do not add ethylene glycol that has been exposed to air—removing the container cap increases water concentration, reducing the glycol concentration below the intended level, which could still lead to freezing of hydraulic components. Take preventive measures to minimize air exposure to ethylene glycol.

2. If glycol is added to the water, do not install freeze protection valves. This could result in glycol leaking from the valves.

3. Required glycol concentrations may vary by type. Always compare the requirements in the table above with the specifications provided by the glycol manufacturer, and adhere to the manufacturer's requirements if necessary.

4. The concentration of added glycol must never exceed 35%.

5. If the liquid in the system is frozen, the pump will not start. Note that even if measures are taken to prevent system bursting, the liquid inside may still freeze.

6. Stagnant water in the system is highly likely to freeze, causing damage.



### INFORMATION

1. Protection against bursting: Glycol prevents the piping from bursting but does not prevent the liquid inside the piping from freezing.

2. Protection against freezing: Glycol prevents the liquid inside the piping from freezing.

Glycol lowers the freezing point of water.

The required ethylene glycol concentration depends on the lowest expected outdoor temperature, as well as whether the goal is to protect the system from bursting or from freezing. More ethylene glycol is needed to prevent the system from freezing.

Add ethylene glycol in accordance with the table below.

Lowest Expected Outdoor Temperature	Burst Prevention	Freeze Prevention
-5°C	10%	15%
-10°C	15%	25%
-15°C	20%	35%
-20°C	25%	—
-25°C	30%	—
-30°C	35%	—

Add propylene glycol


Lowest Expected Outdoor Temperature	Burst Prevention	Freeze Prevention
-------------------------------------	------------------	-------------------

-3°C	10%	15%
-7°C	20%	30%
-13°C	30%	45%
-25°C	40%	—
-37°C	50%	—

### 7.5.3 Protected by anti-freeze valve

Add anti-freeze valve in engineering installation,

Anti-freeze valves allow the drainage of pipe medium when the average temperature of the medium reaches 3°C. This can prevent ice formation in the system circuit. When used in heating engineering installations, it can effectively avoid potential damage to machines and pipes.



### 7.5.4 Others

A battery-powered circulation pump can be installed in the water circuit system. In the event of an emergency, such as a power outage, this pump will activate to continuously circulate water through the circuit, preventing freezing.

Note that its operation is not long-lasting—typically only a few days—so the situation must be addressed urgently within this timeframe.

## 7.6 Filling the domestic hot water tank

1. Open each hot water tap one by one to purge air from the system piping.
2. Open the cold water supply valve.
3. Once all air is purged, close all water taps.
4. Check for water leaks.


## 7.7 Water pipe insulation

 <b>CAUTION</b>
1. One-way valves should not be wrapped with insulation cotton to facilitate future maintenance.
2. Do not use excessive force when connecting field piping, and ensure the piping is properly aligned. Piping deformation can cause unit malfunction.
 <b>NOTICE</b>
1. Make sure the outside piping is insulated as instructed to protect against hazards.

All piping in the complete water circuit **MUST** be insulated to prevent condensation during cooling operation and a reduction in heating and cooling capacity.

For piping exposed to the air, it is recommended to use insulation with a thickness of at least that shown in the table below (with a thermal conductivity  $\lambda=0.039$  W/mK).

Piping length (m)	Minimum insulation thickness (mm)
<20	19
20~30	32
30~40	40
40~50	50



For other scenarios, the minimum insulation thickness can be determined using the Hydronic Piping Calculation tool. This tool also calculates the maximum hydronic piping length from the indoor unit to the outdoor unit (or vice versa) based on the emitter pressure drop.


1. Once all water fittings and pipes are installed and connected, the water pipes must be insulated.
2. Pipe laying and insulation should be completed in a single process, with joints tightly adhered, surfaces smooth, arcs uniform, and no gaps or breaks.
3. Use external insulation materials: When installing the water tank, wrapping its exterior with insulation materials effectively reduces heat loss.
4. Regularly check the water tank's sealing: The sealing of an insulated water tank is critical to its insulation effectiveness. Inspect the tank's sealing regularly to ensure there are no water leaks or heat loss.
5. Use insulation covers: Installing an insulation cover on top of the water tank effectively reduces heat loss. Such covers can be made of insulating materials like insulation cotton or insulation adhesive.
6. Regularly clean the water tank: Internal dirt can impair insulation performance. Regular cleaning to maintain the tank's interior cleanliness improves insulation effectiveness.

# 8 Electrical installation

## 8.1 Opening the electrical box cover

To access the unit for installation and maintenance, follow the instructions below.

 <b>WARNING</b>
1. Risk of electrocution.
2. Risk of burning.
 <b>NOTICE</b>
1. Keep the screws properly for later use.



## 8.2 Precautions for electrical wiring

 <b>WARNING</b>
1. The appliance must be installed in accordance with national wiring regulations.
2. Follow the Wiring Diagram for electrical wiring, which is located on the rear side of the electrical box cover.
3. This appliance includes an earth connection solely for functional purposes.
4. Be sure to install the required fuses or circuit breakers (type AC is sufficient). An all-pole disconnection switch with a contact separation of at least 3 mm in all poles must be connected in the fixed wiring.
5. It is prohibited to install emergency stop switches, remote switches used to stop the unit (including circuit breakers, contactors, and relays) within 2 meters of the unit.
6. Establish electrical connections to the fixed wiring.
7. ALWAYS use multi-core cable for power supply cables.

8. If the power supply has a missing or incorrect N-phase, the equipment may malfunction.
9. Ensure proper earthing. Do not earth the unit to a utility pipe, surge absorber, or telephone earth. Inadequate earthing may result in electrical shock.
10. Install the required fuses or circuit breakers.
11. Secure electrical wiring with cable ties to prevent contact with sharp edges or piping, especially on the high-pressure side.
12. Do not use taped wires, stranded conductor wires, extension cords, or star-system connections, as they may cause overheating, electrical shock, or fire.
13. Do not install a phase-advancing capacitor, as this unit is equipped with an inverter. A phase-advancing capacitor will reduce performance and may cause accidents.
14. Rotating fan: Before powering on or servicing the outdoor unit, ensure the discharge grille covers the fan to protect against contact with the rotating fan.
15. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified personnel to avoid hazards.



**CAUTION**

1. Do not push or store excess cable length inside the unit.
2. A main switch or other disconnection device (with contact separation in all poles) must be included in the fixed wiring, in compliance with relevant local laws and regulations.
3. Use only copper wires.
4. Never squeeze bundled cables; keep them away from piping and sharp edges.
5. Ensure no external pressure is applied to the terminal connections.
6. Field wiring must be performed in accordance with the wiring diagram supplied with the unit and the instructions below.
7. Use a dedicated power source, do not share the power source with another appliance.
8. Properly earth the unit, including the wired controller. Do not connect the unit to a utility pipe, surge protector, or telephone earth. Inadequate earthing may result in electrocution..
9. An earth fault circuit interrupter (30 mA) must be installed to prevent electrical shock. Use 3-core shielded wires.
10. Install the required fuses or circuit breakers.
11. A leakage protection switch must be installed on the unit's power supply.
12. Install an earth fault circuit interrupter and fuse on the power supply line.



**NOTICE**

1. The distance between high-voltage and low-voltage cables must be at least 50 mm.
2. All communication wires, including the unit-to-controller ABXYE line, must be shielded.
3. Use H07RN-F as the power cable. Only the thermistor and wired controller wiring operate at low voltage.
4. Power cables and communication wires must be routed separately and must not be placed in the same conduit, as this may cause electromagnetic interference.
5. Secure electrical wires with cable ties to prevent contact with piping, especially on the high-pressure side.
6. This unit is equipped with an inverter. Installing a phase-advancing capacitor is prohibited, as it will reduce the power factor improvement effect and may cause abnormal heating of the capacitor due to high-frequency waves.
7. The external load current must be less than 0.2 A. If a single load's current exceeds 0.2 A, the load

must be controlled via an AC contactor.
8. The expansion valve electric heating tape, plate heat exchanger electric heating tape, and flow switch electric heating tape share the same terminal port.
9. The equipment must be earthed.
10. Any high-voltage external load that is metal or has an earthed port must be earthed.
11. Ensure the earth fault circuit interrupter is compatible with the inverter (resistant to high-frequency electrical noise) to prevent unnecessary activation.
12. Over-tightening may damage screws. Tighten screws with a proper screwdriver; using an improper screwdriver can damage screws and result in incorrect tightening torque.

## 8.3 Guidelines for connecting electrical wires

### 8.3.1 Field wiring guidelines

1. Most field wiring for the unit connects to the terminal block inside the switch box. To access the terminal block, remove the switch box service panel.
2. Secure all cables using cable ties.
3. The backup heater requires a dedicated power circuit.
4. For installations equipped with a user-supplied domestic hot water tank, the booster heater requires a dedicated power circuit.
5. Please refer to the Installation & Owner's Manual of the domestic hot water tank. Secure the wiring in the order specified below.
6. Route the electrical wires such that the front cover does not lift during wiring, and attach the front cover securely. Install the wires and fasten the cover firmly to ensure a proper fit.

### 8.3.2 Circuit protector selection

1. Select the minimum required wire diameter for each unit individually based on Table 8-1 and Table 8-2. The rated current in Table 8-1 corresponds to the MCA (Minimum Circuit Ampacity) in Table 8-2. If the MCA exceeds 63 A, wire diameters must be selected in accordance with local wiring regulations.
2. The maximum allowable voltage deviation between phases is 2%.
3. Select circuit breakers with a contact separation of at least 3 mm in all poles to ensure full disconnection. MFA (Maximum Fuse Amperage) is used to select current circuit breakers and residual current operation breakers. The inverter PCB is equipped with an overcurrent protector (fuse); if additional overcurrent protectors are required, refer to the TOCA (Total Overcurrent Protection Amperage) in Table 8-2.

Table 8-1

Rated current (A)	Nominal cross-sectional area (mm )	
	Flexible cord	Cable for fixed wiring
≤3	0.5 and 0.75	1 and 2.5
>3 and ≤6	0.75 and 1	1 and 2.5
>6 and ≤10	1 and 1.5	1 and 2.5
>10 and ≤16	1.5 and 2.5	1.5 and 4
>16 and ≤25	2.5 and 4	2.5 and 6
>25 and ≤32	4 and 6	4 and 10
>32 and ≤50	6 and 10	6 and 16
>50 and ≤63	10 and 16	10 and 25

Table 8-2

System	Outdoor unit				Power current		
	Voltage(V)	Hz	Min.(V)	Max.(V)	MCA(A)	TOCA(A)	MFA(A)
8 kW 1 Ph	220-240	50	198	264	10.3	16	16
11 kW 1 Ph	220-240	50	198	264	17.7	24.8	25
11 kW 3 Ph	380-415	50	342	456	8.4	14.6	16
13 kW 3 Ph	380-415	50	342	456	9.1	15.2	16
16 kW 3 Ph	380-415	50	342	456	11.1	18.3	20

MCA: min. circuit current. (A)


TOCA: total over current (A)

MFA: max. fuse current (A)

### 8.3.3 Tightening torque

Item	Tightening torque (N·m)
M4 (power terminal, electric control board terminal)	1.2 to 1.4
M4 (earthing)	1.2 to 1.4

### 8.3.4 Back plate layout for connection



- A Outlet water
- B Inlet water
- C Drainage
- D Cable hole

## 8.4 Connection with power supply

### 8.4.1 Precautions

For connecting the unit to a power supply terminal, use a circular wiring terminal with an insulated casing (see Figure 7.1).

If such a circular wiring terminal cannot be used, follow these instructions:

- Use a power cord meeting the specified requirements and connect it firmly. Apply the appropriate tightening torque specified in the "Tightening torques" section above to prevent the cord from being accidentally pulled out by external force.
- Do not connect two power cords of different diameters to the same power supply terminal. This could lead to loose wiring, causing the wires to overheat (see Figure 7.2).





Figure 7.1



Proper power wiring connections






Figure 7.2

### 8.4.2 Wiring of main power supply

#### a. For power supply: 230V 50Hz



#### b. For power supply: 400V 50Hz



Note:

1. The disconnection incorporated in the fixed wiring shall be in accordance with AS/NZS 3000 Electrical installations shall be provided with devices to prevent or remove hazards associated with the electrical installation and for maintenance of electrically activated equipment. Electrical installations shall include all switching devices or other means of disconnection necessary to enable operations, repairs and maintenance work to be carried out with safety.
2. Supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (code designation 60245 IEC 57).

## 8.5 Installation of wired controller

 <b>CAUTION</b>	
1.	The general wiring instructions in previous chapters must be followed.
2.	The wired controller must be installed indoors and protected from direct sunlight.
3.	Ensure the wired controller is kept away from ignition sources, flammable gases, oil, water vapor, and sulfide gases.
4.	To prevent electromagnetic interference, maintain a proper distance between the wired controller and electrical appliances (e.g., lamps).
5.	The remote wired controller operates on a low-voltage circuit. Never connect it to a standard 220 V/380 V circuit, nor place it in the same wiring tube as such a circuit.
6.	If signal wire extension is needed, use a terminal connection block.
7.	Do not use a megger to test the insulation of the signal wire after connection is completed.


### 8.5.1 Materials and requirements for installing the wire controller

No.	Name	Qty	Remarks
1	Wired controller	1	/
2	Screws	2	/
3	Wall-mounted panel	1	86mm*88mm

1. Install at a height of 1 to 1.5 meters from the floor.
2. Mount vertically on the wall.
3. Avoid installation in the following locations:
  - Near windows or other areas exposed to direct sunlight or direct airflow.
  - In shaded areas or behind objects that disrupt the room's airflow.
  - Locations prone to condensation.
  - Near heat sources.
  - On uneven surfaces.

### 8.5.2 Dimensions


Unit: mm



### 8.5.3 Wired controller installation and connection

#### 1. Drilling into the wall:

Press the wall panel firmly against the wall surface. Drill holes along the positioning center points and insert M4-compatible expansion anchors.




#### 2. Wall Panel Installation:

Screw two M4 screws into the wall holes along the wall to secure the mounting bracket.



3. Secure the cable:

Cut the notch in the plastic housing and thread the cable through.




4. Installing the display:

Note: Installation can be adjusted based on the actual usage direction.



## 8.6 Connection of other components

Customers can connect different auxiliary devices according to their needs, based on the circuit diagram shown in the figure.



For the temperature Sensor:


**AI5A** means Bottom Temp. of BT

**AI5B** means Top Temp. of BT

**AI5C** means DHW tank temp

**AI5D** means Outlet temp.of whole system

**AI5E** means Inlet temp. of FH



**L1 H**:Thermostat Signal H

**L1 C**:Thermostat Signal C

**P\_O N**:Secondary Circulation Pump

**SL1 SL2**:Solar water heater

**IBH1**:Electric heat1

**IBH2**:Electric heat2

**TBH**:DHW tank heater

**2OFF/2ON N**:Cooling 3 way valve

**3OFF/3ON N**:Mixing 3 way valve

**1OFF/1ON N**:DHW 3 way valve

**AHS1 AHS2**:Auxiliary heat source

**HT N**:Pan heater

**P\_R N**:Return water pump

**P\_M N**:Mixing water pump

**P\_S N**:Solar water pump

**DFR1 DFR2**:Defrost signal

**ERR1 ERR2**:Error signal

# 9 Display Operation Guide

## 9.1 Main Interface



No.	Meaning	Description
①	Menu	After clicking this button, the unit will enter the function menu interface, where you can configure various custom modes.
②	Mode setting	After clicking this button, you can configure the unit mode settings. There are three modes available: Heating, Cooling, and Auto.
③	Power consumption	The number indicates real-time power consumption, while the bar chart shows hourly power consumption for the current day. If power consumption is not enabled, the main screen will not show.
④	Screen lock	After locking, the display cannot be operated; Press the button again to unlock the screen.
⑤	Operating strategy	After clicking this button, you can select the unit's operating strategy. There are three strategies available: Turbo, Standard, and Silent.
⑥	100% Green enable button	After clicking this button, the unit will operate in conjunction with the solar inverter device. Note: This function requires the installation of iGarden's Inverter to be enabled.
⑦	DHW setting	Upper shows the target DHW temperature. You can slide the ring to set the target temperature or click the target temperature to set it. Lower shows the actual temperature of the hot water tank.
⑧	DHW switch	You can turn the DHW function on or off.

⑨	Fault icon	When a fault occurs, this icon will appear. Clicking it will take you to the fault log interface for viewing.
⑩	WiFi icon	It indicates the current network settings status. Clicking this icon to access the network settings interface.
⑪	SG Ready icon	When the SG Ready function is enabled, this icon will be illuminated, otherwise, it will be dim.
⑫	Defrosting icon	When the Defrosting is enabled, this icon will be illuminated, click can enable the forced defrost.
⑬	System time	Shows the date and time. Click can modify the date and time.
⑭	100% Green icon	When the 100% Green function is enabled, this icon will be illuminated.
⑮	Ambient temp.	It shows the current ambient temperature.
⑯	Electric heater	When the Electric heater is enabled, this icon will be illuminated, otherwise, it will be dim. Click the icon to access the forced opening settings
⑰	Operating strategy icon	It shows the current Operating strategy
⑱	On/off timer icon	When the Timer function is enabled, this icon will be illuminated. Click this icon to access the timer settings interface.
⑲	Heating/Cooling On/Off	You can turn the cooling/heating on or off.
⑳	Cooling/Heating Temperature Setting	It will show the current cooling/heating target temperature. Slide the ring to set the target temperature. You can also set the target temperature by tapping it; after tapping, the device will enter the target temperature setting interface. Current Temperature: shows the current temperature.


### 9.1.1 ON/OFF

Click the ON/OFF switch button corresponding to each zone on the main interface to enable/disable cooling, heating, or hot water for that zone.



### 9.1.2 Adjusting Temperature

Slide the ring to set the target temperature. You can also set the target temperature by tapping it; After tapping, the device will enter the target temperature setting interface



Enter the setting temperature directly, then click the checkmark to save the adjusted temperature value.

### 9.1.3 Air conditioning mode settings

There are three air conditioning modes: 1. Cooling mode, 2. Heating mode, 3. Auto mode. Click  on the main interface to open the air conditioning mode settings, as shown:



Click the mode you want to set.

### 9.1.4 Screen unlock

If the lock screen icon appears, the display will not be operable, as shown in the picture:



Click the lock screen icon again, and it will disappear, showing the main interface. The display can be operated again.

### 9.1.5 Power Mode Settings


There are four power modes: 1. Standard Mode, 2. Turbo Mode, 3. Silent Mode, 4. Auto Mode. Click the power mode settings will show on the main interface, as shown:




Click the mode you want to set.

### 9.2 Main menu

Click the Menu button  to enter the main interface.






## Query Menu

The Query Menu contains three interfaces:

- ① Analog Input Query Interface
- ② Load Output Query Interface
- ③ Program Version Query Interface


### 9.2.1 Analog Input Query Interface

This interface can be accessed to view the unit's current information (such as temperature, active electrical components, etc.).




### 9.2.2 Load Output Query Interface

On the output interface, you can view the output status of each load component. When the corresponding button icon illuminates, it indicates that the component is active.



### 9.2.3 Program Version Query Interface

When handling certain after-sales issues, providing the software information used by the unit controller may be necessary to facilitate better troubleshooting. This information can be found by accessing the version query interface.



## 9.3 Display Setting

Display settings allow you to configure everyday preferences such as language, screen brightness, lock screen functionality, and keypad sounds.



### 9.3.1 Language Setting

Users can select the language as they need.

### 9.3.2 Brightness setting

This display offers three brightness levels: high, medium, and low. Users can select the appropriate brightness based on their usage environment and personal preferences.

### 9.3.3 Screen saver



The display will enter screen saver mode after a period of inactivity. The duration before entering screen saver mode can be customized according to user preferences.

When the display is in screen saver mode, simply click the screen to resume normal operation.

Note: Setting the "Screen Saver Time" to 0 disables the screen saver function, keeping the screen constantly on.

### 9.3.4 Alarm Sound Setting

Users may configure whether an alarm sound is generated when faults occur, based on their specific needs. The following four modes are available:



- ① Continuous Sound: The alarm will sound continuously until the fault query interface is accessed and the fault is cleared.
- ② No Sound: No corresponding alarm sound will be generated when a fault alarm occurs.
- ③ Ten-Second Sound: When a fault alarm occurs, the alarm sound will ring for ten seconds and then stop.
- ④ Ten-Second Cycle: When a fault alarm occurs, the alarm sound will sound for ten seconds and then stop. If the fault remains unresolved after thirty minutes, the alarm sound will sound again for ten seconds and then stop, repeating this cycle until all faults are resolved.

### 9.3.5 Keypad buzzer

In the display settings interface, you can enable or disable the "Keypad Buzzer" to control the audio feedback for this display's operations.


Enable Keypad Buzzer: Provides audible feedback during touch operations.

Disable Keypad Buzzer: No audible feedback during touch operations.

## 9.4 Time and Date

The date and time shown at the top of the main interface will synchronize with the network. If they do not match the actual date and time, you will need to manually adjust and calibrate them.

As shown in the image below:



## 9.5 Timer setting

The Timer Settings interface offers four functions: Timer Power On/Off, Disinfection Timer, Silent Timer, and DHW Pump Timer, as shown below:




### 9.5.1 Timer on/off

Click to enter the Timer On/Off menu, where you'll find three options: Daily Timer, Weekly Timer, and Cancel Timer.



#### Daily Timer

Select "Daily Timer" to enter the daily timer settings interface. Within this interface, you can configure multiple timer schedules. Each schedule allows you to set its execution time, operating mode, and operating temperature independently. By turning the corresponding number on the left on or off, you can enable or disable that specific schedule.



Example: Set the timer according to the following five groups in the table.

No.	Start Time	End Time	Mode	Set Temp.
1	1: 00	6: 00	DHW	50°C
2	7: 00	9: 00	Heating	30°C
3	11: 00	13: 00	Cooling	20°C
4	16: 00	19: 00	Cooling	20°C
5	20: 00	22: 00	DHW	50°C


Specific operational procedures for the unit are as follows:

Time	Unit Action
1: 00	DHW Mode On
6: 00	DHW Mode Off
7: 00	Heating Mode On
9: 00	Heating Mode Off
11: 00	Cooling Mode On
13: 00	Cooling Mode Off
16: 00	Cooling Mode On
19: 00	Cooling Mode Off
20: 00	DHW Mode On
22: 00	DHW Mode Off

Note: The timer settings for this group will be invalid if the start and end times are identical, the start time is later than the end time, the settings span multiple days, or the temperature exceeds the allowed range for this mode.

## Weekly Timer

In the timer menu, select "Weekly Timer" to access it. Weekly Timer allows you to select specific days of the week to execute the daily timer schedule, based on the daily timer settings.



Note:

- ① Daily and weekly timers cannot be enabled simultaneously.
- ② Timer setup procedures are identical to daily power-on/off operations and are not repeated here.
- ③ Timer groups will be invalid if:
  - Start and end times are identical

- Start time is later than end time
- Settings span multiple days
- Temperature exceeds the mode's permissible range

### Cancel Timer

To cancel all scheduled power-on/off settings at once (without affecting other timed functions), follow the steps outlined in this section.

In the Timed Power On/Off menu, tap "Clear Timers." A confirmation pop-up will appear; tap the checkmark (✓) to confirm clearing the timers and close the pop-up.

If a daily or weekly timer is active, the timer icon will appear on the main interface. If a daily or weekly timer is inactive, the timer icon will not appear on the main interface.


### 9.5.2 Disinfection Function

The disinfection function is designed to eliminate bacteria and pathogens within the hot water tank. The tank temperature will be forced to reach 61-70 degrees Celsius (the exact value determined by the parameter "Disinfection Temperature"), which can be configured in the advanced settings.

#### Disinfection Timer

Before using the disinfection function, ensure that the parameter under "User Parameters" > [Scheduled Disinfection Function] is set to Enabled (refer to the parameter table in User Parameters for details). If this parameter is set to Disabled, the disinfection function will not be available. Below are instructions for scheduled and manual operation. For scheduled use:

On the main screen, press  to enter the menu. Locate and select "Timer Settings". Click to choose "Scheduled disinfection".



After setting the start time, select the day or days of the week when it should take effect on the right side.

#### Manual disinfection

Manual control takes precedence over timed control. The manual disinfection function can be activated or deactivated by setting the "Current Status."

If the current status is "Off," manually click to activate the disinfection function.


If the current status is "On," manually click to deactivate the disinfection function.

### 9.5.3 Silent timer

To prevent excessive noise during machine operation from affecting user experience or disturbing others, we can activate silent mode during specific periods to reduce noise levels. Silent mode offers two levels: Level 1 and Level 2. In Level 2 mode, the max. speed of the fan and compressor is lower than in Level 1.

Click to select "Scheduled Quiet Mode" to enter the settings interface. Within this interface, you can choose the quiet level (Level 1 or Level 2), as well as the start and end times.


There are two sets of scheduled times available. Use the toggle switch to the left of each set to enable or disable that specific schedule.



### 9.5.4 DHW Pump Timer

The DHW Pump Timer function returns water to the water network, enabling nearly instant hot water upon turning on the faucet without waiting for cold water to drain out. This significantly conserves water resources while enhancing user comfort.

By switching the timers for each numbered group, you can activate or deactivate the timer for that group. Setting the start time for the return water pump will achieve zero cold water flow at that moment.




## 9.6 WiFi Setup

For details, please refer to the Network Setup User Manual.

## 9.7 User Parameter Settings

On the main interface, click to enter the settings menu, locate "User Parameter Settings," and select it.

User parameters can be directly accessed by end users. The interface is shown in the figure below:



For additional user parameters, please refer to the table below (actual parameters are subject to the show on the display).

Setting Item	Setting Range	Unit
CTRL_MODE	Cooling Mode Heating Mode Auto Mode	
COOL_TEMP_SET	min...max	°C
HEAT_TEMP_SET	min...max	°C
HOT_WATER_TEMP_SET	min...max	°C
COOL_ROOM_TEMP_SET	16...30	°C
HEAT_ROOM_TEMP_SET	16...30	°C
HEAT_TEMP_SET_B	40...60	°C
HEAT_ROOM_TEMP_SET_B	16...30	°C
POWER_MODE	Standard/Turbo/Silent/Auto	
STERILIZATION	Disable/Enable	
STERILIZATION_TEMP	60...70	°C
STERILIZATION_CYCLE_MAX	90...300	Min
STERILIZATION_HIGH_TEMP_TIME	5...60	Min
Zone A Cool Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp. Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9	
Zone A Heat Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp. Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9	
Zone B Cool Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp. Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9	
Zone B Heat Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp. Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9	
C#9_TA_C1	-5...46	
C#9_TA_C2	-5...46	
C#9_TWout2_C1	5...25	
C#9_TWout2_C2	5...25	
C#9_TA_H1	-25...35	
C#9_TA_H2	-25...35	
C#9_TWout2_H1	25...65	
C#9_TWout2_H2	25...65	
00#UNIT	[0]Disable;[1]Enable	

## AT Compensation Function

Ambient temperature compensation allows presetting the target water temperature based on external ambient conditions. When weather warms up, heating output is reduced. To conserve energy, the ambient temperature compensation function selects a lower target water temperature for heating when external ambient temperatures rise.

In the User Parameters interface, select one or more of the following as needed: "Zone A Cooling Curve," "Zone A Heating Curve," "Zone B Cooling Curve," and "Zone B Heating Curve." Choose to disable or use different "AT Compensation Function"

Note: Ambient temperature compensation curves are divided into cooling and heating modes, each employing distinct curves. For heating, there are 8 low-temperature curves, 8 high-temperature curves, and one curve generated by settings. For cooling, there are 8 low-temperature curves, 8 high-temperature curves, and one curve generated by settings. These curves are presented in tabular form in ANNEX C. Please refer to ANNEX C for details.

## 9.8 Manual Defrost

During normal operation, the unit is equipped with an intelligent (automatic) defrost function. However, in certain special

circumstances, manual defrosting may be required. Click  on the main interface to quickly access the manual defrost page.




On the manual defrost settings interface, the current status of each module is shown, such as module stopped, module running, and module defrosting.

Only when the module is in the running state and conditions like water temperature and fin temperature are met, clicking "Manual Defrost" will successfully initiate defrosting. At this point, the module's current status will switch to defrosting. Otherwise, it will remain in its original state.

## 9.9 Force Open Function

To enhance the system's heating efficiency and adaptability under specific conditions, ensuring effective heating across various climates and usage scenarios, this unit features functions such as underfloor heating drying, forced activation of auxiliary electric heating, and forced activation of water tank electric heating.

On the main interface, press  to enter the "Forced Open Function" page.



### 9.9.1 Floor Heating Drying Function

Using the floor heating drying function allows the floor heating system to reach optimal operating condition before formal commissioning. This ensures system performance and longevity while guaranteeing safe and efficient operation.

This function can only be activated when the [floor heating inlet temperature sensor] is in use and the unit is in standby mode.

### 9.9.2 Forced open auxiliary electric heater

Auxiliary electric heater can enhance the heating capacity of the unit during extremely cold weather conditions, but it consumes more energy. It is recommended to use this feature only as an emergency or supplementary measure when necessary.

This function can only be activated when [Auxiliary Electric Heater] is enabled and the unit is operating in heating mode.

### 9.9.3 Force open water tank heater

Force-open water tank heater enables rapid water heating by forcibly activating the tank's electric heating element, enhancing user experience.

When the system requires cooling or heating and the heat pump operates in cooling or heating mode, hot water demand may arise. The force-open water tank heater function can then be used to produce hot water.

### 9.9.4 Forced open DHW mode

The Forced DHW Mode function compels the system to operate in hot water production mode. During this mode, the heat pump, auxiliary electric heating, water tank electric heating, and external heat sources will all activate provided their respective conditions are met.

### 9.9.5 Force open external heat source

External heat sources primarily refer to heat sources other than the heat pump itself, including natural gas boilers, industrial waste heat recovery, and geothermal energy. Integrating these existing external heat sources within the user's home enhances the stability of the heating system.

In heating or DHW mode, external heat sources can be manually activated to provide additional heat.

## 9.10 Holiday Mode

### 9.10.1 Holiday Away Mode

Holiday Away Mode is commonly used during winter vacations to prevent water pipes from freezing. Activate this mode after leaving home and deactivate it before returning. Access the Holiday Away Mode settings interface.




Application Example: Suppose the current date is January 3, 2025. You will be away for two weeks starting three days later, departing on January 6, 2025, and returning on January 20, 2025. To prevent water pipes from freezing, configure settings as shown in the table below.

Parameter Name	Parameter Value
Function Usage	Use
Start	06-01-2025
End	20-01-2025
Heating Mode Usage	Use
DHW Mode Usage	Use


### 9.10.2 Holiday Stay-at-Home Mode

Holiday At Home mode functions similarly to Scheduled mode. When Holiday At Home mode is active, any scheduled settings will be invalidated.



For example, if the Holiday At Home function is enabled and set to activate from July 1, 2025, to August 8, 2025, the regular scheduled function will operate before July 1, 2025, and after August 8, 2025. During the period from July 1, 2025, to August 8, 2025, the Holiday At Home function will be executed.


### 9.11 Fault Inquiry Interface



### 9.11.1 Current fault


Click the fault code on the main interface to view the current fault page.

In the current fault section, if a fault is present, the current fault interface appears as shown below (click the  reset button to clear all faults meeting the reset conditions).



### 9.11.2 Historical faults

All faults that have occurred on the unit (including those that have been reset) are recorded in the controller and can be queried in the historical faults section.



 This interface shows the fault code, occurrence time, and fault description for each past incident. Clicking the  "Clear" button will erase all historical faults. Please exercise caution before proceeding to avoid accidental deletion.

# 10 Configuration

## 10.1 Overview: Configuration

This chapter outlines the necessary steps and information required to configure the system after installation.

Failure to configure the system correctly may result in unexpected operation. System configuration affects the following:

- Software calculations
- User interface display and functionality

The unit must be configured by an authorized installer to align with the installation environment (such as outdoor climate and installed options) and meet user requirements.

## 10.2 Check before configuration

<input type="checkbox"/>	<b>Field wiring:</b> Ensure all wiring connections comply with the instructions in "8. Electrical installation".
<input type="checkbox"/>	<b>Fuses, circuit breakers, or protection devices:</b> Verify their size and type against the instructions in "8.3 Guidelines for Connecting Electrical Wires". Ensure no fuses or protection devices have been bypassed.
<input type="checkbox"/>	<b>Backup heater's circuit breaker:</b> Confirm the backup heater's circuit breaker in the switch box is closed (varies by backup heater type). Refer to the wiring diagram.
<input type="checkbox"/>	<b>Booster heater's circuit breaker:</b> Ensure the booster heater's circuit breaker is closed (only applicable to units with an optional domestic hot water tank).
<input type="checkbox"/>	<b>Internal wiring:</b> Inspect wiring and connections inside the switch box for looseness or damage, including earth wiring.
<input type="checkbox"/>	<b>Mounting:</b> Verify that the unit and water loop system are properly installed to prevent water leakage, abnormal noises, and vibrations when the unit starts.
<input type="checkbox"/>	<b>Damaged equipment:</b> Inspect internal components and piping for damage or deformation.
<input type="checkbox"/>	<b>Refrigerant leak:</b> Check for refrigerant leakage inside the unit. If a leak is found, follow the relevant guidelines in "Safety Precautions".
<input type="checkbox"/>	<b>Power supply voltage:</b> Check the power supply voltage to ensure it matches the voltage specified on the unit's identification label.
<input type="checkbox"/>	<b>Air vent valve:</b> Ensure the air vent valve is open (at least 1 full turn).
<input type="checkbox"/>	<b>Shut-off valve:</b> Confirm the shut-off valve is fully open.
<input type="checkbox"/>	<b>Sheet metal:</b> Ensure all sheet metal components of the unit are correctly installed.
<input type="checkbox"/>	<b>Water volume:</b> Verify the system's water volume is within the specified limits.
<input type="checkbox"/>	<b>Strainer:</b> Ensure the strainer is correctly installed and clean.

After powering on the unit, check the following items:

<input type="checkbox"/>	<b>Upon power-on of the unit, nothing is displayed on the wired controller:</b> Before diagnosing possible error codes, check for the following issues, - Wiring connection problems (power supply or communication signal).
--------------------------	---

	- Fuse failure on the PCB.
<input type="checkbox"/>	<p><b>Error code "water flow protection" is displayed on the wired controller:</b></p> <ul style="list-style-type: none"> <li>- There is residual air in the system.</li> <li>- The water level in the system is insufficient.</li> </ul> <p>Before starting the test run: Ensure the water system and tank are filled with water and all air is purged. Otherwise, the pump or backup heater (optional) may be damaged.</p>
<input type="checkbox"/>	<p><b>Error code "Communication error" is displayed on the wired controller:</b></p> <ul style="list-style-type: none"> <li>- Check the wiring between the wired controller and the unit.</li> </ul>
<input type="checkbox"/>	<p><b>Initial start-up at low outdoor ambient temperature:</b></p> <p>To perform the initial start-up in low outdoor ambient temperatures, the water must be heated gradually. Gradually open the end-load to allow the water temperature to rise steadily.</p>

# 11 Commissioning

## 11.1 Overview: Commissioning

This chapter describes what you have to do and know to commission the system after it is installed and configured.

### Typical workflow

Commissioning typically consists of the following stages:

1. Checking the "Checklist before commissioning".
2. Performing an air purge.
3. Performing a test run for the system.
4. If necessary, performing a test run for one or more actuators.

## 11.2 Precautions during commissioning

 CAUTION
1. When connecting the power supply: Connect the earth cable first, before making the current-carrying connections.
2. When disconnecting the power supply: Disconnect the current-carrying cables first, before separating the earth connection.
3. After completing electrical work, confirm that each electrical component and terminal inside the electrical components box is securely connected.

## 11.3 Checklist before commissioning

Before starting the unit, a number of verifications must be carried out on the installation process to ensure the unit can operate under optimal conditions. The following checklist is not exhaustive and should only be used as a minimum reference standard.

<input type="checkbox"/>	The complete installation instructions, as outlined in the installer reference guide, have been read.
<input type="checkbox"/>	The fan rotates freely without obstruction.
<input type="checkbox"/>	The flow direction of all water pipes is correct.
<input type="checkbox"/>	All system piping operates in accordance with installation requirements.
<input type="checkbox"/>	The unit's power supply voltage has been checked and is within authorized limits.
<input type="checkbox"/>	The unit is properly grounded.
<input type="checkbox"/>	Protective devices and disconnecting devices are present.
<input type="checkbox"/>	All electrical connections are tight and secure.
<input type="checkbox"/>	All pipes are free of leaks, and adequate air ventilation is ensured.

<input type="checkbox"/>	Fuses or locally installed protection devices are installed as specified in this document and have not been bypassed.
<input type="checkbox"/>	Pipes of the correct size are installed and properly insulated.
<input type="checkbox"/>	Shut-off valves are correctly installed and fully open.
<input type="checkbox"/>	Automatic air purge valves are open.
<input type="checkbox"/>	The pressure relief valve discharges water when opened, and the water is clean.
<input type="checkbox"/>	The domestic hot water tank is completely filled.
<input type="checkbox"/>	The minimum water flow is guaranteed under all conditions.

## 11.4 Checklist during commissioning

<input type="checkbox"/>	The minimum flow rate during backup heater/defrost operation is guaranteed under all conditions.
<input type="checkbox"/>	An air purge must be performed.
<input type="checkbox"/>	An actuator test run must be performed.
<input type="checkbox"/>	A test run must be performed.

### 11.4.1 Minimum flow rate

Model	Rated Water Flow Rate	Minimum Water Flow Rate to be Guaranteed
iGXC08	1.50m <sup>3</sup> /h	1.05m <sup>3</sup> /h
iGXC11	1.80m <sup>3</sup> /h	1.26m <sup>3</sup> /h
iGXC11T	1.80m <sup>3</sup> /h	1.26m <sup>3</sup> /h
iGXC13	2.20m <sup>3</sup> /h	1.54m <sup>3</sup> /h
iGXC13T	2.20m <sup>3</sup> /h	1.54m <sup>3</sup> /h
iGXC16	3.00m <sup>3</sup> /h	2.10m <sup>3</sup> /h
iGXC16T	3.00m <sup>3</sup> /h	2.10m <sup>3</sup> /h

### 11.4.2 Water pressure adjustment requirements

1. Before the test, the pipes must be fixed, and the connections shall be laid exposed.
2. A pressure gauge, with a pressure accuracy of 0.01 MPa, must be installed at the lowest part of the test pipe section.
3. Slowly fill the pipe with water starting from the lowest section, fully expel the air from the pipe, and conduct a water tightness test.
4. Pressurize the pipe slowly using a manual pump; the pressurization process shall take no less than 10 minutes.
5. After pressurizing to the specified test pressure, maintain a stable pressure for 1 hour. The pressure drop shall not exceed 0.06
6. At 1.15 times the working pressure, maintain a stable pressure for 2 hours. The pressure drop shall not exceed 0.03 MPa.
7. Before the test, ensure there are no leaks at any connection points.
8. Within 30 minutes, up to two pressure replenishments are allowed to reach the specified test pressure.

### 11.4.3 Air purge

 <b>NOTICE</b>
1. Before starting the air purge, open the safety valve and check whether the water circuit is sufficiently filled with water. Only when water flows out of the valve after opening it can you start the air purge procedure.
 <b>INFORMATION</b>
1. For best results, each loop should be air-purged separately.
2. Ensure all air is purged before conducting the test run. Additionally, avoid disturbances in the water circuit during the test run.

#### Why

During the commissioning and installation of the unit, it is crucial to expel all air from the water circuit. If air is not fully purged from the water circuit of a heat pump system, multiple critical problems may occur:


1. **Air locks:** Trapped air can obstruct water flow, disrupting circulation in pipes or components such as heat exchangers. This impairs heat transfer efficiency, resulting in subpar heating/cooling performance and uneven temperature distribution.
2. **Cavitation:** Air bubbles in the water can collapse violently under pressure, leading to cavitation. Over time, this erodes pump impellers, valves, and pipe walls, damaging components and shortening their service life.
3. **Corrosion acceleration:** Oxygen in trapped air reacts with metal surfaces (such as pipes and heat exchangers), accelerating rust and corrosion. This weakens the system's structural integrity, raises the risk of leaks, and may necessitate premature part replacement.
4. **Increased noise and vibration:** Air in the water circuit causes turbulent flow, leading to gurgling sounds, vibrations, or unstable operation of pumps and fans.
5. **System inefficiency or failure:** Restricted water flow and reduced heat exchange can force the heat pump to operate under heavier loads, increasing energy consumption. In severe cases, this may trigger safety shutdowns or complete system failure due to overheating or pressure imbalances.

## How


1. Click the Menu button to enter the main menu interface.




2. Find Advanced Settings on the main menu interface and click it, then enter the password 123456.



3. Find the Manual Test and select



4. Find the main circulation pump and turn it on. The pump will continuously circulate water through the system until all air is purged from the pipes.



### 11.4.4 Actuator test run

 <b>NOTICE</b>
1. During the commissioning of the actuator, the protection function of the unit is disabled. Excessive use may damage components.

**Why**

Check whether each actuator is in good working conditions.

**What - Actuator List**


No.	Code Name	Load	Note
1	SL1 SL2	Solar water heater	
2	P_O N	Secondary Circulation Pump	
3	IBH1	Electric heater1	
4	IBH2	Electric heater2	
5	TBH	DHW tank heater	Invisible if DHW is disabled
6	20FF/20N N	Cooling three way valve	
7	30FF/30N N	Mixing valve	
8	10FF/10N N	DHW three way valve	
9	AHS1 AHS2	Auxiliary heat source	
10	HT N	Pan heater	
11	P_R N	Return water pump	Invisible if DHW is disabled
12	P_S N	Solar water pump	
13	P_M N	Mixing water pump	

**How**


1. Click the Menu button to enter the main menu interface.




2. Find Advanced Settings on the main menu interface and click it, then enter the password 123456.



3. Find the Manual Test and select



4. Select the corresponding actuator for testing.



#### 11.4.5 Unit test run



#### INFORMATION

1. If the outdoor temperature is outside the operating range, the unit may fail to operate or fail to deliver the required capacity.

#### Why

Conduct test runs on the unit and monitor the leaving water temperature and tank temperature to verify that the unit is functioning properly.

#### What

Circulated pump operation

Cooling operation

Heating operation

DHW operation

#### How



1. Press the "1 OFF" button on the wired controller to start the heat pump. Check if the water pump is running.

2. When the water pump has been running for 3 minutes, the compressor will start.

Listen for any strange sounds from the compressor. If an abnormal sound occurs, stop the heat pump and check the compressor. If the compressor is running well, check the refrigerant pressure gauge.

3. Then check if the power input and running current meet the manual requirements. If not, stop the machine and inspect.

4. Adjust the valves on the water circuit to ensure good hot (cold) water supply for each valve, meeting the heating (or cooling) requirements. Check if the outlet water temperature is stable.

5. The parameters of the wired controller are set by the factory, and users shall not change them on their own.

6. It is necessary to verify against the project delivery checklist for compliance.

# 12 Hand-over to the user

Once the trial run is completed and the unit is operating properly, ensure the following points are clear to the user:

- Clear the error history in the controller before handing over the unit to the user.
- It is strongly recommended to set up the unit's WLAN connection. For more details, refer to the APP.
- Ensure the user has received the printed documentation and advise them to keep it for future reference.
- Explain to the user how to operate the system correctly and what steps to take in case of problems.
- Demonstrate to the user the maintenance procedures for the unit.
- Explain the energy-saving tips to the user as outlined below.

## 12.1 Energy saving tips

### Tips about room temperature

1. Ensure the set room temperature is never excessively high (in heating mode) or excessively low (in cooling mode), and always adjust it according to actual needs. A 1-degree Celsius increase or decrease can save up to 6% of heating or cooling costs.
2. Do not adjust the set room temperature drastically to speed up heating or cooling, as such operation will not accelerate the process.
3. If your system includes slow-response heat emitters (such as underfloor heating), avoid large fluctuations in the set room temperature and do not let the room temperature rise or drop excessively. Otherwise, it will take more time and energy to reheat or cool the room.
4. Use a weekly schedule to meet your regular heating or cooling needs. If necessary, you can easily adjust the schedule:
  - For short periods: You can temporarily override the scheduled room temperature until the next scheduled setting takes effect. For example, this can be done during a party or when you are away for a few hours.
  - For longer periods: You can use the holiday mode.

### Tips about DHW tank temperature

1. Use a weekly schedule to meet your regular domestic hot water needs (only in scheduled mode).
2. Program the DHW tank to heat up to a preset temperature at night, as space heating demand is low during this period.
3. If heating the DHW tank only at night is insufficient, program an additional heating cycle during the day to reach the preset temperature.
4. Ensure the set temperature of the DHW tank is not excessively high. For example, after installation, reduce the tank temperature by 1°C each day and check if there is still an adequate supply of hot water.
5. Program the domestic hot water pump to turn on only during daytime periods when instant hot water is needed, such as in the morning and evening.

# 13 Control and function

## 13.1 Temperature control

### 13.1.1 Heating/Cooling mode

#### ① Heating Mode:

##### Return Water Temperature Control

When return water temperature  $<$  Target water temperature - [HEAT\_LOAD\_dT], unit will start

When return water temperature  $>$  Target water temperature + [HEAT\_UNLOAD\_dT], unit will stop.

##### Outlet Water Temperature Control

When outlet water temperature  $<$  Target water temperature - [HEAT\_LOAD\_dT], unit will start

When outlet water temperature  $>$  Target water temperature + [HEAT\_UNLOAD\_dT], unit will stop.

##### Buffer Tank Temperature Control

When top buffer tank temperature  $<$  target water temperature - [HEAT\_LOAD\_dT], unit will start

When top buffer tank temperature  $>$  target water temperature + [HEAT\_UNLOAD\_dT], unit will stop

#### ② Cooling Mode:

##### Return Water Temperature Control

When Return water temperature  $>$  target water temperature + [COOL\_LOAD\_dT], unit will start

When Return water temperature  $<$  target water temperature - [COOL\_UNLOAD\_dT], unit will stop

##### Outlet Water Temperature Control

When outlet water temperature  $>$  target water temperature + [ COOL\_LOAD\_dT ], unit will start

When outlet water temperature  $<$  target water temperature - [ COOL\_UNLOAD\_dT ], unit will stop

##### Buffer Tank Temperature Control

When top buffer tank temperature  $<$  target water temperature + [ COOL\_LOAD\_dT ], unit will start

When top buffer tank temperature  $>$  target water temperature - [ COOL\_UNLOAD\_dT ], unit will stop

### 13.1.2 DHW mode

When hot water tank temperature  $<$  target temperature - [HW\_dT], unit will start.

When hot water tank temperature  $\geq$  target temperature, unit will stop.

## 13.2 DHW function

### 13.2.1 Whether DHW mode is enabled

Set whether to enable the DHW mode through the display. When it is set to enable, the unit can operate according to the control logic of the DHW mode. When the DHW mode is not enabled, the unit will turn off the hot water function.

### 13.2.2 Whether DHW PRIORITY is enabled

When both the DHW mode and Cooling/Heating mode are turned on, you can set whether to turn on the DHW priority through the display.


#### 1. If the DHW priority is enabled

When the water tank temperature  $\geq$  target temperature,

The Cooling mode/Heating mode will run until the target temperature is reached or the limit time is reached, then switch to DHW mode, after water tank reaching the target temperature or the DHW mode reaching maximum time switch back to Cooling mode/Heating mode.

#### 2. If the DHW priority is not enabled

the heat pump will run the Cooling mode/Heating mode) first. After running until the target temperature is reached, it will switch to DHW mode, and the DHW mode will keep running until the water tank temperature reaching the water tank target temperature or the maximum time is reached, then switch back to the Cooling mode/Heating mode operation




## DHW PRIORITY

### 13.2.3 DHW mode ambient restriction

In the DHW mode setting interface, you can set the DHW maximum ambient temperature and the DHW minimum ambient temperature of the heat pump. When the outside ambient temperature  $>$  the DHW maximum ambient temperature, or  $<$  the DHW minimum ambient temperature, only the water tank electric heater is turned on to produce hot water.

And only When the outside ambient temperature  $>$  the DHW minimum ambient temperature and  $<$  the DHW maximum ambient temperature, the heat pump will produce hot water



## 13.3 Cooling function

### 13.3.1 Whether cooling mode is enabled


Set whether to enable the cooling mode through the display. When it is set to enable, the unit will operate cooling mode.

When the cooling mode is set to be disabled, the unit will turn off cooling function.

### 13.3.2 Cooling mode ambient restriction


In the Cooling mode setting interface, you can set the Cooling maximum ambient temperature and the Cooling minimum ambient temperature of the heat pump. When the outside ambient temperature  $>$  the Cooling maximum ambient temperature, or  $<$  the Cooling minimum ambient temperature, the unit can not turn on to cool the water.

And only when the outside ambient temperature  $>$  the Cooling minimum ambient temperature and  $<$  the Cooling maximum ambient temperature, the heat pump will produce cool water



### 13.3.3 Cooling on/off operation

In cooling mode, when the outlet water temperature reaches (target water temperature - [COOL\_UNLOAD\_dT]), the heat pump is stopped and only the water pump is turned on; When it is detected that the outlet water temperature reaches (target water temperature + [COOL\_LOAD\_dT]), the heat pump is turned on for cooling operation



## 13.4 Heating function


### 13.4.1 Whether heating mode is enabled

Set whether to enable the heating mode through the display. When it is set to enable, the unit will operate heating mode. When the heating mode is set to be disabled, the unit will turn off heating function.

### 13.4.2 Heating mode ambient restriction


In the heating mode setting interface, you can set the heating maximum ambient temperature and the heating minimum ambient temperature of the heat pump. When the outside ambient temperature > the heating maximum ambient temperature, or < the heating minimum ambient temperature, only the electric heater is turned on to produce hot water.

And only when the outside ambient temperature > the heating minimum ambient temperature and < the heating maximum ambient temperature, the heat pump will produce hot water again



### 13.4.3 Heating on/off operation


In heating mode, when the outlet water temperature reaches (target water temperature + [HEAT\_UNLOAD\_dT]), the heat pump is stopped and only the water pump is turned on; When it is detected that the outlet water temperature reaches (target water temperature - [ HEAT\_LOAD\_dT ]), the heat pump is turned on for heating operation



### 13.5 Automatic function

When the user selects the automatic mode, the operation mode is automatically switched according to the Minimum Ambient Temperature for Automatic Cooling and Maximum Ambient Temperature for Automatic Heating.

When the outdoor ambient temperature  $<TA\_auto\_ht\_max-1$ , the heat pump operates in the heating mode, and when the outdoor ambient temperature  $>TA\_auto\_cl\_min+1$ , the heat pump operates in the cooling mode.



Note,

TA\_auto\_cl\_min: Minimum Ambient Temperature for Automatic Cooling

TA\_auto\_ht\_max: Maximum Ambient Temperature for Automatic Heating

## 13.6 External heat source control logic

Prerequisites:

[TWout3\_SENSOR] set to "Enable"

Either of the following conditions must be met:

① Unit is in heating mode and [External Heat Source] is set to "Heating" or "Heating & Hot Water"

② Unit is in DHW mode and [External Heat Source] is set to "DHW" or "Heating & DHW"

Hot water tank electric heater is in off state

System total outlet temperature < 80°C

### Heating Operation Control

When ambient temperature < [External Heat Source Activation Ambient Temperature] - 2, system total outlet water temperature < target temp. - HEAT\_LOAD\_dT, and external heat source shutdown duration exceeds [External Heat Source Activation Delay], the heat pump will activate the external heat source.

And the external heat source remains active until either the system total outlet water temperature reaches target temp. + HEAT\_UNLOAD\_dT or ambient temperature reaches [External Heat Source Activation Ambient Temperature].

If the compressor is in a state where it cannot be started (start-up restricted or in failure),

the external heat source may be activated only when the system total outlet water temperature < target temp. - HEAT\_LOAD\_dT and the external heat source shutdown duration exceeds 5 minutes.

The external heat source remains active until the system total outlet water temperature reaches target temp. + HEAT\_UNLOAD\_dT or 80°C

### DHW Operation Control

When hot water tank temperature < 40°C, system total outlet water temperature < 80°C, and external heat source shutdown duration exceeds [External Heat Source Activation Delay], the heat pump will activate the external heat source.

And the external heat source remains active until either the system total outlet water temperature reaches 80°C or the hot water tank temperature reaches the target.

If the compressor is in a state where it cannot be started (start-up restricted or in failure),

the external heat source may be activated only when the hot water tank temperature < target temperature-[HW\_dT], system total outlet water temperature < 80°C and the external heat source shutdown duration exceeds 5 minutes.

The external heat source remains active until either the system total outlet water temperature reaches 80°C or the hot water tank temperature reaches the target.

# 13.7 Electric heater control logic

## 13.7.1 Auxiliary electric heater control logic

Prerequisites:

Either of the following conditions must be met:

- ① Unit is in heating mode and [Auxiliary Electric Heater] is set to "Heating" or "Heating & Hot Water"
- ② Unit is in DHW mode and [Auxiliary Electric Heater] is set to "DHW" or "Heating & DHW"

Hot water tank electric heater is in off state

If [TWout3\_SENSOR] is set to "Enable", System total outlet temperature < 80°C

### Heating Operation Control

When ambient temperature < [Auxiliary Electric Heater Activation Ambient Temperature] - 1, heat pump control temperature < target temp. - HEAT\_LOAD\_dT, and auxiliary electric heater shutdown duration exceeds [Auxiliary Electric Heater Activation Delay], the heat pump will activate the auxiliary electric heater.

And the auxiliary electric heater remains active until either the heat pump control temperature reaches target temp. + HEAT\_UNLOAD\_dT or ambient temperature reaches [Auxiliary Electric Heater Activation Ambient Temperature].

If the compressor is in a state where it cannot be started (start-up restricted or in failure), the auxiliary electric heater may be activated only when the heat pump control temperature < target temp. - HEAT\_LOAD\_dT. The auxiliary electric heater remains active until the heat pump control temperature reaches target temp. + HEAT\_UNLOAD\_dT.

### DHW Operation Control


When hot water tank temperature < 40°C, and DHW mode operation time exceeds [Auxiliary Electric Heater Activation Ambient Temperature], the heat pump will activate the auxiliary electric heater.

And the auxiliary electric heater remains active until the hot water tank temperature reaches the target.

If the compressor is in a state where it cannot be started (start-up restricted or in failure), the auxiliary electric heater may be activated only when the hot water tank temperature < target temperature-[HW\_dT]. The auxiliary electric heater remains active until the hot water tank temperature reaches the target.

### Electric heater level control

When you connect two auxiliary electric heaters, they will activate in the sequence described below.



### Anti-freeze Operation Control

When auxiliary electric heater is required for anti-freeze protection, the auxiliary electric heater must be activated; otherwise, no activation is needed.

### Defrost Operation Control

When no system total outlet temperature fault occurs, the following control logic exists,  
The auxiliary electric heater requires activation when all the following conditions are met:  
The unit is defrosting  
Total outlet temperature  $T_{\text{Hout2}}(\text{heat pump} + \text{auxiliary electric heater}) < 16^{\circ}\text{C}$

## 13.7.2 DWH tank electric heater control logic

Prerequisites:

- Current operating mode is DHW Mode,
- [DWH tank Electric Heater] is set to "Enabled"
- Ambient temperature  $< [\text{DWH tank Electric Heater Activation Ambient Temperature}]$

### DHW Mode is Priority

When the hot water tank temperature  $< \text{target temperature} - [\text{HW\_dT}]$ , and the DHW mode operation time exceeds the [DHW Tank Electric Heater Activation Delay], the heat pump will activate the DHW tank electric heater until the hot water tank temperature reaches the target temperature.

If the compressor is in a state where it cannot be started (start-up restricted or in failure),  
the DHW tank electric heater may be activated only when the hot water tank temperature  $< \text{target temperature} - [\text{HW\_dT}]$ .  
The DHW tank electric heater remains active until the hot water tank temperature reaches the target or reaches  $85^{\circ}\text{C}$ .

### DHW Mode is not Priority

When the hot water tank temperature  $< \text{target temperature} - [\text{HW\_dT}]$ , the heat pump will activate the DHW tank electric heater until the hot water tank temperature reaches the target temperature.

If the compressor is in a state where it cannot be started (start-up restricted or in failure),  
the DHW tank electric heater may be activated only when the hot water tank temperature  $< \text{target temperature} - [\text{HW\_dT}]$ .  
The DHW tank electric heater remains active until the hot water tank temperature reaches the target or reaches  $85^{\circ}\text{C}$ .

### Defrost Operation Control

Turn on DHW tank electric heater TBH: Hot water tank temperature  $< [\text{DHW target temperature}] - 1^{\circ}\text{C}$   
Turn off DHW tank electric heater TBH: Hot water tank temperature  $\geq [\text{DHW target temperature}]$

### Rapid DHW Mode Control

Activate the DHW tank electric heater when all the following conditions are met:

- ① Enter Rapid DHW Mode Control
- ② Hot water tank temperature  $< [\text{DHW target temperature}] - 1^{\circ}\text{C}$

Deactivate the DHW tank electric heater when any of the following conditions is met:

- ① Hot water tank temperature  $\geq [\text{DHW target temperature}]$
- ② Received DHW mode shutdown command
- ③ Exiting Rapid hot water mode

## Emergency DHW Tank Electric Heater

Activate the DHW tank electric heater when all the following conditions are met:

- ① DHW mode enabled
- ② Received emergency DHW tank heater command
- ③ Hot water tank temperature < [DHW target temperature] - 1°C

Deactivate the DHW tank electric heater when any of the following conditions is met:

- ① Hot water tank temperature ≥ [DHW target temperature]
- ② Received heat pump shutdown command

## 13.8 Water pump control logic

### 13.8.1 Main Circulation Pump Control

The main circulation pump operates based on the settings for [Hot Water Pump Mode] and [Pump Operation Mode].

The main circulation pump operation mode is selected as follows:


When [Hot Water Pump Mode] is "Disabled": Main Circulation Pump Operation Mode = [Pump Operation Mode]

When [Hot Water Pump Mode] is "Enabled":

- If the unit operates in DHW Mode: Main Circulation Pump Operation Mode = [Hot Water Pump Mode]
- If the unit operates in Heating/Cooling Mode: Main Circulation Pump Operation Mode = [Pump Operation Mode]

When the main circulation pump's operating mode is set to "Keep Running," the pump will run continuously after heat pump off.

When the main circulation pump's operating mode is set to "Interval Operation," the pump will follow this cycle during shutdown: run for 5 minutes, then stop for the [Pump Interval Off Duration] time.



When the main circulation pump operates in "Temperature-to-Stop" mode, it will stop running once the target temperature is reached. If the ambient temperature falls below the pump freeze protection temperature, the pump will activate for 5 minutes, then shut off for [Pump Interval Off Duration] before repeating the cycle.

Note: When the main circulation pump is activated during anti-freeze mode, scheduled sterilization, or commissioning operations, it will remain running continuously and will not be subject to the interval operation or temperature-to-stop restrictions.

### 13.8.2 Secondary Circulation Pump Control

Activate the secondary circulation pump if any of the following conditions is met,

- ① Heat pump in antifreeze operation
- ② [External circulation system function] set to "Zone A secondary circulation pump" with Zone A in operation
- ③ [External circulation system function] set to "Zone A&B secondary circulation pump" with either Zone A or Zone B in operation
- ④ Manual startup command for trial operation function

### 13.8.3 Mixing Pump Control

The mixing pump circulates water through the underfloor heating system in Zone B. It will activate during heating, anti-freeze protection, or test operation in Zone B, otherwise remaining off.

### 13.8.4 DHW Pump Control

Prerequisites:

[DHW Pump] set to 'Enabled' and [DHW Function] set to 'Enabled'

① If [DHW Pump Timer] is set to 'Enabled'

When the time reaches the user-set DHW pump start time, the DHW pump turns on, runs continuously for a set period, then off.

② If [DHW Pump disinfection] is set to "Enabled"

When the unit enters scheduled disinfection and the DHW tank temperature reaches the disinfection temperature minus the [HW\_dT] (if the unit has no DHW tank electric heater, the DHW tank temperature only needs to reach 58°C), the DHW pump will turn on. It will remain on until the unit exits scheduled disinfection or the DHW pump has run continuously for a set period, at which point it will off.

### 13.8.5 Solar Water Pump Control

Prerequisites:

[Solar Water Pump] set to "Enable" and [Hot Water Function] set to 'Enable'

① If the [Solar Temperature sensor] is set to "Disabled," the solar pump will activate when a solar signal is detected and the hot water tank temperature is below the target temperature minus the [HW\_dT]. The solar pump will remain on until the solar signal is lost or the hot water tank temperature reaches the target temperature

② If the [Solar Temperature Sensor] is set to 'Enabled', the solar pump will activate when the solar temperature reaches the [Solar Pump Activation Temperature], the hot water tank temperature is below the target temperature minus the [HW\_dT], and the solar temperature exceeds the hot water tank temperature + 1°C. The solar pump will remain active until the solar temperature falls below the activation temperature minus the [HW\_dT], the hot water tank temperature reaches the target temperature, or the solar temperature drops below the hot water tank temperature, at which point the solar pump will deactivate.

## 13.9 Three way valve control logic

### 13.9.1 DWH three-way valve control logic

The DHW three-way valve is used to switch between the heating/cooling water circuit and the hot water circuit. Its operating logic is as follows:

When the unit operates in cooling (or heating) mode, the DHW three-way valve maintains an OFF output.

When the unit operates in DHW mode, the DHW three-way valve maintains an ON output.

When the unit triggers defrosting in heating mode, the DHW three-way valve maintains an OFF output.

When the unit triggers defrosting in DHW mode, the DHW three-way valve maintains an ON output.

### 13.9.2 Cooling three-way valve control logic

The cooling three-way valve is used to switch between heating and cooling water circuits. Its operating logic is as follows:

When the heat pump operates in heating mode, the cooling three-way valve maintains an OFF output.

When the heat pump operates in cooling mode, the cooling three-way valve maintains an ON output

### 13.9.2 Mixing three-way valve control logic

The mixing three-way valve controls whether hot water flows into the Zone B underfloor heating circuit (to prevent excessive water temperature in Zone B):

When hot water is required for heating in Zone B, the mixing three-way valve maintains an OFF output.

When hot water is not required for heating in Zone B, the mixing three-way valve maintains an ON output.

## 13.10 Others

### 13.10.1 Scheduled disinfection function

Prerequisites:

Both [Hot Water Function] and [Scheduled Disinfection Function] must be set to "Enabled"

When the current time reaches the user-set "disinfection time point" or disinfection is triggered by the holiday away mode, the unit will activate high-temperature hot water production for disinfection:

Stage 1: The unit will activate the compressor and auxiliary electric heater to heat water for disinfection until the hot water tank reaches the disinfecting temperature. The compressor will then shut off, entering Stage 2. If the compressor is unavailable, the unit will proceed directly to Stage 2.

Stage 2: The unit will activate auxiliary electric heater to disinfect the hot water tank. For the operation logic, refer to the corresponding section on auxiliary electric heater.

After continuous hot water disinfection for a period, the unit will exit the disinfection mode.

During floor heating preheating/floor heating drying periods, scheduled disinfection is not performed.

### 13.10.2 Holiday away mode

Set the start and end dates for the holiday away mode via the display. During the holiday away period, the unit operates heating/hot water functions at a lower target water temperature to meet water circuit antifreeze and energy-saving requirements. If the unit has a timed disinfection function, it will perform a single disinfection only on the final day of the holiday away period.

When receiving a command to deactivate holiday away mode or the holiday away mode ends, the unit exits holiday away mode and returns to normal operation.

### 13.10.3 Holiday stay mode

Set the start date and end date for Holiday Stay Mode, and configure the scheduled time periods/operating modes via the display. During the period of holiday stay, the unit will start and stop daily according to the preset time periods and operating modes.

When the unit receives a command to disable holiday stay mode from the display or when holiday stay mode ends, it exits holiday away mode and returns to normal operation.

Holiday away mode and holiday stay mode are mutually exclusive and cannot run simultaneously. Holiday away mode has higher priority than holiday stay mode.

### 13.10.4 Crankcase electric heater control

#### Control Logic

If the compressor is not running, and the ambient temperature is  $<$  [Crankcase Heater On Ambient Temperature] , the unit will activate the crankcase electric heater.

If the compressor is running, or the ambient temperature is  $\geq$  [Crankcase Heater Off Ambient Temperature] , the unit will deactivate the crankcase electric heater.

#### Crankcase Electric Heater Preheating Function

After system powers on, if ambient temperature  $<$  [Crankcase Electric Heater Activation Ambient Temperature] and unit power-off duration  $>$  [Minimum Preheat Power-Off Duration], the unit will enter preheating mode.

During preheating, the unit cannot be started but will retain startup commands. It will automatically start upon reaching the preheating duration based on the stored command.

When the system is in preheating mode during startup, you may select either Normal Preheat or Quick Preheat based on the prompts:

Normal Preheat: Preheat time = (Unit power-off duration - [Minimum Preheat Power-off]) / ([Maximum Preheat Power-off] - [Minimum Preheat Power-off])  $\times$  ([Maximum Preheat Time] - [Minimum Preheat Time]) + [Minimum Preheat Time]

Quick Preheat: Preheat time = [Minimum Preheat Duration]

### 13.10.5 Pan electric heater control

When [Pan Electric Heater Mode] is set to "Defrost Pan Electric Heater":

During defrosting:

When ambient temperature  $\leq$  [Pan Heater Activation Ambient Temperature], the pan electric heater will activate.

When ambient temperature  $>$  [Pan Heater Activation Ambient Temperature] + 2, the pan electric heater will deactivate.

After defrosting: The pan electric heater will deactivate after a 360-second delay.

When [Pan Electric Heating Mode] is set to "Low Ambient Temperature Pan Electric Heater":

When the compressor is running:

- If ambient temperature  $\leq$  [Pan Electric Heater Ambient Temperature], the pan electric heater will turn on.

- If ambient temperature  $>$  [Pan Electric Heater Ambient Temperature] + 2, the pan electric heater will turn off.

When the compressor is off: After waiting 360 seconds, the pan electric heater will turn off.

### 13.10.6 Water circuit anti-freeze function

#### **Water circuit anti-freeze entry/exit temperature confirmed**

Water circuit anti-freeze entry temperature must be selected as the lowest value among the following:

Heat pump inlet temperature

Heat pump outlet temperature

Buffer tank temperature

Hot water tank temperature

Water circuit anti-freeze exit temperature must be selected as the lowest value among the following:

Heat pump inlet temperature

Heat pump outlet temperature

#### **Water circuit anti-freeze exit temperature detection**

When ambient temperature  $\geq$  [Anti-Freeze Interval Ambient Temperature], Standby Anti-freeze Interval = [Anti-Freeze Interval 1]

When ambient temperature  $<$  [Anti-Freeze Interval Ambient Temperature], Standby Anti-freeze Interval = [Anti-Freeze Interval 2]

When the ambient temperature is  $\leq$  [Anti-Freeze Entry Ambient Temperature] and the main circulation pump has been stopped for [Standby Anti-Freeze Interval], the main circulation pump will be started. After the main circulation runs for 180 seconds, the system will detect the water circuit anti-freeze exit temperature

#### **Load Operation During Anti-Freeze Protection**

If Ambient temperature  $\leq$  [Anti-Freeze Entry Ambient Temperature], or Water circuit anti-freeze entry temperature  $\leq$  [Pump Anti-Freeze Temperature], the unit will only activate the main circulation pump.

If Water circuit anti-freeze entry temperature  $\leq$  [Electric Heater Anti-Freeze Temperature], the unit will activate the auxiliary electric heater.

If Water circuit anti-freeze entry temperature  $\leq$  [Compressor Anti-Freeze Temperature], the heat pump will run in heating/DHW mode

#### **Load Operation Exit Anti-Freeze Protection**

When the water circuit anti-freeze exit temperature exceeds [Compressor Anti-Freeze Exit Temperature] + 5°C, anti-freeze protection is immediately deactivated.

When the ambient temperature exceeds [Anti-Freeze Entry Ambient Temperature] + [Anti-Freeze Exit Ambient Temperature Difference], anti-freeze protection is immediately deactivated.

When the ambient temperature is  $\leq$  [Anti-Freeze Entry Ambient Temperature] + [Anti-Freeze Exit Ambient Temperature Difference] or ambient temperature sensor failure occurs, anti-freeze protection is deactivated according to the following rules:

When water circuit anti-freeze exit temperature  $>$  [Pump Anti-Freeze Temperature], exit pump anti-freeze. At this point, the main circulation pump stops running.

When water circuit anti-freeze exit temperature  $>$  [Electric Heater Anti-Freeze Exit Temperature], exit electric heater anti-freeze. At

this point, the auxiliary electric heater stops running.

When water circuit anti-freeze exit temperature  $>$  [Compressor anti-freeze exit temperature], exit compressor anti-freeze protection. At this point, both the compressor and auxiliary electric heating stop operating, and the main circulation pump shuts off after a 60-second delay.

### 13.10.7 Anti-freeze function in cooling mode

When the unit operates in cooling mode:

If the heat pump outlet water temperature is  $<$  [Cooling Outlet Temperature Limit], the heat pump will be shut down.

If [Cooling Outlet Temperature Limit]  $<$  heat pump outlet water temperature  $<$  [Cooling Outlet Temperature Limit] + [Outlet Water Load Compensation] + 2°C, operation remains unchanged.

If the heat pump outlet water temperature is  $>$  [Cooling Outlet Temperature Limit] + [Outlet Water Load Compensation] + 2°C, the compressor returns to normal operation.

Within 3 minutes of compressor startup, if the anti-freeze temperature is  $<$  [Cooling Evaporator Lowest Temperature - 3°C] and remains so for 30 seconds, the compressor will stop.

After 3 minutes of compressor startup, if the anti-freeze temperature is  $<$  [Cooling Evaporator Lowest Temperature] and remains so for 30 seconds, the compressor will stop.

When the anti-freeze temperature is  $>$  [Cooling Evaporator Lowest Temperature + 2°C], the heat pump will return to normal operation.


### 13.10.8 Defrost control

Mode	Entry conditions (all of the following conditions must be met)	Exit Conditions (Exit if any one is met)
Normal defrost	1. Defrost entry water temperature = [Defrost exit water temperature] + 6°C Heat pump outlet water temperature, heat pump inlet water temperature $>$ Defrost entry water temperature 2. Coil temperature $\leq$ [Permissible defrost coil temperature] 3. Ambient temperature $\leq$ [Permissible defrost ambient temperature] 4. Cumulative heating/DHW operation time $\geq$ [Defrost interval] (Time determined by table below) 5. Compressor operation time $>$ [Defrost start time] 6. Ambient Temperature - Coil Temperature $\geq$ "Defrost Ambient Coil Differential", where the selection of "Defrost Ambient Coil Differential" is as follows: ①. When Ambient Temperature $\geq$ [Defrost Ambient Temperature 1], Defrost Ambient Coil Differential = [Defrost Ambient Coil Differential 1] ②. When [Defrost Ambient Temperature 1] $>$ Ambient Temperature $\geq$ [Defrost Ambient Temperature 2], Defrost Ambient Coil Differential = [Defrost Ambient Coil Differential 2] ③. When [Defrost Ambient Temperature 2] $>$ Ambient Temperature $\geq$ [Defrost Ambient Temperature 3], Defrost Ambient Coil Differential = [Defrost Ambient Coil Differential 3] ④. When [Defrost Ambient Temperature 3] $>$ Ambient Temperature $\geq$ [Defrost Ambient Temperature 4], Defrost Ambient Coil Differential =	1. Defrost operation time $\geq$ [Defrost Time] 2. Coil temperature $\geq$ [Defrost Exit Coil Temperature] 3. Heat pump outlet water temperature and heat pump inlet water temperature $\leq$ [Defrost Exit Water Temperature] and sustained for 10 seconds 4. Compressor failure or manual power-off

	[Defrost Ambient Coil Differential 4] ⑤. When [Defrost Ambient Temperature 4] > Ambient Temperature, Defrost Ambient Coil Differential = [Defrost Ambient Coil Differential 5]	
Timed defrost	<ol style="list-style-type: none"> <li>1. Compressor operation time &gt; [Defrost start time]</li> <li>2. Coil temperature or suction temperature &lt; [Allowable defrost coil temperature]</li> <li>3. Cumulative heating/DHW operation time ≥ [Scheduled defrost interval]</li> <li>4. Heat pump outlet water temperature, heat pump inlet water temperature &gt; [Defrost exit water temperature]</li> </ol>	

After powering on the unit, the initial defrost wait time for the compressor is [Initial Defrost Interval].

Following the first defrost cycle, the defrost interval selection is as shown in the figure (Note: Values in the figure are for reference only; actual parameter settings shall prevail).



Among them:

T1: [Defrost Ambient Temperature 1]

T2: [Defrost Ambient Temperature 2]

T3: [Defrost Ambient Temperature 3]

T4: [Defrost Ambient Temperature 4]

Time 1: [Defrost Interval 1]

Time 2: [Defrost Interval 2]

Time 3: [Defrost Interval 3]

Time 4: [Defrost Interval 4]

Time 5: [Defrost Interval 5]

Note: A 1°C difference exists when the defrost ambient temperature crosses from high to low zones.

### 13.10.9 Photovoltaic-linked function

Photovoltaic-linked status selection:

0-SG Ready

1-PV Ready

2-SG Ready & PV Ready

[SG\_Ready] Set to "Enable":

Mode	EVU Signal	SG Signal	Command
SG_Ready1	1	0/1	Smart Grid Directive 1
SG_Ready2	0	0	Smart Grid Directive 2
SG_Ready3	0	1	Smart Grid Directive 3

[PV\_Ready]Set to "Enable":

Mode	EVU Signal	SG Signal	Command
PV_Ready1	1	0/1	Low-Power PV
PV_Ready2	0	0	Mid-Power PV
PV_Ready3	0	1	High-Power PV

When both SG\_Ready and PV\_Ready occur simultaneously, SG\_Ready takes priority.

# 14 Technical data

## 14.1 Refrigerant diagram

Refrigerant piping graphic example:


- High temp., high pressure gas

→ Low temp., low pressure gas liquid mixture
- High temp., high pressure liquid


→ Low temp., low pressure gas

Note: The refrigerant flow direction shown in the figure is the main refrigerant flow direction for reference only.

### 14.1.1 Heating/DHW Mode



### 14.1.2 Cooling/Defrosting



### 14.1.3 Key components

No.	Part name
①	Compressor
②	Temperature sensor (Compressor exhaust temperature)
③	High pressure sensor/switch
④	4-way valve
⑤	High pressure switch
⑥	High pressure sensor
⑦	Temperature sensor (Compressor suction temperature)
⑧	Gas-liquid separator
⑨	Plate heat exchanger
⑩	Temperature sensor (Water outlet)
⑪	Temperature sensor (Water inlet)
⑫	Refrigerant storage tank
⑬	Flow switch
⑭	Gas separator
⑮	Main circulation pump
⑯	Filter
⑰	Electronic expansion valve(EEV)
⑱	Filter
⑲	Finned heat exchanger
⑳	Fan

#### **Compressor:**

The refrigerant is compressed to very high pressures in the compressor, while its temperature is also raised. When the refrigerant enters a compressor, it is in a gaseous state at low pressure and low temperature and exits the compressor at high pressure and high temperature in a gaseous state.

#### **4-way valve:**

To Control refrigerant flow direction. The heat pump has upgraded the default position of 4-way valve , and made it to keep closed in heating mode and keep open in cooling mode. When closed, the air side heat exchanger functions as an evaporator and water side heat exchanger functions as a condenser; when open, the air side heat exchanger functions as a condenser and water side heat exchanger function as an evaporator.

#### **High pressure switch:**

To regulate refrigerant system pressure. When refrigerant system pressure rises above the upper limit, the high pressure switch turns off, stopping the compressor.

**High pressure sensor:**

To monitor the pressure of the high-pressure side in the refrigerant system in real time, convert the pressure signal into an electrical signal and transmit it to the controller. It not only assists in triggering overload protection, but also helps adjust the operating parameters of the system (such as compressor frequency, expansion valve opening).

**Low pressure switch:**

To monitor the pressure of the low-pressure side in the system. When the pressure drops below the lower limit (e.g., refrigerant leakage), the low pressure switch will cut off the compressor power supply to prevent the compressor from idling and being damaged (due to insufficient lubrication).

**Low pressure sensor:**

To detect the pressure of the low-pressure side continuously, convert it into an electrical signal and send it to the controller. It provides data support for system adjustment (e.g., regulating refrigerant flow) while cooperating with the low pressure switch to achieve more precise low-pressure protection.

**Fan motor**

To drive the fan to rotate. On the condenser side, it accelerates air flow to help the refrigerant dissipate heat and condense; on the evaporator side, it promotes air circulation to enhance the refrigerant's evaporation and heat absorption. Its rotation speed can be adjusted according to pressure/temperature signals (e.g., increasing speed when the high pressure is too high) to improve heat exchange efficiency.

**Air side heat exchanger(Finned heat exchanger):**

To transfer heat between refrigerant and air. Refrigerant passes through the tube coils, conducts heat to the fins and dissipates heat to air forced through the heat exchanger.

**Filter:**

To protect the inside of the heat pump from the dust and other contaminants that are found in the air, including hairs, pet dander and fibres. As the air passes through the filter, this dust and dirt gets caught to stop it from entering different parts of the system.

**Electronic expansion valve (EEV):**

To Control refrigerant flow and reduces refrigerant pressure.

**Refrigerant storage tank:**

To hold excess fluid refrigerant when the system is in operation.

**Plate heat exchanger:**

To transfer heat between two fluids. This has a major advantage over a conventional heat exchanger in that the fluids are exposed to a much larger surface area because the fluids are spread out over the plates. This facilitates the transfer of heat, and greatly increases the speed of the temperature change.

**Water pump (Circulating pump):**

To Circulate water in the water circuit.

**Water flow switch:**

To detect water flow rate to protect compressor and water pump in the event of insufficient water flow.


**Gas separator**

It can vent air from the water circuit. Crucially, when refrigerant leaks into the water circuit, it can exhaust the refrigerant from the water to the outdoors, preventing it from entering the indoor space and reducing safety risks.


# 14.2 Electronic system

## 14.2.1 Electric wiring diagram

iGXC11




# IGXC11T



### 14.2.2 Control board interface diagram


#### Main Board



Label	Port code	Content	Rated voltage
①	J1	Communicate with inverter board, RS485	A B: 0-5V DC +12V GND: 12V DC
②	J2	Communicate with expansion board, RS485	A B: 0-5V DC
③	J3	Reserved	A B: 0-5V DC 5VA G: 5V DC 12VA G: 12V DC
④	J4	Reserved	A1 B1: 0-5V DC
⑤	J9	Port for R290 refrigerant sensor	P1 P2: 0-5V DC 5VA G: 5V DC 12VA G: 12V DC
⑥	DI1	Port for high-pressure switch	0-5V DC
⑦	DI2	Port for low-pressure switch	0-5V DC
⑧	DI3	Reserved	0-5V DC
⑨	DI4	Reserved	0-5V DC
⑩	DI5	Port for water flow switch	0-5V DC
⑪	A18	Port for inlet water temperature sensor	0-5V DC
⑫	A17	Port for outlet water temperature sensor	0-5V DC
⑬	A16	Reserved	0-5V DC
⑭	A15	Port for coil temperature sensor	0-5V DC
⑮	A14	Port for exhaust temperature sensor	0-5V DC
⑯	A13	Port for suction temperature sensor	0-5V DC
⑰	A12	Port for anti-freeze temperature sensor	0-5V DC
⑱	A11	Port for ambient temperature sensor	0-5V DC
⑲	DCF1	Reserved	0-5V DC
⑳	DCF2	Reserved	0-5V DC
㉑	J8	Reserved	0-5V DC
㉒	J5	Port for high-pressure sensor	0-5V DC
㉓	J7	Reserved	0-5V DC
㉔	J6	Port for low-pressure sensor	0-5V DC
㉕	PHASE	Reserved	380V AC
㉖	DO1	Reserved	220V AC
㉗	DO2	Port for four-way valve	220V AC
㉘	DO3	Port for Pan heater	220V AC

②9	DO4	Reserved	220V AC
③0	DO5	Port for crankcase heater	220V AC
③1	DO6	Reserved	220V AC
③2	DO0	Port for main circulation pump	220V AC
③3	PWR	Power supply port, 220V	220V AC
③4	#1	Port for electronic expansion valve	0-12V DC
③5	JP1	Port for the programming software	0-5V DC
③6	#2	Reserved	0-12V DC
③7	JP2	Reserved	0-5V DC
③8	#3	Reserved	0-12V DC
③9	#4	Port for PWM control of main circulation pump	0-5V DC


# Expansion Board



Label	Port code	Content	Rated voltage
①	P_F	Reserved	220V AC
②	JP1	Reserved	0-5V DC
③	J11	Reserved	0-5V DC
④	J1	Communicate with the mainboard, RS485	A B: 0-5V DC
⑤	J2	RS485 A1_B1/RS485 A2_B2	A1 B1: 0-5V DC A2 B2: 0-5V DC
⑥	JP2	Reserved	0-5V DC
⑦	JP3	Reserved	0-5V DC
⑧	J3	Port for the display	pin1-2: 12V DC pin3-4: 0-5V DC
⑨	J4	Reserved	0-5V DC
⑩	J5	Reserved	0-5V DC
⑪	J6	Reserved	0-5V DC
⑫	AI5	AI5E: Port for floor heating inlet temp. sensor AI5D: Port for whole system outlet temp. sensor AI5C: Port for DHW tank temp. sensor AI5B: Port for buffer tank top temp. sensor AI5A: Port for buffer tank bottom temp. sensor	0-3.25V DC
⑬	AI6	Reserved	0-3.25V DC
⑭	AI4	Reserved	0-3.25V DC
⑮	AI1	Reserved	0-3.25V DC
⑯	AI3	Reserved	0-3.25V DC
⑰	AI2	Reserved	0-3.25V DC
⑱	J7	20FF/20N N: Cooling 3 way valve 30FF/30N N: Mixing 3 way valve 10FF/10N N: DHW 3 way valve AHS1 AHS2: Auxiliary heat source1/2 HT: Pan heater P_R: Return water pump P_S: Solar water pump P_M: Mixing water pump DFR1 DFR2: Defrost signal ERR1 ERR2: Error signal	220V AC
⑲	IBH1/IBH1/TBH	IBH1: Electric heat1	220V AC

		IBH2:Electric heat2 TBH:DHW tank heater	
⑳	J9	L1 H:Thermostat Signal H L1 C:Thermostat Signal C SL1 SL2:Solar water heater P_0 N:Secondary Circulation Pump	220V AC
㉑	TBH_FB	Port for the overload protector of water tank electric heater	220V AC
㉒	IBH1/2_FB	Port for the overload protector of electric heater 1/2	220V AC
㉓	JP5	Reserved	0-5V DC
㉔	DO14	Reserved	220V AC
㉕	POUT	Reserved	220V AC
㉖	DO15	Reserved	220V AC
㉗	PWR	Power supply port, 220V	220V AC

# Inverter Board



Label	Port code	Content	Rated voltage
①	LIN	Port for reactor input power	0-400V
②	LOUT	Port for reactor output power	0-400V
③	J4	Communicate with the mainboard, RS485	0-14V
④	J3	Reserved	0-14V
⑤	JP2	Reserved	0-5V
⑥	JP3	Reserved	0-5V
⑦	FAN1	Port for fan motor	0-400V
⑧	FAN2	Reserved	0-400V
⑨	W	Power output W of inverter PCB to compressor	0-220V
⑩	V	Power output V of inverter PCB to compressor	0-220V
⑪	U	Power output U of inverter PCB to compressor	0-220V
⑫	AC_L	Power input L of inverter PCB	0-220V
⑬	AC_N	Power input N of inverter PCB	0-220V
⑭	PE	Ground	/
⑮	N-	Port for the neutral wire	0-400V

# 15 Maintenance and service

## 15.1 Safety precautions for maintenance

	<b>DANGER: RISK OF ELECTROCUTION</b>
	<b>DANGER: RISK OF BURNING/SCALDING</b>
1. The water in the tank may get extremely hot.	
	<b>WARNING</b>
1. If the internal wiring is damaged, it must be replaced by the manufacturer, its service agent, or other similarly qualified individuals.	
2. Ensure the valve (if fitted) leading to the expansion vessel is opened; otherwise, overpressure may occur.	
3. Please note that some parts of the electrical component box can get hot.	
4. Do not spray or rinse the unit, as this may lead to electric shock or fire hazards.	
5. Do not leave the unit unattended with the service panel removed.	
	<b>CAUTION</b>
1. Water coming out of the valve can be extremely hot.	
2. Users shall not alter the internal structure or wiring of the equipment.	
	<b>NOTICE</b>
1. Maintenance <b>MUST</b> be performed by an authorized installer or service agent.	
2. We recommend performing maintenance at least once a year. However, applicable legislation may require shorter maintenance intervals.	
3. Before performing any maintenance or service work, touch a metal part of the unit to eliminate static electricity and protect the PCB.	
4. Handle the filter with care. To prevent damage to the filter mesh, do not use excessive force when reinserting it.	
5. Handle the water filters with care. Do not use excessive force when reinserting them to avoid damaging the water filter mesh.	
6. When checking the magnetic filter/dirt separator for tightness, hold it firmly to avoid applying stress to the water piping.	
7. Do not isolate the magnetic filter/dirt separator by closing the shut-off valves. Sufficient pressure is required to properly empty the dirt separator.	
8. To prevent dirt from remaining in the dirt separator, <b>ALWAYS</b> remove the magnetic sleeve.	
9. <b>ALWAYS</b> first unscrew the drain cap, connect a drain hose to the bottom of the water filter, then open the drain valve.	
10. When using agents for descaling or chemical disinfection, ensure the water quality still complies with EU Directive 2020/2184.	
11. Although the water circuit is drained, some water may spill when removing the magnetic filter/dirt separator from the filter housing. <b>ALWAYS</b> clean up any spilled water.	

12. To protect the piping connected to the magnetic filter/dirt separator from damage, it is recommended to perform this procedure with the magnetic filter/dirt separator removed from the unit.

13. Opening the magnetic filter/dirt separator is only required in case of severe issues. Preferably, this action should never be performed during the entire service life of the magnetic filter/dirt separator.



### INFORMATION

1. For annual maintenance, it is not necessary to remove the water filter from the unit to clean it. However, if there is an issue with the water filter, you may need to remove it for a thorough cleaning.

2. It is recommended that this maintenance be performed more than once a year.

3. Install the strainer correctly in the housing of the magnetic filter/dirt separator using the protrusions.

## 15.2 Tools used for maintenance


### 1. Flaring tool (clutch type)

The flaring tool features a larger clamping bar hole to position the pipe end at 0-0.5 mm, and incorporates a stronger internal spring to ensure reliable flaring torque.



### 2. Torque wrench

To improve compression strength, the wrench diameter varies based on the size of the flare nut. It is typically used for installing and removing globe valve caps.



### 3. Phillips screwdriver

It is typically used for installing and removing screws.



#### 4. Hexagonal wrench

It is typically used for opening and closing globe valve gates.



Specification: 3/8" hexagonal

#### 5. Pipe cutter

It is typically used for cutting copper pipes.



#### 6. Multimeter

It is typically used to test electrical circuits when circuit.



## 7. Manifold pressure gauge

Each port of the manifold features a distinct shape to prevent the use of incorrect refrigerants.

\* However, the port shapes for R410A and R32 are identical, so caution must be exercised to avoid using the wrong refrigerant.

	R32 (Compatible with R410A)	R290	R454B
High-pressure gauge (red)	-0.1 ~ 5.3 MPa -76 cmHg ~ 53 kgf / cm <sup>2</sup>	-76 cmHg ~ 35 kgf / cm <sup>2</sup>	-0.1 ~ 5.3 MPa -76 cmHg ~ 53 kgf / cm <sup>2</sup>
Low-pressure gauge (blue)	-0.1 ~ 3.8 MPa -76 cmHg ~ 38 kgf / cm <sup>2</sup>	-76 cmHg ~ 17 kgf / cm <sup>2</sup>	-0.1 ~ 3.8 MPa -76 cmHg ~ 38 kgf / cm <sup>2</sup>

Differences in manifold port sizes

	R32 (Compatible with R410A)	R290	R454B
Port size	1/2 UNF20	7/16 UNF20	1/2 UNF20

## 8. Charging hose

The charging hose has enhanced pressure resistance.

Meanwhile, its material has been upgraded to be HFC-resistant, and the size of each manifold adapter has been adjusted to align with the port size of the manifold gauge itself.

Additionally, some hoses are equipped with a check valve near the sampler to prevent backflow of gas pressure. (The use of hoses with valves is recommended.)




Differences in charging hoses

		R32 (Compatible with R410A)	R290	R454B
Pressure resistance	Normal working pressure	5.1 MPa (52 kgf / cm <sup>2</sup> )	3.4 MPa (35 kgf / cm <sup>2</sup> )	5.1 MPa (52 kgf / cm <sup>2</sup> )
	Burst pressure	27.4 MPa (280 kgf / cm <sup>2</sup> )	17.2 MPa (175 kgf / cm <sup>2</sup> )	27.4 MPa (280 kgf / cm <sup>2</sup> )
Material		HNBR rubber with nylon inner coating	NBR rubber	HNBR rubber with nylon inner coating

### 9. Vacuum pump and vacuum pump adapter

When using a vacuum pump, a solenoid valve must be installed to prevent vacuum pump oil from flowing back into the charging hose. Additionally, a vacuum pump with an anti-oil backflow function (or fitted with a vacuum pump adapter) should be used.

If vacuum pump oil (mineral oil-based) mixes with R410A (or R32), it could damage the equipment.



### 10. Electrical leak detector for HFC refrigerant

For more accurate detection, we recommend using a detector specifically configured and calibrated for R290 detection.



### 11. Digital scale for refrigerant charging

R32 and R410A are characterized by high pressure and rapid evaporation rates. Therefore, if refrigerant is recovered using the cylinder charging method (instead of liquefying it into the cylinder), the refrigerant will evaporate in the weighing glass, making it difficult to read the weight. (R22 charging cylinders differ in pressure resistance, scale, and connection port size, so they are not applicable.)

Furthermore, the digital scale for refrigerant charging is reinforced, with four pillars at the corners supporting the weight of the refrigerant cylinder. The charging hose is equipped with two separate connection ports: one for R22 (7/16 UNF20) and another for R32/R410A (1/2 UNF20), enabling compatibility with existing refrigerants.



## 12. Refrigerant cylinder

R290 is a single-component refrigerant, so both its liquid and gas forms can be charged, and additional charging is feasible. The color of the cylinder varies by manufacturer. When in use, please carefully check the label on the refrigerant cylinder, which should include the refrigerant's chemical name (propane), R290 identification, and safety warnings for use and storage.

## 13. Connection port for refrigerant cylinder and filler

A charging port matching the size of the charging hose's connection port (1/2 UNF20) is required. Additionally, the packaging must be made of HFC-resistant materials.



For other installation work, common tools can be used, such as a metal saw, electric drill, long-nose pliers, hole core drill, flax tape, level, thermometer, clamp, electric knife, pliers, reamer or scraper, spring bender, adjustable wrench, fixed wrench, feeler gauge, hexagonal wrench (4 mm), tester, and megohmmeter.

# 15.3 Yearly maintenance

## 15.3.1 Overview: Yearly maintenance outdoor unit

Check the following at least once a year:

### Heat exchanger

The heat exchanger of the outdoor unit may become clogged with dust, dirt, leaves, and other debris. It is recommended to clean the heat exchanger annually. A clogged heat exchanger can cause excessively low or high pressure, leading to reduced performance.

### Water filter

Close the valve, then clean and rinse the water filter.

## 15.3.2 Maintenance checklist

### By user

Items	Recommended frequency
Clean the surrounding of the outdoor unit.	Once a month.

### By installer

Items	Recommended frequency
General	
Check if all the parts are in the proper position.	Once a year.
Water loop	
Check if the water pressure is sufficient.	Once a year.
Clean the strainer in water system.	Once a year.
Check if the flow switch works in good condition.	Once a year.
Check if the water pressure relief valve (in water system) works in good condition.	Once a year.
Check if the water pressure relief valve (in DHW water loop) works in good condition.	Once a year.
Check if the insulation of backup heater is in good condition.	Once a year.

Check if there is water leakage in the water loop. Take care if anti-refrigerant is applied.	Once a year.
Check if the booster heater of DHW water tank is clean and in good condition.	Once a year.
Wiring and electrical parts	
Check if the temperature sensor works in good condition.	Once a year.
Check if the wiring and cables of the installation is in good condition.	Once a year.
Check if the contactors and circuit breakers works in good condition.	Once a year.
Refrigerant loop	
Check if there is refrigerant leakage in the refrigerant loop.	Once a year.



## 15.4 Disassembly of structural components

### 15.4.1 Safety Precautions for maintenance

 <b>CAUTION</b>
1. The diagonal-patterned front frame is rather sharp. During disassembly, please exercise caution to avoid direct contact with its sharp edges.
2. Care should be taken with the position of the sheet metal parts to prevent them from hitting people.
3. The unit is in a stationary state with both power and water supply cut off.


### 15.4.2 Removing the top cover

- ① Loosen the three screws at the rear side of the top cover.
- ② Lift the top cover upwards from the unit.
- ③ Remove the top cover upwards.



### 15.4.3 Removing the service panel


- ① Loosen these five screws.
- ② Push the side panel downwards, then pull it out horizontally.



### 15.4.4 Removing the front frame


Note: Before removing the front frame, please ensure that your top cover and service panel have been removed.

- ① Loosen these four screws between the front frame and the top beam.
- ② Loosen these four screws between the front frame and bottom panel.
- ③ After removing all the above screws, push the front frame forward (be careful not to touch the sharp areas of the front frame with your hands)




### 15.4.5 Removing the fan grille

- ① Loosen these six screws.
- ② Pull the air guide ring outwards.



### 15.4.6 Removing the support plate



- ① Loosen these thirteen screws.
- ② Pull it out horizontally



### 15.4.7 Removing the water connection panel


Note: Before removing the water connection panel, ensure that the service panel, rear protective mesh (if you have it), and top cover have been removed.

- ① Loosen these eight screws.
- ② Remove the water connection panel towards the rear direction.



## 15.5 Replacement of electrical components


### 15.5.1 Replacing the main board



If the unit's load output is abnormal and it is determined that the main board needs to be replaced, follow these steps:

1. Ensure the unit is in a stopped state and disconnected from the power supply.
2. The service panel and top cover need to be removed.
3. Locate the position of the main board, which can be determined by referring to the unit's exploded view in the appendix.
4. Remove the wire harnesses connected to the main board.
5. Use a Phillips screwdriver to loosen the screws fixing the main board.
6. Pull upwards forcefully to remove the damaged main board.
7. Install the replacement main board in the position of the electrical box, referring to the circuit diagram to reconnect the wire harnesses to their original positions.
8. Use the screwdriver to secure the main board.
9. Power on and verify the unit's main control program.
10. After confirming that the unit's main control parameters are correct, attempt to start the unit.
11. Debug various parameters of the unit, and only deliver to the customer after ensuring stable operation.


## 15.5.2 Replacing the expansion board



If the unit's load output is abnormal and it is determined that the expansion board needs to be replaced, follow these steps:

1. Ensure the unit is in a stopped state and disconnected from the power supply.
2. The service panel and top cover need to be removed.
3. Locate the position of the expansion board, which can be determined by referring to the unit's exploded view in the appendix.
4. Remove the wire harnesses connected to the expansion board.
5. Use a Phillips screwdriver to loosen the screws fixing the expansion board.
6. Pull upwards forcefully to remove the damaged expansion board.
7. Install the replacement expansion board in the position of the electrical box, referring to the circuit diagram to reconnect the wire harnesses to their original positions.
8. Use the screwdriver to secure the expansion board.
9. Power on and verify the unit's main control program.
10. After confirming that the unit's main control parameters are correct, attempt to start the unit.
11. Debug various parameters of the unit, and only deliver to the customer after ensuring stable operation.

### 15.5.3 Replacing the drive board



If the unit's load output is abnormal and it is determined that the expansion board needs to be replaced, follow these steps:

1. Ensure the unit is stopped and disconnected from the power supply.
2. The service panel and top cover need to be removed.
3. Locate the drive board, which can be identified by referring to the unit's exploded view in the appendix.
4. Disconnect the wire harnesses connected to the drive board.
5. Use a Phillips screwdriver to loosen the screws securing the drive board.
6. Pull upward firmly to remove the damaged drive board.
7. Install the replacement drive board in the electrical box position, and refer to the circuit diagram to reconnect the wire harnesses to their original locations.
8. Use the screwdriver to fasten the drive board.
9. Check whether the compressor parameters are normal and if the unit can start up properly.
10. Debug all parameters of the unit, and only hand it over to the customer after confirming stable operation

## 15.6 Service information

 <b>WARNING</b>
1. These instructions are intended solely for qualified contractors and authorized installers.
2. Work on refrigerant circuits containing flammable refrigerants in safety group A2L may only be performed by authorized heating contractors. These contractors must have received training in accordance with EN 378 Part 4 or IEC 60335-2-40, Section HH, and hold a certificate of competence issued by an industry-accredited body.
3. Brazing/soldering work on the refrigerant circuit may only be carried out by contractors certified in accordance with ISO 13585 and AD 2000, Datasheet HP 100R, and only by those qualified and certified for the specific processes to be performed. The work must fall within the scope of the specified applications and be conducted in accordance with prescribed procedures. Brazing/soldering work on accumulator connections requires personnel and process certification by a notified body in compliance with the Pressure Equipment Directive (2014/68/EU).
4. Work on electrical equipment may only be performed by a qualified electrician.
5. Prior to initial commissioning, all safety-related points must be inspected by the relevant certified heating contractors. The system must be commissioned by the system installer or a qualified person authorized by the installer.

### 15.6.1 Label for refrigerant presence

Equipment should be fitted with a label indicating that it has been decommissioned and emptied of refrigerant. The label must include the date and a signature. Additionally, ensure that appropriate labels are affixed to the equipment to state that it contains flammable refrigerant.

### 15.6.2 Leak detection methods

The following leak detection methods are considered acceptable for systems containing flammable refrigerants. An electronic leak detector should be used to detect flammable refrigerants; however, its sensitivity may be insufficient, or the detector may require recalibration. (Detection equipment should be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the specific refrigerant.

Leak detection equipment should be set to a percentage of the refrigerant's Lower Flammable Limit (LFL) and calibrated to be suitable for the refrigerant in use. The appropriate gas percentage (maximum 25%) must be confirmed.

Leak detection fluids are suitable for use with most refrigerants, but chlorine-containing detergents should not be used, as chlorine may react with the refrigerant and corrode copper pipes.

If a leak is suspected, all naked flames must be removed or extinguished. If a refrigerant leak is found and brazing is required, all refrigerant should be recovered from the system or isolated (using shut-off valves) in a part of the system remote from the leak. Oxygen-free nitrogen (OFN) should then be purged through the system both before and during the brazing process.

### 15.6.3 Check of refrigeration equipment

When electrical components need to be replaced, they must be suitable for their intended purpose and meet the correct specifications. Always adhere to the manufacturer's maintenance and service guidelines. If in doubt, consult the manufacturer's technical department for assistance.

For installations using flammable refrigerants, the following checks should be performed:

- The quantity of refrigerant to be charged depends on the size of the room where the refrigerant-containing parts are installed.

- Ventilation equipment and outlets should function properly and not be obstructed.
- If an indirect refrigeration circuit is used, the secondary circuits should be checked for any presence of refrigerant; markings on the equipment must be visible and legible.
- Illegible markings and signs should be corrected.
- Refrigeration pipes or components should be installed in positions where they are unlikely to be exposed to substances that may corrode refrigerant-containing components, unless the components are made of materials inherently resistant to corrosion or are appropriately protected against corrosion.

#### 15.6.4 Check of electrical devices

Repair and maintenance of electrical components should include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, the electrical supply to the circuit must not be connected until the fault is satisfactorily resolved.

If the fault cannot be corrected immediately but continued operation is necessary, an appropriate temporary solution should be implemented. This must be reported to the equipment owner to ensure all parties are informed.

Initial safety checks should include the following:

- Capacitors should be safely discharged to avoid the risk of sparking.
- During system charging, recovery, or purging, no live electrical components or wiring may be exposed.
- Earth bonding must be continuous.

#### 15.6.5 Repair of sealed components

When repairing sealed components, all electrical supplies must be disconnected from the equipment being worked on before any sealed covers are removed. If it is absolutely necessary to keep an electrical supply connected to the equipment during servicing, a continuously operating leak detection device should be placed at the most critical point to alert of potential hazards.

Special attention should be paid to the following to ensure that working on electrical components does not alter the casing in a way that compromises its protective function. This includes checking for damaged cables, an excessive number of connections, terminals not constructed according to original specifications, damaged seals, and incorrectly fitted glands:

- Ensure all apparatuses are securely mounted.
- Ensure seals or sealing materials have not degraded to the point where they can no longer prevent the entry of flammable atmospheres. Replacement parts must comply with the manufacturer's specifications.
- The use of silicon sealant may reduce the effectiveness of some leak detection equipment. Intrinsically safe components do not need to be isolated before work is performed on them.

#### 15.6.6 Repair of intrinsically safe components

Do not apply any permanent inductive or capacitive loads to the circuit without first ensuring that such loads will not exceed the permissible voltage or current for the equipment in use.

Intrinsically safe components are the only type that can be worked on when they are live in a flammable atmosphere.

Test apparatus must be provided with the correct rating.

Replace components solely with parts specified by the manufacturer. Using other parts may cause leaked refrigerant in the atmosphere to ignite.

#### 15.6.7 Transportation and marking

Transport the equipment containing flammable refrigerants in accordance with the transport regulations. Mark the equipment with signs in compliance with local regulations.

## 15.7 Repair of refrigerant cycle/brazing points

 <b>WARNING</b>
1. This operation must be carried out by professional welders.
2. This should be operated by professionals.
3. Welding should be conducted in a safe area.

### 15.7.1 Preparation for refrigerant cycle/brazing repair

Brazing is a technique necessary for repairing refrigerant cycle systems, requiring advanced skills and experience. This brazing process may only be performed by workers who have completed the "gas welding skills training" as specified in the *Occupational Safety and Health Act* and passed the refrigerant operation training program.

Disassembling and reconnecting (assembling) the refrigerant system requires a workspace with adequate ventilation and fire prevention measures (including fire buckets and fire extinguishers). In addition, workers must wear goggles, gloves, safety shoes, and long-sleeved shirts, remain vigilant about work safety, and take care to prevent secondary defects (to ensure product quality).

For brazing structural components of indoor/outdoor units (such as heat exchangers, compressors, expansion valves, and four-way valve assemblies), all refrigerant must first be recovered. It is essential to confirm that no refrigerant residue remains in the system, and all needle valves and globe valves must be fully opened. When brazing outdoors, check to ensure there is no refrigerant in the air (be cautious of evaporated refrigerant).

Furthermore, protect compressor terminals with metal plates during heating, and cool the expansion valve and four-way valve with wet towels (to dissipate heat) to prevent component damage. During brazing, the brazing material should be applied based on the principle of capillary action without melting the base material. If overheating causes holes or oxidation, do not re-braze or patch the component; instead, replace it entirely.

### 15.7.2 Pressure adjustment for vacuum pump

#### 1. Cylinder with adjustment handle


① Check and confirm that the adjustment handle of Pressure Regulator No. 1 is loosened (by turning it counterclockwise). If the cylinder valve is opened while the pressure adjustment handle of the first pressure gauge is closed, the second pressure gauge may be damaged.

② Open the cylinder valve and check the remaining quantity using the first pressure gauge.

③ Check the pressure on the second pressure gauge, then turn the adjustment handle clockwise to adjust the pressure.

- Second gauge pressure of Oxygen . . . . . 0.5 MPa (5.0 kgf/cm<sup>2</sup>)


- Second gauge pressure of Propane . . . . . 0.05 MPa (0.5 kgf/cm<sup>2</sup>)



2. For cylinders without adjustment valves, the second gauge pressure is regulated by the regulator.

Check the valves on both sides of the torch, open the cylinder valve, and check the remaining refrigerant in the cylinder.

Note: Do not connect oil-containing components to the regulator's connection ports. In particular, use oil-free oxygen cylinder regulators. Do not disassemble or repair regulators or pressure gauges.



### 15.7.3 Checks to gas supply

Ensure there is no fire in the vicinity of the torch, then verify the gas supply.


1. Slightly open the torch's "propane valve", confirm that gas flows out from the torch nozzle, then close the "propane valve".
2. Gently open the torch's "oxygen valve", confirm that gas flows out from the torch nozzle, then close the "oxygen valve".

Check for gas leaks at the hose connections.

### 15.7.4 Flame adjustment

1. Gently open the torch's "propane valve" and ignite using a lighter. At this stage, the flame—composed solely of propane—will appear red.
2. Gradually open the torch's "oxygen valve" to mix in oxygen. Use the valves to adjust the propane and oxygen levels to achieve a flame suitable for brazing work.

If the white core of the flame splits into two, the torch nozzle may be clogged. In such cases, remove the torch tip and inspect it




### 15.7.5 Flame types

Types of flame variations based on the ratio of propane to oxygen:


[Neutral flame]

Use this flame for brazing. It forms when oxygen and propane are mixed in the proper ratio, with minimal effect on the brazing metal.




[Carburizing flame]

When propane is in excess, a white flame appears between the white core flame and the outer flame. This occurs due to insufficient oxygen, resulting in a high proportion of unburned propane. Carbon black generated during brazing may contaminate the surface of the brazing metal.



[Oxidizing flame]

Compared to the neutral flame, this flame contains more oxygen. Though smaller in size, it has the highest heat. However, the excess oxygen in the flame causes oxidation at the brazing point. Additionally, its high temperature may lead to holes or melting of the pipe.



### 15.7.6 Shutting off the flame

[In case of short interruption]

1. Close the torch's "propane valve."
2. Close the torch's "oxygen valve."

[In case of completion]

1. As noted above, shut off the flame using the procedure for "short interruption."
2. Fully close the valves of the oxygen cylinder and propane cylinder.
3. Open the torch's "oxygen valve" and "propane valve" to release any remaining gas in the hoses.

Confirm that the first and second gauge pressures on the pressure regulators of the oxygen and propane cylinders read "zero."

### 15.7.7 Flux requirements

Use flux to protect the base material, as it serves the following purposes:

1. Remove impurities and oxide films from the metal substrate to enhance the fluidity of the brazing alloy.
2. Prevent oxidation of the metal surface during the brazing process.
3. Reduce the surface tension of the brazing material.

### 15.7.8 Nitrogen requirements

To prevent oxidation inside the pipes, conduct brazing operations under a nitrogen flow.

The flow rate should be 0.05 m<sup>3</sup>/h, or the pressure of the relief valve should be kept below 0.02 MPa (0.2 kgf/cm<sup>2</sup>).


### 15.7.9 Checking brazing (insertion) points

1. Brazing points must be free of impurities.


If dirt or oil adheres to the brazing point, the brazing filler metal will be unable to reach the joint, potentially resulting in poor weld quality.

2. Brazing points require sufficient gap space to leverage capillary action during brazing.


If the gap is too large, this capillary action may fail to occur, leading to poor welds as the brazing filler metal will not flow to form a proper joint.



3. Appropriate insertion size. The general guideline for pipe insertion size is three times the diameter of the base material, though the specific insertion size must be determined with consideration to potential clogging of the brazing material. In general, for thin pipes, the insertion size should be increased to ensure welding stability and strength; for thick pipes, the insertion size also needs to be enlarged to accommodate the thicker base metal and create sufficient space for welding or brazing.




4. Brazing material flows from top to bottom. The brazing alloy easily flows toward the joint via capillary action. Furthermore, bending the brazing section of the capillary (dryer side) at an angle of approximately 120° starting 15 mm from the top of the pipe can prevent damage to the interior of the dryer and clogging of the brazing material caused by excessive insertion of the capillary.



### 15.7.10 Brazing and heating

1. Direct the flame at the pipe with a larger heat capacity, so that the brazing material melts due to the pipe's heat. Heat the pipe to the brazing material's melting temperature. However, if overheating occurs, judge the temperature by the pipe's color to avoid melting the pipe.



Preheating involves heating the base material to its melting temperature; this requires training to distinguish the color of the heated base material to prevent it from melting.

Color and temperature of copper pipe(Reference)

Turns red . . . . . 480°C

Dark red . . . . . 650°C

Bright red . . . . . 760°C

Bright white red . . . . . 870°C

Melting temperature of copper . . . . . Approx. 1083°C

Highest temperature obtained in propane and oxygen . . . . . Approx. 1083°C

It is important to heat the bonding parts evenly in a short time until the brazing temperature is reached in the following manner.

2. Direct the flame at the side with better heat transfer. If the pipe thickness is consistent, heat 30% of the iron and 70% of the copper to ensure the interior of the copper pipe reaches brazing temperature. Iron pipes have low heat transfer efficiency, meaning only the area directly exposed to the flame will reach high temperatures—this leads to pipe oxidation and adversely affects the flow of the brazing filler.

3. Apply the flame to the side with a larger heat capacity. When brazing thin pipes (such as capillaries and dryers), ensure the flame is directed at the dryer side (the thicker pipe side) to prevent heat damage to the capillary and dryer.

4. When brazing the compressor's connection pipes (suction and discharge), first remove the soundproof panel and fan. Position the compressor bracket vertically (to prevent refrigeration oil leakage from the compressor) and apply the flame from the compressor body side.

### 15.7.11 Brazing terminology

Pin hole → small holes produced on the surface of the brazing metal.

Wet temperature → the liquidus temperature at which the brazing material begins to flow out through heating.

Gas hole → cavities formed by gas in the brazing material at the brazing part (gas reservoir).

Pit → small dents produced on the outer surface of the welded part due to gas holes.

Void ratio → the brazing filler metal cannot fully contact the brazing parts. Cannot be identified from the outside.

### 15.7.12 Selection of brazing materials

Use bag-type brazing materials (silver brazing alloy) to improve welding performance.

Category	JIS Default Number	Composition (%)						Temperature (°C)			Tensile Strength (Reference)		Characteristics and Applications
		Ag	Cu	Zu	Cd	Ni	P	Solidification Temperature	Evaporation Temperature	Brazing Application Temperature	Kgf•cm <sup>2</sup>	Base Material	
BAg	BAg*1A	49.0	14.5	14.5	17.0	-	-	Approx. 625	Approx. 635	635	45.5	S20C	Good fluidity at low temperatures, best for small joint gaps in general.
		~ 51.0	~ 16.5	~ 18.5	~ 19.0					~ 760			
	BAg*1	44.0	14.0	14.0	23.0	-	-	Approx. 605	Approx. 620	620	45.5	S20C	Similar performance to BAg*1A, suitable for all base materials except light metals.
		~ 56.0	~ 16.0	~ 18.0	~ 25.0					~ 760			
	BAg*2	34.0	25.0	19.0	17.0	-	-	Approx. 605	Approx. 700	620	45.5	S20C	It is a universal form of brazing filler metal, suitable for slightly larger gap connections.
		~ 36.0	~ 27.0	~ 23.0	~ 19.0					~ 760			
	BAg*3	48.0	14.5	19.0	15.0	15.0	-	Approx. 630	Approx. 690	620	620	SS	Good corrosion resistance in stainless steel base brazing, suitable for brazing tungsten carbide, aluminum bronze, and copper.
		~ 51.0	~ 16.5	~ 23.0	~ 17.0	~ 17.0				~ 760	~ 760	~ SUS	
BCuP	BCuP-2	-	Residual	-	-	-	6.8	Approx. 710	Approx. 785	690	21	Cu	Good fluidity, suitable for copper pipe brazing.
							~ 7.5			~ 815	~ 24.5		
	BCuP-3	4.8	Residual	-	-	-	5.8	Approx. 645	Approx. 815	720	21	Cu	Suitable for brazing when joint spacing is not constant.
		~ 5.2					~ 6.7			~ 815	~ 24.5		
	BCuP-5	14.5	Residual	-	-	-	5.8	5.8	Approx. 800	705	21	Cu	For brazing copper and copper without using flux, but not possible to braze base materials.
		~ 15.5					~ 6.7	~ 6.7		~ 815	~ 24.5		

Note:

BCuP (brazing copper phosphorus) easily reacts with sulfur, forming brittle compounds that are water-soluble, which can lead to gas leaks. In hot spring areas, use other brazing materials or apply protective paint to the surface.

# 16 Troubleshooting

## 16.1 Overview: troubleshooting

This chapter outlines the steps to take when issues occur.

It includes guidance on:

- Solving problems based on symptoms
- Solving problems based on error codes

### Before troubleshooting

conduct a thorough visual inspection of the unit to check for obvious defects, such as loose connections or faulty wiring.

## 16.2 Precautions when troubleshooting

	<b>DANGER: RISK OF ELECTROCUTION</b>
	<b>DANGER: RISK OF BURNING/SCALDING</b>
	<b>WARNING</b>
<p>1. When inspecting the unit's switch box, ALWAYS ensure the unit is disconnected from the mains. Turn off the corresponding circuit breaker.</p>	
<p>2. If a safety device is activated, stop the unit and identify the cause of activation before resetting it. NEVER bypass safety devices or adjust their settings to values other than the factory defaults. If you cannot determine the cause of the issue, contact your dealer.</p>	
<p>3. To prevent hazards from accidental resetting of the thermal cut-out: The appliance's power supply MUST NOT be routed through an external switching device (such as a timer) or connected to a circuit that is regularly turned on and off by the utility provider.</p>	

## 16.3 Solving problems based on symptoms

### 16.3.1 Symptom: The unit is NOT heating or cooling as expected

Possible causes	Corrective action
The temperature setting is NOT correct	Check the temperature setting on the remote controller.
The water flow is too low	Check and make sure that: <ul style="list-style-type: none"> <li>- All shut-off valves of the water circuit are completely open.</li> <li>- The water filters are clean. Clean if necessary.</li> <li>- There is no air in the system. Purge air if necessary.</li> <li>- The water pressure is &gt;1 bar.</li> <li>- The expansion vessel is NOT broken.</li> <li>- The valve (if equipped) of the water circuit</li> </ul>

	towards the expansion vessel is open. - The resistance in the water circuit is NOT too high for the pump. If the problem persists after you have conducted all of the above checks, contact your dealer. In some cases, it is normal that the unit decides to use a low water flow.
The water volume in the installation is too low	Make sure that the water volume in the installation is above the minimum required value
Fins are dirty	Clean the evaporator coil
Air inlet blocked	Remove any objects obstructing air circulation of the unit.
Insufficient refrigerant	Check the unit for leaks, repair if any. Evacuate all refrigerant and recharge the unit with correct amount.

### 16.3.2 Symptom: Hot water does NOT reach the desired temperature

Possible causes	Corrective action
One of the tank temperature sensors is broken.	See the service manual of the unit for the corresponding corrective action.

### 16.3.3 Symptom: The compressor does NOT start

Possible causes	Corrective action
No power supply	Check the power supply
Fuse blown or circuit breaker tripped	Check if the unit is open-circuited or grounded. Then replace the fuse, reset the circuit breaker, and check if the circuit is stable or well connected.
Some protection activated	Check which protection is working, clear the protection, then restart the unit.
Loose wiring	Check wire connections and tighten screws on terminals
Compressor failure	Replace the compressor
The unit may operate out of its operating range	Too low ambient temperature

### 16.3.4 Symptom: The system is making gurgling noises after commissioning

Possible causes	Corrective action
There is air in the system.	Purge air from the system.
Incorrect hydraulic balance.	To be performed by the installer: - Perform hydraulic balancing to assure that

	<p>the flow is correctly distributed between the emitters.</p> <p>- If hydraulic balancing is not sufficient, change the pump limitation settings</p> <p>The water pressure must be larger than or equal to 1.5 bar.</p> <p>Verify that the expansion vessel is not broken.</p> <p>Verify that the pre-pressure of the expansion vessel is set correctly.</p>
Various malfunctions.	Check if or is displayed on the home screen of the user interface.
Valves in the water system are not fully open	Check all valves to ensure they are fully open
Water filter dirty or clogged	Clean the water filter

### 16.3.5 Symptom: The pump is making noise (cavitation)

Possible causes	Corrective action
There is air in the system.	Purge air from the system.
The water pressure at the pump inlet is too low	<p>Check and make sure that:</p> <ul style="list-style-type: none"> <li>- The water pressure is &gt;1 bar.</li> <li>- The water pressure sensor is not broken.</li> <li>- The expansion vessel is NOT broken.</li> <li>- The valve (if equipped) of the water circuit towards the expansion vessel is open.</li> <li>- The pre-pressure setting of the expansion vessel is correct</li> </ul>

### 16.3.6 Symptom: The pressure relief valve opens

Possible causes	Corrective action
The expansion vessel is broken	Replace the expansion vessel.
The valve (if equipped) of the water circuit towards the expansion vessel is closed.	Open the valve.
The water volume in the installation is too high	Make sure that the water volume in the installation is below the maximum allowed value
The water circuit head is too high	<p>The water circuit head is the difference in height between the indoor unit and the highest point of the water circuit. If the indoor unit is located at the highest point of the installation, the installation height is considered 0 m. The maximum water circuit head is 10 m.</p> <p>Check the installation requirements.</p>

Water pressure in the installation higher than 0.3MPa.	Make sure that the water pressure in the installation is within 0.10 to 0.20 MPa.
--	---

### 16.3.7 Symptom: The water pressure relief valve leaks

Possible causes	Corrective action
Dirt is blocking the water pressure relief valve outlet	<p>Check whether the pressure relief valve works correctly by turning the red knob on the valve counterclockwise:</p> <ul style="list-style-type: none"> <li>- If you do NOT hear a clacking sound, contact your dealer.</li> <li>- If the water keeps running out of the unit, close both the water inlet and outlet shut-off valves first and then contact your dealer.</li> </ul>

### 16.3.8 Symptom: Insufficient space heating capacity at low outdoor temperature.

Possible causes	Corrective action
The backup heater operation is not activated	<p>Check the following:</p> <ul style="list-style-type: none"> <li>- The backup heater operation mode is enabled.</li> <li>- The backup heater overcurrent circuit breaker is on. If not, turn it back on.</li> </ul>
The backup heater equilibrium temperature has not been configured correctly	Increase the equilibrium temperature to activate the backup heater operation at a higher outdoor temperature.
There is air in the system.	Purge air manually or automatically.

### 16.3.9 Symptom: The pressure at the tapping point is temporarily unusually high.

Possible causes	Corrective action
Failing or blocked pressure relief valve.	<ul style="list-style-type: none"> <li>- Flush and clean the complete tank including the piping between pressure relief valve and the cold water inlet.</li> <li>- Replace the pressure relief valve.</li> </ul>

## 16.4 Troubleshooting Based on error codes

If the unit encounters a problem, the user interface will display an error code. It is important to understand the issue and take appropriate measures before resetting the error code. This should be performed by a licensed installer or your local dealer. This chapter provides an overview of most possible error codes and their descriptions as they appear on the user interface.

<b>Error code table</b>		
<b>Power Protection</b>		
<b>Error code</b>	<b>Error name</b>	<b>Note</b>
E1	Phase Reversal Protection	For three-phase model
E7	Phase Loss Protection	For three-phase model
<b>Sensor Fault</b>		
<b>Error code</b>	<b>Error name</b>	<b>Note</b>
E12	DHW Tank Temp. Sensor Fault	
E14	TWout3_SENSOR Fault	Not applicable
E15	Floor Heating Inlet Temp. Sensor Fault	Not applicable
E80	Buffer Tank Top Temp. Sensor Fault	
E81	Buffer Tank Bottom Temp. Sensor Fault	Not applicable
E82	Solar Water Heater Temp. Sensor Fault	Not applicable
E84	Air Conditioner Total Outlet Temp. Sensor Fault	Not applicable
E85	Room Temp. Sensor Fault	
E101	Coil Temp. Sensor Fault	
E102	Exhaust Temp. Sensor Fault	
E104	High Pressure Sensor Fault	
E105	Low Pressure Sensor Fault	
E108	Suction Temp. Sensor Fault	
E109	Cooling after EEV Temp. Sensor Fault	
E127	EVI Inlet Temp. Sensor Fault	Not applicable
E128	EVI Outlet Temp. Sensor Fault	Not applicable
E129	Refrigerant Gas Side Temp. Sensor Fault	Not applicable
E130	Refrigerant Liquid Side Temp. Sensor Fault	Not applicable
E161	Ambient Temp. Sensor Fault	
E168	Plate Heat Exchanger Outlet Temp. Sensor Fault	
E171	Plate Heat Exchanger Inlet Temp. Sensor Fault	
E172	Total Outlet Temp. Sensor Fault	Not applicable
E182	R290 Sensor Fault	
E183	R290 Leak Alarm	
<b>Communication Fault</b>		
<b>Error code</b>	<b>Error name</b>	<b>Note</b>
E2	EEPROM Data Error	
E6	System Maintenance Data Error	
E83	Display Communication Fault	
E120	EC1 Communication Fault	Not applicable
E122	EC2 Communication Fault	Not applicable
E124	Inverter Board Communication Fault	
E178	Communication Fault Between Mainboard and Expansion Board	
E179	Low Protocol Version Alarm	
E181	Abnormal Device Configuration	
E185	Model configuration failed	

E186	Communication Failure Between Mainboard and Expansion Board	
<b>Refrigerant System Protection</b>		
<b>Error code</b>	<b>Error name</b>	<b>Note</b>
E10	DHW Heater Overheat Protection	
E97	Compressor Low Pressure Protection	
E98	Compressor High Pressure Protection	
E103	Exhaust Temp. Overheat Protection	
E106	Pressure Value Too Low Protection	
E107	Pressure Value Too High Protection	
E110	Suction Temp. Too Low Protection	
E111	Frequent Defrosting Protection	
E112	Abnormal Suction-exhaust Temp. Difference Protection	
E113	Low Evaporation Pressure Protection In Cooling	
E115	Low Ambient Temp. Protection	
E116	Plate Heat Exchanger Inlet Water Temp. Too Low	
E117	Plate Heat Exchanger Inlet Water Temp. Too High	
E118	Fan 1 Speed Abnormal Fault	
E119	Fan 2 Speed Abnormal Fault	Not applicable
E121	EC1 Fault	Not applicable
E123	EC2 Fault	Not applicable
E125	Inverter Board Fault	
E126	Inverter Model Setting Protection	
E131	High Evaporation Temp. Protection	
E133	MPPT1 Fault	Not applicable
E134	MPPT2 Fault	Not applicable
E164	Auxiliary Electric Heater Overload Protection	
E165	Overload Protection	Not applicable
E166	Plate Heat Exchanger Outlet Water Temp. Too Low	
E167	Plate Heat Exchanger Outlet Water Temp. Too High	
<b>Water Circuit Protection</b>		
<b>Error code</b>	<b>Error name</b>	<b>Note</b>
E169	Insufficient Water Flow Protection	
E174	Plate Heat Exchanger Inlet/Outlet Temp. Difference Large Protection	
E175	Plate Heat Exchanger Inlet/Outlet Temp. Difference Abnormal Protection	
E176	Inverter Water Pump Alarm	
E180	Inverter Water Pump Fault	
E184	Flow Sensor Fault	
<b>Inverter Board Fault</b>		
<b>Error code</b>	<b>Error name</b>	<b>Note</b>
Er.ocb (1)	Overcurrent During Inverter Board Startup Protection	
Er.ocA (2)	Overcurrent Protection for Inverter Board Acceleration Operation	
Er.ocd (3)	Overcurrent Protection for Inverter Board Deceleration Operation	

Er.ocn (4)	Overcurrent Protection for Inverter Board Constant-Speed Operation	
Er.ouA (5)	Overvoltage Protection for Inverter Board Acceleration Operation	
Er.oud (6)	Overvoltage Protection for Inverter Board Deceleration Operation	
Er.oun (7)	Overvoltage Protection for Inverter Board Constant-Speed Operation	
Er.ouE (8)	Overvoltage Protection for Inverter Board During Standby	
Er.dcL (9)	Undervoltage Protection for Inverter Board During Operation	
Er.PLI (10)	Input Phase Loss Protection for Inverter Board	
Er.PLo (11)	Output Phase Loss Protection for Inverter Board	
Er.FoP (12)	Protection of inverter power devices	
Er.oHI (13)	Inverter Board Overheat Protection	
Er.oLI (14)	Inverter Board Overload Protection	
Er.oLL (15)	Inverter Motor Overload Protection	
Er.EEF (16)	PFC Start Failed on Inverter Board	
Er.oLP (17)	Inverter Motor Overload Protection	
Er.ULd (18)	Inverter Motor Overspeed Protection	
Er.Co1 (19)	Inverter Board D-Axis Overcurrent Protection	
Er.Co2 (20)	Inverter Board Q-Axis Overcurrent Protection	
Er.EEP (21)	Inverter board parameter storage failed	
Er.CFE (22)	Inverter Board Communication Fault	
Er.ccF (23)	Inverter Board Current Detection Fault	
Er.ArF (24)	Inverter Board PFC Temp. Fault	
Er.Aco (25)	Inverter Board Start Motor Locked-Rotor Protection	
Er.PGo (26)	Inverter Board Running Motor Locked-Rotor Protection	
Er.rHo (27)	Inverter Board Heat Dissipation Temp. Fault	
Er.Abb (28)	Inverter Board Out of Speed Fault	
Er.lo1 (29)	Inverter Board Interrupt Fault 1	
Er.lo2 (30)	Inverter Board Interrupt Fault 2	
Er.PnL (31)	Starting Rotor Vibration Over-limit Protection	
Er.rr1 (32)	Operating Rotor Vibration Over-limit Protection	
Er.PF1 (33)	Inverter Board PFC Overcurrent Protection	
Er.PF2 (34)	PFC Overcurrent Protection	
Er.PF2 (35)	PFC Effective Current Overload Protection	
Er.Seq (36)	Input Power Phase Incorrect Fault	
Er.FmA (37)	Input Power Frequency Too High Protection	
Er.Fmi (38)	Input Power Frequency Too Low Protection	
Er.AcH (39)	Input Power Overvoltage Protection	
Er.AcL (40)	Input Power Undervoltage Protection	
Er.Invt(41)	Input Three-Phase Voltage Distortion Protection	
Er.Invt(42)	Output Power Overvoltage Protection	
Er.Invt(43)	Charging Circuit Abnormal Protection	
Er.Invt(44)	TASK2 Overflow Fault	
Er.Invt(45)	TASK2 Operational Fault	


Note: Below are troubleshooting steps for some common faults. For faults not listed here, please contact the supplier for resolution.

### 16.4.1 E1 Troubleshooting

**Description**

Error code		E1(For 3Ph unit)	
Description		Phase Reversal Protection	
Triggering		At least one of L1/L2/L3/N misconnected	
Relative ports and locations	Terminal blocks		

**Procedure**




## 16.4.2 E7 Troubleshooting

### Description


Error code		E7	
Description		Phase Loss Protection	
Triggering		At least one of L1/L2/L3/N disconnected	
Relative ports and locations	Terminal blocks		

### Procedure




### 16.4.3 E12, E80 Troubleshooting

#### Description

Error code	Description	Port	Location (Main Control PCB)																								
E12	DHW Tank Temp. Sensor Fault	AI5C	 <table border="1" data-bbox="539 517 853 723"> <tr> <td>S1 H: Thermostat Signal H</td> <td>S1 C: Thermostat Signal C</td> </tr> <tr> <td>SL1 SL2: Solar water heater</td> <td>P.D N: Secondary Circulation Pump</td> </tr> <tr> <td>1-2: Electric heat1</td> <td>3-4: Electric heat2</td> </tr> <tr> <td>P. S: DHW tank heater</td> <td>2DPF/2DN N: Cooling three way valve</td> </tr> <tr> <td>DPF/2DN N: Mixing valve</td> <td>TOPF/7DN N: DHW three way valve</td> </tr> <tr> <td>AHS1 AHS2: Auxiliary heat source</td> <td>HT N: Fan heater</td> </tr> <tr> <td>P. S N: Return water pump</td> <td>P. S N: Solar water pump</td> </tr> <tr> <td>P. M N: Mixing water pump</td> <td>DFR1 DFR2: Defrost signal</td> </tr> <tr> <td>ERR1 ERR2: Fault signal</td> <td></td> </tr> <tr> <td>AI5A: Bottom Temp. of BT</td> <td>AI5B: Top Temp. of BT</td> </tr> <tr> <td>AI5D: DHW tank temp.</td> <td>AI5D: Outlet temp. of whole system</td> </tr> <tr> <td>AI5E: Inlet temp. of FH</td> <td></td> </tr> </table>	S1 H: Thermostat Signal H	S1 C: Thermostat Signal C	SL1 SL2: Solar water heater	P.D N: Secondary Circulation Pump	1-2: Electric heat1	3-4: Electric heat2	P. S: DHW tank heater	2DPF/2DN N: Cooling three way valve	DPF/2DN N: Mixing valve	TOPF/7DN N: DHW three way valve	AHS1 AHS2: Auxiliary heat source	HT N: Fan heater	P. S N: Return water pump	P. S N: Solar water pump	P. M N: Mixing water pump	DFR1 DFR2: Defrost signal	ERR1 ERR2: Fault signal		AI5A: Bottom Temp. of BT	AI5B: Top Temp. of BT	AI5D: DHW tank temp.	AI5D: Outlet temp. of whole system	AI5E: Inlet temp. of FH	
S1 H: Thermostat Signal H	S1 C: Thermostat Signal C																										
SL1 SL2: Solar water heater	P.D N: Secondary Circulation Pump																										
1-2: Electric heat1	3-4: Electric heat2																										
P. S: DHW tank heater	2DPF/2DN N: Cooling three way valve																										
DPF/2DN N: Mixing valve	TOPF/7DN N: DHW three way valve																										
AHS1 AHS2: Auxiliary heat source	HT N: Fan heater																										
P. S N: Return water pump	P. S N: Solar water pump																										
P. M N: Mixing water pump	DFR1 DFR2: Defrost signal																										
ERR1 ERR2: Fault signal																											
AI5A: Bottom Temp. of BT	AI5B: Top Temp. of BT																										
AI5D: DHW tank temp.	AI5D: Outlet temp. of whole system																										
AI5E: Inlet temp. of FH																											
E80	Buffer Tank Top Temp. Sensor Fault	AI5B																									

Procedure






### 16.4.4 E104, E105, E182 Troubleshooting

#### Description

Error code	Description	Port	Location (Main Control PCB)
E182	R290 Sensor Fault	J9	
E104	High Pressure Sensor Fault	J5	
E105	Low Pressure Sensor Fault	J6	

#### Procedure






### 16.4.5 E101, E102, E108, E109, E161, E168, E171 Troubleshooting

**Description**



Error code	Description	Port	Location (Main Control PCB)
E101	Coil Temp. Sensor Fault	AI5	
E102	Exhaust Temp. Sensor Fault	AI4	
E108	Suction Temp. Sensor Fault	AI3	
E109	Anti-freeze Temp. Sensor Fault	AI2	
E161	Ambient Temp. Sensor Fault	AI1	
E168	Plate Heat Exchanger Outlet Temp. Sensor Fault	AI7	
E171	Plate Heat Exchanger Inlet Temp. Sensor Fault	AI8	

Procedure




## 16.4.6 E83 Troubleshooting

### Description


Error code	E83
Description	Communication fault between display and Main Control Board
Triggering	Main Control Board side: Communication failure with display lasts 2 min Display side: No communication reply from Main Control PCB for 1 min
Relative ports and locations	<p data-bbox="416 1115 448 1144">J3</p>  

Procedure




## 16.4.7 E124 Troubleshooting

### Description



Error code		E124
Description		Communication fault between Inverter Board and Main Control Board
Triggering		Communication failure lasts 1 min
Relative ports and locations	Main Control Board(J1)	 <p>A photograph of the Main Control Board (J1). A red rectangular box highlights a connector located in the upper left quadrant of the board. The board is green and populated with various electronic components, including capacitors, resistors, and integrated circuits. Several multi-pin connectors are visible along the top and right edges.</p>
	Inverter Board(J4)	 <p>A photograph of the Inverter Board (J4). A red rectangular box highlights a connector located in the upper right quadrant of the board. The board is green and features large electrolytic capacitors, inductors, and other power-related components. Multiple connectors are visible along the bottom and right edges.</p>

Procedure




## 16.4.8 E178 Troubleshooting

### Description


Error code		E178
Description		Communication fault between Expansion Board and Main Control Board
Triggering		Communication failure lasts 1 min
Relative ports and locations	Main Control Board(J2)	 <p>A photograph of the Main Control Board (J2) showing various components. A red circle highlights a green connector located near the top center of the board.</p>
	Expansion Board(J1)	 <p>A photograph of the Expansion Board (J1) showing various components. A red circle highlights a green connector located near the top right of the board.</p>

Procedure




### 16.4.9 E103 Troubleshooting

**Description**


Error code	E103	
Description	The protection for overheat exhaust temperature of Compressor	
Triggering	The Main Control PCB detected that the compressor exhaust temperature was $\geq 110^{\circ}\text{C}$	
Relative ports and locations	AI4	 <p>The diagram shows the Main Control PCB with various ports labeled: Flow Switch, Inlet Water Temperature, Outlet Water Temperature, Coil Temperature, Exhaust Temperature (circled in red), Suction Temperature, Anti-Freeze Temperature, Ambient Temperature, High Pressure Sensor, and Low Pressure Sensor. The photograph below shows the physical PCB with the corresponding port also circled in red.</p>

Procedure




### 16.4.10 E106 Troubleshooting

**Description**


Error code	E106	
Description	Low pressure protection	
Triggering	The Main Control Board detected that the low pressure switch has been triggered.	
Relative ports and locations	D12	 <p>The diagram illustrates the wiring for the E106 error code, which is triggered by a low pressure switch. It shows a terminal block with various sensors connected. A red circle highlights the connection for the Low Pressure Protection sensor. The photo below shows the physical PCB with a red circle highlighting the location of the Low Pressure Protection sensor.</p>

Procedure




## 16.4.11 E107 Troubleshooting

### Description

Error code	E107	
Description	High pressure protection	
Triggering	The Main Control Board detected that the high pressure switch has been triggered.	
Relative ports and locations	DI1	 <p>The diagram and photograph illustrate the wiring and physical location of the High Pressure Sensor. The wiring diagram shows the sensor connected to the High Pressure Protection line. The photograph shows the Main Control Board with the High Pressure Sensor terminal highlighted in red.</p>

Procedure




### 16.4.12 E115 Troubleshooting

**Description**

Error code	E115	
Description	Low Ambient Temp. Protection	
Triggering	In heating/ DHW mode, the error occurs when Ambient Temp. < -25°C In cooling mode, the error occurs when Ambient Temp. < -7°C	
Relative ports and locations	AI1	<p>The diagram and photo illustrate the sensor connections for the E115 error code. The wiring diagram shows the following connections:</p> <ul style="list-style-type: none"> <li>R290 Leak Sensor</li> <li>High Pressure Protection</li> <li>Low Pressure Protection</li> <li>Flow Switch</li> <li>Inlet Water Temperature</li> <li>Outlet Water Temperature</li> <li>Coil Temperature</li> <li>Exhaust Temperature</li> <li>Suction Temperature</li> <li>Anti-Freeze Temperature</li> <li>Ambient Temperature (highlighted with a red circle in the diagram)</li> <li>High Pressure Sensor</li> <li>Low Pressure Sensor</li> </ul> <p>The photo shows the physical PCB with a red circle highlighting the Ambient Temperature sensor connector on the right side of the board.</p>

Procedure




### 16.4.13 E118 Troubleshooting

**Description**

Error code		E118
Description		Fan 1 Speed Abnormal Fault
Triggering		If the heat pump detects that the fan speed remains too low for a period, this fault will be triggered.
Relative ports and locations	FAN1	

## Procedure




### 16.4.14 E164 Troubleshooting

#### Description



<p><b>Error code</b></p>	<p><b>E164</b></p>	
<p>Description</p>	<p>Auxiliary Electric Heater Overload Protection</p>	
<p>Triggering</p>	<p>After enabling the electric heater function, the heat pump will detect the electric heater overload protection port. If it is disconnected, a fault will be reported.</p>	
<p>Relative ports and locations</p>	<p>IBH1/2_FB</p>	

Procedure




### 16.4.15 E166 Troubleshooting

#### Description


Error code	E166
Description	Plate Heat Exchanger Outlet Water Temp. Too Low
Triggering	When the plate heat exchanger outlet water temperature < [ Cooling outlet temperature too low ], this protection is triggered.
Relative ports and locations	<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p data-bbox="316 1093 359 1126">AI7</p> </div> <div>  <p data-bbox="1233 506 1497 689">Inlet Water Temperature Outlet Water Temperature Coil Temperature Exhaust Temperature Suction Temperature Anti-Freeze Temperature Ambient Temperature</p> <p data-bbox="1233 786 1453 864">High Pressure Sensor Low Pressure Sensor</p> <p data-bbox="424 759 679 786">Electronic Expansion Valve</p> </div> </div> 

## Procedure




### 16.4.16 E167 Troubleshooting

#### Description

Error code	E167
Description	Plate Heat Exchanger Outlet Water Temp. Too High
Triggering	When the plate heat exchanger outlet water temperature $\geq$ [Heating outlet temperature too high ], this protection is triggered.
Relative ports and locations	<p data-bbox="316 1099 357 1126">AI7</p> 

Procedure




### 16.4.17 E10 Troubleshooting

**Description**

<b>Error code</b>	<b>E10</b>
-------------------	------------


<b>Description</b>	DHW Heater Overheat Protection
--------------------	--------------------------------

<b>Triggering</b>	After enabling the DHW electric heater function, the heat pump will detect the DHW electric heater overload protection port. If it is disconnected, a fault will be reported.
-------------------	---




Relative ports and locations

TBH\_FB




Procedure




# 16.4.18 E169 Troubleshooting

## Description

Error code	E169	
Description	Water Flow Protection	
Triggering	When the flow switch detects insufficient water flow, it will trigger this alarm.	
Relative ports and locations	D15	 <p>The diagram shows a terminal block with various sensors connected. A red circle highlights the connection point for the Flow Switch. The photograph shows the physical control board with a red circle highlighting the corresponding terminal on the board.</p> <ul style="list-style-type: none"> <li>R290 Leak Sensor</li> <li>High Pressure Protection</li> <li>Low Pressure Protection</li> <li>Flow Switch</li> <li>Inlet Water Temperature</li> <li>Outlet Water Temperature</li> <li>Coil Temperature</li> <li>Exhaust Temperature</li> <li>Suction Temperature</li> <li>Anti-Freeze Temperature</li> <li>Ambient Temperature</li> <li>High Pressure Sensor</li> <li>Low Pressure Sensor</li> </ul>

**Procedure**



Note 1:

The meaning of percentage of water pump			
Percentage	Water pump model	Brand	Description
0%	Para 25-130/8-75/IPWM1-12	WILO	IPWM connection port short circuited
2%			Pump Standby
80%			Undervoltage<160/170-194V, and Pump keeps running
85%			Undervoltage<160/170V, Overvoltage>253V-264V; Motor overload; module overheat; external pump flow rate larger than internal pump flow rate, Pump stops running
90%			Motor overspeed; over current; underspeed; pump stalling, and pump stops running
95%			Pump damaged; circuit damaged; terminal damaged, and pump stops running
100%			IPWM connection port open circuited

Note 2– Indicator lights on WILO water pump:

PWM Feedback	LED Status	Fault Name	Fault Type	Protection Activation	Pump Action
95%	Red light always on	Drive failure	Final fault	Driver internals error	Try to reset the pump
95%	Red light always on	Missing motor or winding contacts, or electrical box not connected	Final fault	During startup, electrical box&motor connection is disconnected	Try to reset the pump
95%	Red light always on	Stuck (Not Rotating)	Final fault	Rotor is not rotating; anti-jam program has been activated but failed	Rotor is permanently stuck, no longer reset the pump
90%	Red light flashing	Over-current	Fault	Motor phase current exceeds maximum allowable value	Try to reset the pump
90%	Red light flashing	Over-speed	Fault	Motor speed exceeds maximum allowable value	Try to reset the pump
85%	Red light flashing	Input voltage too low	Fault	Input voltage < 160Vac	To prevent damage to electronic components, allow the pump to stop running
85%	Red light flashing	Input voltage too high	Fault	Input voltage > 253Vac (230V+10%)	253-263V: Do not stop the pump, allow reduction of some hydraulic performance > 263V:To prevent damage to electronic components, allow the pump to stop running. Alarm signal (PWM, LED) is only reported when the pump is stopped
85%	Red light flashing	Motor overload	Fault	Overload occurs; actual speed is lower than the minimum operable speed on motor	Try to reset the pump
85%	Red light flashing	Electrical box temperature too high	Fault	Temperature exceeds maximum allowable value	Pump stops when temperature is too high
85%	red and green lights flashing	Generator mode operation	Alarm	External water flow causes the generator to run	Run continuously
80%	red and green lights flashing	Voltage too low	Alarm	Voltage lower segment: 160Vac < U < 190Vac; Voltage upper segment: 170Vac < U < 195Vac	Run continuously, output performance may be reduced

Note 3: The possible error and solutions of water pump



The meaning of percentage of water pump		
Possible cause	Solution	Description
Water pump leak	Replace the sealing ring	Error occurs at the first time running
Water inlet and outlet pipe connected reversely	Connect the pipe correctly.	
The power cable (DO0) is not connected properly	Connect the power cable correctly.	
The feedback signal cable (#4) is not connected properly	Connect the feedback signal cable correctly.	
Pump stalling	Remove the water pump, Rotate the impeller manually until it can move freely. And then install it back. (If it's too hard to rotate the impeller manually, replace the water pump)	Error occurs at the first time running or after running for a while
Power supply is abnormal	Check the power supply	
E169 occurs after water pump running for a while	Fill the water circuit first and then release the air.	Error occurs after running for a while
Motor stall, and it can not be rotated manually	Replace water pump	Error occurs at the first time running or after running for a while
Water pump connection is correct, the water pump icon on the display is lit. While no indicator lights on water pump is lit.	Replace water pump	Error occurs at the first time running

Note 4: The possible error and solutions of water flow switch failure


The possible causes of water flow switch failure and solutions		
Possible cause	Solution	Description
The water flow in the pipe is not consistent with arrow on the flow switch.	Adjust the direction of water flow in the pipe to be the same as the arrow on the flow switch	Error occurs at the first time running
Flow switch (DI5) is not connected properly.	Insert the plug of the water flow switch correctly	
External pump starts before internal pump(PUMPI) starts	Start internal pump first, make sure water flow is sufficient for external pump	
Flow switch not installed properly	Reinstall the flow switch correctly	Error occurs at the first time running or after running for a while
Flow switch leak	Replace the sealing ring	
flow switch rake blocked	Clean the obstacles	
flow switch rake damaged	Replace the flow switch	
The flow switch contact can not be completely closed	Replace the flow switch	
The flow switch contact can not be completely open	Replace the flow switch	
The flow switch model did not match	Replace the flow switch	

### 16.4.19 E174 Troubleshooting

#### Description

Error code	E174
Description	Plate Heat Exchanger Inlet/Outlet Temp.Large Difference Protection
Triggering	When the inlet-to-outlet temperature difference of the plate heat exchanger exceeds [Excessive Inlet-to-Outlet Temperature Difference], an alarm will be triggered.
Relative ports and locations	<div style="display: flex; justify-content: space-between;"> <div style="width: 15%;"> <p>AI7&amp;AI8</p> </div> <div style="width: 85%;">  <p>Relative ports and locations</p> </div> </div> 

Procedure



## 16.4.20 Fault recovery ways

Recovery way	<p>Auto reset (A) Alarms automatically reset after fault elimination. Auto reset has no limit on the number of times.</p>
	<p>Manual reset (M) Alarms can only be manually reset via the controller after fault elimination. Limited auto reset (A/M) faults and auto reset (A) faults can also be manually reset.</p>
	<p>Limited Auto-Reset (A/M) After a fault alarm, when the fault is cleared, a delay of [Fault Reset Time] occurs. If the same fault does not reoccur during this period, the alarm automatically resets. Within the set time [Auto-Reset Allowance Time], automatic reset is permitted twice. Upon the third alarm, the system locks and requires shutdown. After a "Specific Time," the system automatically resets. "Specific Time": Starts at 30 minutes and increases by 30 minutes per trigger lockout, up to a maximum of 4 hours. After manual reset, the alarm count resets, and the "Specific Time" restarts from 30 minutes.</p>
E1	A/M
E7	A/M
E12	A
E80	A
E104	M
E105	M
E182	A
E101	M
E102	M
E108	M
E109	M
E161	A
E168	A
E171	A
E83	M
E124	A
E178	A
E103	A/M
E106	A/M
E107	A/M
E115	A
E118	A/M
E164	M
E166	A/M
E167	A/M
E10	M
E169	A/M
E174	A/M

# 17 Disposal

## 17.1 General

The unit's components and accessories are not classified as ordinary household waste. The unit itself, along with compressors, motors, and other components, may only be disposed of by qualified specialists. This unit contains hydrofluorocarbon, which may only be disposed of by qualified specialists.

## 17.2 Packaging

- Dispose of the packaging properly.
- Observe all relevant regulations



## 17.3 Refrigerant Handling

 <b>WARNING</b>	
1. Given the characteristics of R290 refrigerant, work involving it should only be performed by individuals with specialized expert knowledge in refrigeration and who are competent in handling R290.	
2. Charging and discharging operations should be performed on the low-pressure side as much as possible to prevent frostbite caused by the refrigerant.	

### 17.3.1 Removal and evacuation

When accessing the refrigerant circuit for repair or other purposes, conventional procedures should be followed. However, given the flammability involved, it is crucial to adhere to best practices. Operate in accordance with the following steps:

- Remove the refrigerant;
- Purge the circuit with inert gas;
- Evacuate the circuit;
- Purge the circuit again with inert gas;
- Open the circuit via cutting or brazing.

The charged refrigerant must be recovered and stored in appropriate recovery cylinders. The system should be flushed with oxygen-free nitrogen (OFN) to ensure unit safety, and this process may need to be repeated multiple times. Never use compressed air or oxygen.

Flushing is performed by filling the system with OFN until the working pressure is reached, then venting to the atmosphere, followed by evacuating the system to a vacuum. This process must be repeated until no refrigerant remains in the system. After the final OFN charge, the system should be vented down to atmospheric pressure before commencing work. This operation is absolutely critical if brazing work is to be carried out on the piping.

Ensure the outlet of the vacuum pump is kept away from any ignition sources and that sufficient ventilation is provided.

### 17.3.2 Charging procedures

In addition to conventional charging procedures, the following requirements must be observed:

- When using charging equipment, ensure that different refrigerants do not become contaminated. Hoses or lines should be as short as possible to minimize the amount of refrigerant retained in them.
- Before charging the system with refrigerant, the refrigeration system must be earthed (grounded).
- Upon completion of charging, label the system if it is not already labeled.
- Exercise extreme caution to avoid overfilling the refrigeration system.
- Prior to recharging the system, test it with oxygen-free nitrogen (OFN). After charging is complete but before commissioning, perform a leak test on the system. Conduct a follow-up leak test before leaving the site.

### 17.3.3 Recovery

When removing refrigerant from a system—whether for maintenance or decommissioning—always follow best practices to ensure safe removal.

When transferring refrigerant into cylinders, use only appropriate refrigerant recovery cylinders. Ensure an adequate number of cylinders are available to hold all the refrigerant. All cylinders used must be designated, labeled for the recovered refrigerant (i.e., specialized cylinders for refrigerant recovery), and equipped with properly functioning pressure relief valves and associated shut-off valves.

Empty recovery cylinders should be evacuated and, if possible, cooled before recovery begins.

The recovery equipment must be in good working order, accompanied by on-site operating instructions, and suitable for recovering

flammable refrigerants. Additionally, a set of calibrated weighing scales must be available and functional. Hoses should be fitted with leak-free disconnect couplings and in good condition. Before using the recovery equipment, inspect and verify that it is properly maintained, and that any associated electrical components are sealed to prevent ignition in the event of refrigerant leakage. Consult the manufacturer if there is any uncertainty.

Recovered refrigerant should be returned to the refrigerant supplier in appropriate recovery cylinders, along with the relevant Waste Transfer Note. Do not mix refrigerants in recovery units, especially in cylinders.

If compressors or compressor oils are to be removed, ensure they have been evacuated to an acceptable level to eliminate residual flammable refrigerant in the lubricant. Perform the evacuation before returning the compressor to the supplier. To speed up this process, only heat the compressor body electrically. Drain oil from the system safely.

### 17.3.4 Decommissioning

Before beginning this procedure, the technician must be fully familiar with the equipment and all its details. It is recommended that all refrigerants be recovered safely. Prior to recovery, samples of oil and refrigerant should be taken for analysis before reusing reclaimed refrigerant. Ensure electrical power is available before starting the task.

1. Familiarize yourself with the equipment and its operation.
2. Isolate the system electrically.
3. Before attempting the procedure, ensure that:
  - Mechanical handling equipment is available (if needed) for moving refrigerant cylinders.
  - All personal protective equipment is available and used correctly.
  - The recovery process is supervised at all times by a competent individual.
  - Recovery equipment and cylinders comply with relevant standards.
4. Pump down the refrigerant system if possible.
5. If creating a vacuum is not possible, use a manifold to remove refrigerant from different parts of the system.
6. Ensure the cylinders are placed on the scales before recovery begins.
7. Start the recovery machine and operate it according to the manufacturer's instructions.
8. Do not overfill the cylinders (fill to no more than 80% of their volume).
9. Do not exceed the cylinders' maximum working pressure, even temporarily.
10. Once the cylinders are correctly filled and the process is complete, immediately remove the cylinders and equipment from the site and close all isolation valves on the equipment.
11. Recovered refrigerant must not be reused in any other refrigeration system unless it has been cleaned and inspected.

# 18 Check list

## Engineering Commissioning and Acceptance Form

### I. Project Information

<b>User Information</b>	Project name		User name			
	Installation address		Contact number			
<b>Dealer Information</b>	Company name					
	Contact		Contact number			
<b>Installation Company</b>	Company name					
	Installation manager		Contact number			
<b>Temperature at Installation Site</b>	Average surface water temperature		User demand	Cooling/heating demand		
	Summer highest temperature			Air-conditioned area		
	Winter lowest temperature			Hot water demand		
<b>Unit Information</b>	Unit number	Unit model	Unit barcode	Unit number	Unit model	Unit barcode
<b>Other Project Information</b>	Terminal:	<input type="checkbox"/> Fan coil <input type="checkbox"/> Floor heating <input type="checkbox"/> Radiator				
	Buffer/insulation tank (T)		Electric heater configuration (kW)			
	Rated head of primary pump (m):		Rated flow (m <sup>3</sup> /h):			
	Rated head of secondary pump (m):		Rated flow (m <sup>3</sup> /h):			

### II. Pre-acceptance Inspection

Inspection Item		Technical Specification Requirements	Result	Remarks	
<b>Unit Installation</b>	Installation environment	No strong radiation, no corrosive sources, no oil fumes; the unit's noise and exhaust must not affect the activities of surrounding personnel; windbreak walls shall be installed in strong wind environments.			
	Maintenance space	Sufficient maintenance space (side air outlet: over 0.5 m).			
	Ventilation and heat dissipation	Good ventilation and heat dissipation (air outlets shall be 3 m away from obstacles; the rear air return of multiple units shall be at least 1 m away from other units and obstacles).			
	Condensate drainage	Bottom-suspended installation with a reasonable condensate drainage design.			
	Bottom foundation	Sufficient foundation height.			
	Fixation and vibration damping measures	Fixed with bolts and equipped with rubber or spring vibration dampers.			
	Unit installation spacing	Compliance with the unit installation spacing requirements specified in Section 6.1.			
	Terminal fan coil installation		Smooth and reasonable condensate drainage.		
			Installation of indoor air outlets and return air inlets meets installation standards.		
			Inspection openings reserved in accordance with standards.		
		If fan coils are equipped with solenoid valves, ensure that 30% or more of the fan coils are installed with three-way solenoid valves.			
<b>Electrical System</b>	Unit distribution box (if any)	An independent distribution box is installed for the project.			
		The distribution box is equipped with a leakage protection device, and electrical components have rain and moisture protection measures.			
		The distribution box is placed at least 50 cm above the ground and securely fixed.			
		Specifications of the circuit breaker and wires in the distribution box meet the maximum power requirements for unit operation.			
		Copper lugs for load connections are securely fastened.			
	Main unit control box	The phase sequence and neutral wire connections between the unit, water pump, and control box are correct.			
		The main unit control box is properly grounded and must not be connected to gas pipes, water pipes, lightning arresters, or telephone lines.			
		Copper lugs for load connections in the unit control box are securely fastened.			
		The connection between the unit and the water tank temperature sensor is properly made.			
		The circulating water pump is interlocked with the main unit, with correct wiring.			
	Power cable diameter	The diameters of power cables for the total power supply and main unit comply with design requirements.			

		The diameters of power cables for the water pump, electric heater, and other loads comply with design requirements.		
	Signal cables	The connection between the unit and the wired controller is properly made.		
		The connection between the solenoid valve and the room thermostat is properly made.		
		The connection between the room thermostat and fan coils is properly made.		
		The smart control wiring of the room thermostat is properly connected.		
	Selection of air circuit breaker (ACB)	The main air circuit breaker (ACB) of the distribution box and the ACB for the main unit comply with design requirements.		
		ACBs for loads such as water pumps and electric heaters comply with design requirements.		
		The specifications of AC contactors for the water pump and other components comply with design requirements.		
	Circuit installation	Connection cables between the distribution box, unit, and water pump are routed through cable troughs or conduits.		
		High-voltage (HV) and low-voltage (LV) wires are installed separately to prevent signal interference.		
		The distribution box (including ACBs and terminal blocks) and power supply terminals of loads (e.g., the main unit) are installed and securely tightened.		
	Voltage detection	Phase A to neutral voltage		
		Phase B to neutral voltage		
		Phase C to neutral voltage		
		380V±7%: (354V~407V); 220V±7%: (205V~236V); three-phase voltage imbalance <2%		
<b>Water System</b>	Piping design	For water systems with ≥3 units, the water piping is installed in a reverse return configuration.		
	Pipe specifications	The main pipe diameter complies with design requirements.		
		The diameters of the unit's and terminal's inlet and outlet pipes comply with design requirements.		
	Pipe fixation	Pipes are securely fixed in accordance with design requirements.		
	Pipe insulation	When water pipes pass through wall openings, foam sealant must be applied to both sides of the opening for stability and to prevent thermal bridge formation.		
		Pipes between the unit, water tank, and terminals are insulated in accordance with specifications.		
	Pipe valves	Pipe valve types are correctly selected in compliance with design requirements.		
		Unit valves can be opened properly.		
		The one-way valve on the piping is installed in the proper direction.		
		The Y-strainer and two/three-way solenoid valve are installed on the terminal inlet pipe.		

	Flexible connections	Flexible connections are installed between the unit and pipes to prevent vibration.		
		Flexible connections are installed at both ends of water pumps to prevent vibration.		
		Flexible connections and valves are installed on the inlet and outlet pipes of the fan coil.		
	Pressure relief valve	Pressure relief valves are installed on the unit's return water pipe.		
	Air vent valve	Automatic air vent valves are installed on the supply and return main pipes.		
	Drain valve	Drain valves are installed at the lowest point of the water system.		
	Water replenishment valve	Water replenishment valves are installed on the unit's inlet/return water pipes.		
	Microbubble deaerator	A microbubble deaerator is installed on the unit's outlet pipe side.		
	Anti-freeze valve	Ensure complete drainage at the valve installation location.		
	Differential bypass valve	A differential bypass valve is installed in the primary circulation system equipped with solenoid valves.		
		It is installed between the unit's inlet and outlet pipes, with the direction from outlet to inlet.		
	Y-strainer	The Y-strainer is correctly installed on the unit's water inlet pipe or upstream of the water pump.		
	Water tank installation	It must be installed on a load-bearing platform (steel frame or concrete foundation).		
		The water tank openings are fabricated and installed in accordance with design requirements.		
		The water tank temperature sensor is securely installed in the sensor pocket, with an insertion depth of over 250 mm. The sensor pocket is vertically aligned with the lower circulation port and installed 50 mm higher than the port.		
		The high water level probe is installed 150 mm below the horizontal level of the overflow outlet's bottom.		
	Water pump installation	The rated head and flow rate of the circulating water pump comply with design requirements, and it is installed in the proper direction.		
		The pump is installed horizontally with appropriate vibration reduction and rain protection measures.		
	Installation of water replenishment system	Open or closed water replenishment system.		
		For closed systems, check that the pressure is sufficient.		
Water treatment system (hot water)	A water softening system is installed in accordance with design requirements (e.g., resin softening, silica phosphate crystal softening).			
	Water quality complies with the pH and hardness requirements specified in the technical manual.			
Drainage and leak detection	The water system is pressurized, leak-checked, and drained.			
<b>III. Unit Acceptance and Commissioning</b>				

- Power-on test to verify the correct phase sequence of the main unit's power wiring and the water pump's power lines.;
- Preheat the compressor for 12 hours with the unit powered on but not operating.;
- Test whether terminal fan coils can be turned on/off normally: check that the speed, cooling/heating switch, and two/three-way valve are functioning properly.;
- Before operation, manually start the water pump to check for normal operation.;
- Fill the water system (if filling fails or the test run is interrupted (e.g., due to power outage), drain and blow out the water to prevent freezing damage to the unit's heat exchanger and pipes).;
- Air purging of the water system: Reverse, sectional, or layered methods can be used for rapid air purging.;
- Start the unit and test the wired controller and thermostat for functions such as on/off, temperature adjustment, mode switching, and full function switching.
- Operate the unit for 30 minutes, then check and record the following real-time operating data: operating current, high/low pressure, inlet/outlet water temperature, discharge temperature, return gas temperature, coil temperature, etc., as shown in the table below.;
- If abnormalities are detected during the above data monitoring, stop the unit immediately and conduct troubleshooting.;
- After 4 hours of normal operation, stop the unit and clean the Y-strainer to remove pipe debris.;
- Restart the unit and continue data monitoring. If no abnormalities are found, the unit's commissioning and acceptance are complete..

Test Items	Test Results
Ambient temperature	
Inlet water temperature	
Outlet water temperature	
Water tank temperature	
Compressor current	
Discharge temperature	
Coil temperature	
suction temperature	
Operating current	
Inlet temperature of vapor injection	
Outlet temperature of vapor injection	
System anti-freeze temperature	
Opening of electronic expansion valve	
Low pressure	
Wifi signal	

#### IV. Delivery and Training

1. Delivery:  User Manual

2. User training:
- Equipment operation: on/off, temperature setting, function switching, status checking, etc.;
  - Unit maintenance: regular cleaning of Y-strainer and piping, regular power cable inspection, regular cleaning of unit fins, regular cleaning of return air filter, etc.;
  - Simple troubleshooting: water flow fault, high pressure fault, phase sequence fault, etc.;
  - How to protect unit from freezing in winter

<b>Rectification Requirements</b>		
<b>Signature Confirmation</b>	<b>Acceptance Person</b>	
	<b>Date</b>	<b>MM/DD/YY</b>
	<b>User Representative</b>	
	<b>Date</b>	<b>MM/DD/YY</b>

# ANNEX

## ANNEX A. Factory default settings

### iGXC11

Type	No.	Name	Range	Default	Unit
User parameter	1	CTRL_MODE	[1]Cooling;[2]Heating;[3]Auto	Heating	/
User parameter	2	COOL_TEMP_SET	-15~35	7	℃
User parameter	3	HEAT_TEMP_SET	0~105	55	℃
User parameter	4	HOT_WATER_TEMP_SET	0~100	60	℃
User parameter	5	COOL_ROOM_TEMP_SET	16~30	26	℃
User parameter	6	HEAT_ROOM_TEMP_SET	16~30	20	℃
User parameter	9	HEAT_TEMP_SET_B	0~105	60	℃
User parameter	10	HEAT_ROOM_TEMP_SET_B	16~30	26	℃
User parameter	11	POWER_MODE	[0]Standard;[1]Turbo;[2]Silent;[3]Auto	Standard	/
User parameter	13	STERILIZATION	[0]Disable;[1]Enable	Disable	/
User parameter	14	STERILIZATION_TEMP	60~70	65	℃
User parameter	15	STERILIZATION_CYCLE_MAX	90~300	210	Min
User parameter	16	STERILIZATION_HIGH_TEMP_TIME	5~60	15	Min
User parameter	26	Zone A Cool Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp.	Disable	/

Type	No.	Name	Range	Default	Unit
			Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9		
User parameter	27	Zone A Heat Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp. Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9	Disable	/
User parameter	28	Zone B Cool Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp. Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9	Disable	/
User parameter	29	Zone B Heat Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp. Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9	Disable	/
User parameter	30	C#9_TA_C1	-5~46	35	℃
User parameter	31	C#9_TA_C2	-5~46	25	℃
User parameter	32	C#9_TWout2_C1	5~25	10	℃
User parameter	33	C#9_TWout2_C2	5~25	16	℃
User parameter	34	C#9_TA_H1	-25~35	7	℃
User parameter	35	C#9_TA_H2	-25~35	-5	℃
User parameter	36	C#9_TWout2_H1	25~65	28	℃
User parameter	37	C#9_TWout2_H2	25~65	35	℃

Type	No.	Name	Range	Default	Unit
User parameter	38	00#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	39	01#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	40	02#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	41	03#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	42	04#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	43	05#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	44	06#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	45	07#UNIT	[0]Disable;[1]Enable	Enable	/
System parameter	5	WIRE_SW_TYPE	[0]Toggle Switch;[1]Pulse Switch	Toggle Switch	/
System parameter	7	PWR_DOWN_MEM	[0]Disable;[1]Enable	Enable	/
System parameter	8	PWR_ON_RUN	[0]Disable;[1]Enable	Disable	/
System parameter	9	PUMP_RUN_MODE	[0]Always;[1]Interval;[2]Save	Interval	/
System parameter	10	TEMP_CTRL_OBJ	[0]Inlet Temp.;[1]Outlet Temp.;[2]Buffer Tank Temp.	Buffer Tank Temp.	/
System parameter	11	CL_TEMP_CORR	-10~10	0	℃
System parameter	12	HT_TEMP_CORR	-10~10	0	℃
System parameter	13	RV_ON_DLY	-100~100	20	s

Type	No.	Name	Range	Default	Unit
System parameter	14	RV_OFF_DLY	-100~100	-20	s
System parameter	15	LIV_ON_TP_T	0~130	107	℃
System parameter	16	LIV_OFF_TP_dT	0~30	10	℃
System parameter	17	HOT_WATER	[0]Disable;[1]Enable	Enable	/
System parameter	18	HW_dT	0~20	5	℃
System parameter	19	QZH_ON_TA_T	-10~20	12	℃
System parameter	20	QZH_OFF_TA_T	-10~20	14	℃
System parameter	23	PWRD_TIME_MIN	0~48	4	h
System parameter	24	PWRD_TIME_MAX	0~96	48	h
System parameter	25	PREHT_TIME_MIN	0~999	10	Min
System parameter	26	PREHT_TIME_MAX	0~999	50	Min
System parameter	31	REMOTE_SW_TYPE	[0]Disable;[1]Linked Action Effective;[2]Linked Closed Effective;[3]Remote On/Off;[4]Remote Tank Heater;[5]Remote External Heat Source	Remote On/Off	/
System parameter	35	PANEL_CTRL	[0]One-zone Water Temp.;[1]One-zone Room Temp.;[2]Two-zone Water Temp.;[3]Two-zone(Water Temp.+ Room Temp.)	One-zone Water Temp.	/
System parameter	36	DHW_PUMP_MODE	[0]Disable;[1]Always;[2]Interval;[3]Save	Disable	/
System parameter	37	TBH relay diff	0~20	0	℃
System parameter	38	DPH_TYPE	[0]Defrosting Pan Heater;[1]Low AT Pan Heater	Defrosting Pan Heater	/

Type	No.	Name	Range	Default	Unit
System parameter	40	SPLASH_TYPE	0~9999	0	/
System parameter	42	SMART_GRID	[0]Disable;[1]Enable	Disable	/
System parameter	44	PUMPf_INTER_O FF_TIME	5~999	10	Min
System parameter	45	MODE_WIRE_CT RL	[0]Disable;[1]Enable	Disable	/
Compressor parameter	5	CM_RPS_DEC	0~20	5	rps
Compressor parameter	35	CM_RATE_HOLD _t	0~900	60	s
Fan parameter	2	INVT_FAN_ID	0~999	57	/
Anti-freeze parameter	12	PUMPsI_ANTIFR EEZE	[0]Disable;[1]Enable	Disable	/
Switch & Sensor Parameter	1	DI_LDIlp	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Closed	/
Switch & Sensor Parameter	2	DI_LDlhp	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Closed	/
Switch & Sensor Parameter	3	OVERLOAD	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Closed	/
Switch & Sensor Parameter	4	DI_LDlw	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Closed	/
Switch & Sensor Parameter	6	TRF_COMP_RPS _CORR	[0]Disable;[1]Enable	Disable	/
Switch & Sensor Parameter	7	TRFgas_RPS_CO RR_1	-20~20	0	rps
Switch & Sensor Parameter	8	TRFgas_RPS_CO RR_2	-20~20	0	rps
Switch & Sensor Parameter	9	TRFgas_RPS_CO RR_3	-20~20	0	rps

Type	No.	Name	Range	Default	Unit
Switch & Sensor Parameter	10	TRFgas_RPS_CO RR_4	-20~20	0	rps
Switch & Sensor Parameter	11	TRFgas_RPS_CO RR_5	-20~20	0	rps
Switch & Sensor Parameter	12	TRFliq_RPS_CO RR_1	-20~20	0	rps
Switch & Sensor Parameter	13	TRFliq_RPS_CO RR_2	-20~20	0	rps
Switch & Sensor Parameter	14	TRFliq_RPS_CO RR_3	-20~20	0	rps
Switch & Sensor Parameter	15	TRFliq_RPS_CO RR_4	-20~20	0	rps
Switch & Sensor Parameter	16	TRFliq_RPS_CO RR_5	-20~20	0	rps
Switch & Sensor Parameter	17	TRFliq_RPS_CO RR_6	-20~20	0	rps
Switch & Sensor Parameter	18	TRFliq_RPS_CO RR_7	-20~20	0	rps
Switch & Sensor Parameter	20	TFLin_SENSOR	[0]Disable;[1]Enable	Disable	/
Switch & Sensor Parameter	21	TWout3_SENSOR R	[0]Disable;[1]Enable	Disable	/
Switch & Sensor Parameter	22	LDlevu_DI_TYPE	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Open	/
Switch & Sensor Parameter	23	LDlsg_DI_TYPE	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Open	/
Switch & Sensor Parameter	33	TACT1_SENSOR	[0]Disable;[1]Enable	Enable	/
Switch & Sensor Parameter	34	TACT2_SENSOR	[0]Disable;[1]Enable	Disable	/
Switch & Sensor Parameter	38	IBH1 POWER	0~30000	0	W

Type	No.	Name	Range	Default	Unit
Switch & Sensor Parameter	39	IBH2 POWER	0~30000	0	W
Switch & Sensor Parameter	40	IDLE POWER	0~30000	0	W
Switch & Sensor Parameter	41	OTHER RUN POWER	0~30000	0	W
Energy control Parameter	2	COOL_LOAD_dT	-20~20	2	℃
Energy control Parameter	3	COOL_UNLOAD_dT	-20~20	2	℃
Energy control Parameter	4	HEAT_LOAD_dT	-20~20	4	℃
Energy control Parameter	5	HEAT_UNLOAD_dT	-20~20	2	℃
Energy control Parameter	6	ROOM_TEMP_dT	1~10	4	℃
Energy control Parameter	26	IBH_GEAR	1~3	1	/
Energy control Parameter	36	HOT_WATER_ON_MAX	10~600	90	Min
Energy control Parameter	37	HOT_WATER_PRIORITY_LIMIT	10~600	30	Min
Project Parameter	21	ZONE_B_HT_TD	[0] Radiator; [1] Fan coil unit; [2] Floor heating	Floor heating	/
Project Parameter	33	REF_RECYCLE	[0]Disable;[1]Enable	Disable	/
Project Parameter	38	howt_freq_diff	0~20	0	℃
Project Parameter	40	UNIT_MAX	1~8	1	/
Project Parameter	41	DHW_UNIT_NUM	1~8	1	/

Type	No.	Name	Range	Default	Unit
Project Parameter	43	PUMPo_FUNC	[0]Zone A External Circulation Pump;[1]Zone A&B External Circulation Pump	Zone A External Circulation Pump	/
Project Parameter	46	BMS_DATA_FMT	[0]8,N,1;[1]8,N,2;[2]8,O,1;[3]8,E,1	8,N,1	/
Project Parameter	47	BMS_BAUDRATE	[0]2400;[1]4800;[2]9600;[3]19200;[4]38400;[5]57600	9600	/
Project Parameter	48	BMS_ADDR	1~247	1	/
Additional parameter	47	off limit diff	0~2500	500	W
Additional parameter	48	TBH_POWER	0~30000	0	W
Additional parameter	1	Power Limit	0~30000	0	W

# iGXC11T

Type	No.	Name	Range	Default	Unit
User parameter	1	CTRL_MODE	[1]Cooling;[2]Heating;[3]Auto	Heating	/
User parameter	2	COOL_TEMP_SE T	-15~35	7	℃
User parameter	3	HEAT_TEMP_SE T	0~105	55	℃
User parameter	4	HOT_WATER_TE MP_SET	0~100	60	℃
User parameter	5	COOL_ROOM_T EMP_SET	16~30	26	℃
User parameter	6	HEAT_ROOM_TE MP_SET	16~30	20	℃
User parameter	9	HEAT_TEMP_SE T_B	0~105	60	℃
User parameter	10	HEAT_ROOM_TE MP_SET_B	16~30	26	℃
User parameter	11	POWER_MODE	[0]Standard;[1]Turbo;[2]Silent;[3]Auto	Standard	/
User parameter	13	STERILIZATION	[0]Disable;[1]Enable	Disable	/
User parameter	14	STERILIZATION_ TEMP	60~70	65	℃
User parameter	15	STERILIZATION_ CYCLE_MAX	90~300	210	Min
User parameter	16	STERILIZATION_ HIGH_TEMP_TIM E	5~60	15	Min
User parameter	26	Zone A Cool Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp. Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9	Disable	/

Type	No.	Name	Range	Default	Unit
User parameter	27	Zone A Heat Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp. Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9	Disable	/
User parameter	28	Zone B Cool Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp. Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9	Disable	/
User parameter	29	Zone B Heat Curve	[0]Disable;[1]Low Temp. Curve1;[2]Low Temp. Curve2;[3]Low Temp. Curve3;[4]Low Temp. Curve4;[5]Low Temp. Curve5;[6]Low Temp. Curve6;[7]Low Temp. Curve7;[8]Low Temp. Curve8;[9]High Temp. Curve1;[10]High Temp. Curve2;[11]High Temp. Curve3;[12]High Temp. Curve4;[13]High Temp. Curve5;[14]High Temp. Curve6;[15]High Temp. Curve7;[16]High Temp. Curve8;[17]Curve9	Disable	/
User parameter	30	C#9_TA_C1	-5~46	35	℃
User parameter	31	C#9_TA_C2	-5~46	25	℃
User parameter	32	C#9_TWout2_C1	5~25	10	℃
User parameter	33	C#9_TWout2_C2	5~25	16	℃
User parameter	34	C#9_TA_H1	-25~35	7	℃
User parameter	35	C#9_TA_H2	-25~35	-5	℃
User parameter	36	C#9_TWout2_H1	25~65	28	℃
User parameter	37	C#9_TWout2_H2	25~65	35	℃
User parameter	38	00#UNIT	[0]Disable;[1]Enable	Enable	/

Type	No.	Name	Range	Default	Unit
User parameter	39	01#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	40	02#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	41	03#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	42	04#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	43	05#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	44	06#UNIT	[0]Disable;[1]Enable	Enable	/
User parameter	45	07#UNIT	[0]Disable;[1]Enable	Enable	/
System parameter	5	WIRE_SW_TYPE	[0]Toggle Switch;[1]Pulse Switch	Toggle Switch	/
System parameter	7	PWR_DOWN_MEM	[0]Disable;[1]Enable	Enable	/
System parameter	8	PWR_ON_RUN	[0]Disable;[1]Enable	Disable	/
System parameter	9	PUMP_RUN_MODE	[0]Always;[1]Interval;[2]Save	Interval	/
System parameter	10	TEMP_CTRL_OBJ	[0]Inlet Temp.;[1]Outlet Temp.;[2]Buffer Tank Temp.	Buffer Tank Temp.	/
System parameter	11	CL_TEMP_CORR	-10~10	0	℃
System parameter	12	HT_TEMP_CORR	-10~10	0	℃
System parameter	13	RV_ON_DLY	-100~100	20	s
System parameter	14	RV_OFF_DLY	-100~100	-20	s

Type	No.	Name	Range	Default	Unit
System parameter	15	LIV_ON_TP_T	0~130	107	℃
System parameter	16	LIV_OFF_TP_dT	0~30	10	℃
System parameter	17	HOT_WATER	[0]Disable;[1]Enable	Enable	/
System parameter	18	HW_dT	0~20	5	℃
System parameter	19	QZH_ON_TA_T	-10~20	12	℃
System parameter	20	QZH_OFF_TA_T	-10~20	14	℃
System parameter	23	PWRD_TIME_MIN	0~48	4	h
System parameter	24	PWRD_TIME_MAX	0~96	48	h
System parameter	25	PREHT_TIME_MIN	0~999	10	Min
System parameter	26	PREHT_TIME_MAX	0~999	50	Min
System parameter	31	REMOTE_SW_TYPE	[0]Disable;[1]Linked Action Effective;[2]Linked Closed Effective;[3]Remote On/Off;[4]Remote Tank Heater;[5]Remote External Heat Source	Remote On/Off	/
System parameter	35	PANEL_CTRL	[0]One-zone Water Temp.;[1]One-zone Room Temp.;[2]Two-zone Water Temp.;[3]Two-zone(Water Temp.+ Room Temp.)	One-zone Water Temp.	/
System parameter	36	DHW_PUMP_MODE	[0]Disable;[1]Always;[2]Interval;[3]Save	Disable	/
System parameter	37	TBH relay diff	0~20	0	℃
System parameter	38	DPH_TYPE	[0]Defrosting Pan Heater;[1]Low AT Pan Heater	Defrosting Pan Heater	/
System parameter	40	SPLASH_TYPE	0~9999	0	/

Type	No.	Name	Range	Default	Unit
System parameter	42	SMART_GRID	[0]Disable;[1]Enable	Disable	/
System parameter	44	PUMPf_INTER_O FF_TIME	5~999	10	Min
System parameter	45	MODE_WIRE_CT RL	[0]Disable;[1]Enable	Disable	/
Compressor parameter	5	CM_RPS_DEC	0~20	5	rps
Compressor parameter	35	CM_RATE_HOLD _t	0~900	60	s
Fan parameter	2	INVT_FAN_ID	0~999	57	/
Anti-freeze parameter	12	PUMPsI_ANTIFR EEZE	[0]Disable;[1]Enable	Disable	/
Switch & Sensor Parameter	1	DI_LDIlp	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Closed	/
Switch & Sensor Parameter	2	DI_LDlhp	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Closed	/
Switch & Sensor Parameter	3	OVERLOAD	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Closed	/
Switch & Sensor Parameter	4	DI_LDlhw	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Closed	/
Switch & Sensor Parameter	6	TRF_COMP_RPS _CORR	[0]Disable;[1]Enable	Disable	/
Switch & Sensor Parameter	7	TRFgas_RPS_CO RR_1	-20~20	0	rps
Switch & Sensor Parameter	8	TRFgas_RPS_CO RR_2	-20~20	0	rps
Switch & Sensor Parameter	9	TRFgas_RPS_CO RR_3	-20~20	0	rps
Switch & Sensor Parameter	10	TRFgas_RPS_CO RR_4	-20~20	0	rps

Type	No.	Name	Range	Default	Unit
Switch & Sensor Parameter	11	TRFgas_RPS_CO RR_5	-20~20	0	rps
Switch & Sensor Parameter	12	TRFlig_RPS_CO RR_1	-20~20	0	rps
Switch & Sensor Parameter	13	TRFlig_RPS_CO RR_2	-20~20	0	rps
Switch & Sensor Parameter	14	TRFlig_RPS_CO RR_3	-20~20	0	rps
Switch & Sensor Parameter	15	TRFlig_RPS_CO RR_4	-20~20	0	rps
Switch & Sensor Parameter	16	TRFlig_RPS_CO RR_5	-20~20	0	rps
Switch & Sensor Parameter	17	TRFlig_RPS_CO RR_6	-20~20	0	rps
Switch & Sensor Parameter	18	TRFlig_RPS_CO RR_7	-20~20	0	rps
Switch & Sensor Parameter	20	TFLin_SENSOR	[0]Disable;[1]Enable	Disable	/
Switch & Sensor Parameter	21	TWout3_SENSO R	[0]Disable;[1]Enable	Disable	/
Switch & Sensor Parameter	22	LDlevu_DI_TYPE	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Open	/
Switch & Sensor Parameter	23	LDlsg_DI_TYPE	[0]Normally Open;[1]Normally Closed;[2]Disable	Normally Open	/
Switch & Sensor Parameter	33	TACT1_SENSOR	[0]Disable;[1]Enable	Enable	/
Switch & Sensor Parameter	34	TACT2_SENSOR	[0]Disable;[1]Enable	Disable	/
Switch & Sensor Parameter	38	IBH1 POWER	0~30000	0	W
Switch & Sensor Parameter	39	IBH2 POWER	0~30000	0	W

Type	No.	Name	Range	Default	Unit
Switch & Sensor Parameter	40	IDLE POWER	0~30000	0	W
Switch & Sensor Parameter	41	OTHER RUN POWER	0~30000	0	W
Energy control Parameter	2	COOL_LOAD_dT	-20~20	2	℃
Energy control Parameter	3	COOL_UNLOAD_dT	-20~20	2	℃
Energy control Parameter	4	HEAT_LOAD_dT	-20~20	4	℃
Energy control Parameter	5	HEAT_UNLOAD_dT	-20~20	2	℃
Energy control Parameter	6	ROOM_TEMP_dT	1~10	4	℃
Energy control Parameter	26	IBH_GEAR	1~3	1	/
Energy control Parameter	36	HOT_WATER_ON_MAX	10~600	90	Min
Energy control Parameter	37	HOT_WATER_PRIORITY_LIMIT	10~600	30	Min
Project Parameter	21	ZONE_B_HT_TD	[0] Radiator; [1] Fan coil unit; [2] Floor heating	Floor heating	/
Project Parameter	33	REF_RECYCLE	[0]Disable;[1]Enable	Disable	/
Project Parameter	38	howt_freq_diff	0~20	0	℃
Project Parameter	40	UNIT_MAX	1~8	1	/
Project Parameter	41	DHW_UNIT_NUM	1~8	1	/
Project Parameter	43	PUMPo_FUNC	[0]Zone A External Circulation Pump;[1]Zone A&B External Circulation Pump	Zone A External Circulation Pump	/

Type	No.	Name	Range	Default	Unit
Project Parameter	46	BMS_DATA_FMT	[0]8,N,1;[1]8,N,2;[2]8,O,1;[3]8,E,1	8,N,1	/
Project Parameter	47	BMS_BAUDRATE	[0]2400;[1]4800;[2]9600;[3]19200;[4]38400;[5]57600	9600	/
Project Parameter	48	BMS_ADDR	1~247	1	/
Additional parameter	47	off limit diff	0~2500	500	W
Additional parameter	48	TBH_POWER	0~30000	0	W
Additional parameter	1	Power Limit	0~30000	0	W

# ANNEX B. Resistance table

1/3

## R-T CONVERSION TABLE

Part No. : 150-103-98\*\*\*  
 R25 : 10.0 k $\Omega$  (Tolerance 1 %)  
 B25/50 : 3950 K (Tolerance 1 %)

t [°C]	Rmin. [k $\Omega$ ]	Rnom. [k $\Omega$ ]	Rmax. [k $\Omega$ ]
-30	170.0	176.7	183.6
-29	160.2	166.3	172.7
-28	150.9	156.6	162.5
-27	142.2	147.5	153.0
-26	134.0	139.0	144.1
-25	126.4	131.0	135.7
-24	119.2	123.5	127.8
-23	112.5	116.4	120.5
-22	106.2	109.9	113.6
-21	100.3	103.7	107.1
-20	94.70	97.86	101.1
-19	89.40	92.33	95.35
-18	84.44	87.15	89.95
-17	79.78	82.30	84.88
-16	75.40	77.74	80.14
-15	71.30	73.46	75.69
-14	67.44	69.45	71.51
-13	63.81	65.68	67.59
-12	60.40	62.13	63.91
-11	57.20	58.80	60.45
-10	54.18	55.67	57.20
-9	51.34	52.72	54.14
-8	48.67	49.95	51.26
-7	46.15	47.34	48.56
-6	43.77	44.88	46.01
-5	41.54	42.56	43.61
-4	39.43	40.38	41.35
-3	37.43	38.32	39.22
-2	35.56	36.38	37.21
-1	33.78	34.55	35.32
0	32.11	32.82	33.54
1	30.53	31.18	31.85
2	29.03	29.64	30.26
3	27.62	28.18	28.76
4	26.28	26.81	27.34
5	25.02	25.50	26.00
6	23.82	24.27	24.73
7	22.69	23.11	23.53
8	21.62	22.00	22.39
9	20.60	20.96	21.32
10	19.64	19.97	20.31
11	18.73	19.03	19.34
12	17.86	18.15	18.43
13	17.04	17.31	17.57
14	16.27	16.51	16.75
15	15.53	15.75	15.98
16	14.83	15.03	15.24
17	14.16	14.35	14.54
18	13.53	13.71	13.88

## Part No. : 150-103-98\*\*\*

t [°C]	Rmin. [kΩ]	Rnom. [kΩ]	Rmax. [kΩ]
19	12.93	13.09	13.25
20	12.36	12.51	12.66
21	11.82	11.96	12.09
22	11.30	11.43	11.55
23	10.81	10.93	11.04
24	10.34	10.45	10.56
25	9.900	10.00	10.10
26	9.470	9.569	9.669
27	9.061	9.160	9.259
28	8.671	8.770	8.869
29	8.301	8.399	8.498
30	7.949	8.046	8.144
31	7.613	7.710	7.807
32	7.294	7.390	7.486
33	6.990	7.084	7.179
34	6.700	6.794	6.888
35	6.424	6.516	6.609
36	6.161	6.252	6.344
37	5.910	6.000	6.090
38	5.670	5.759	5.848
39	5.442	5.529	5.617
40	5.224	5.310	5.397
41	5.016	5.101	5.186
42	4.818	4.901	4.985
43	4.628	4.710	4.792
44	4.447	4.527	4.608
45	4.274	4.353	4.432
46	4.109	4.186	4.264
47	3.950	4.026	4.103
48	3.799	3.874	3.949
49	3.655	3.728	3.802
50	3.516	3.588	3.661
51	3.384	3.454	3.526
52	3.258	3.326	3.396
53	3.136	3.204	3.272
54	3.020	3.086	3.154
55	2.909	2.974	3.040
56	2.803	2.866	2.931
57	2.701	2.763	2.826
58	2.603	2.664	2.726
59	2.509	2.569	2.629
60	2.419	2.478	2.537
61	2.333	2.390	2.448
62	2.250	2.306	2.363
63	2.171	2.226	2.282
64	2.095	2.148	2.203
65	2.022	2.074	2.128
66	1.952	2.003	2.055
67	1.884	1.935	1.986
68	1.820	1.869	1.919
69	1.758	1.806	1.855
70	1.698	1.745	1.793



## R-T CONVERSION TABLE

Part No. :  
 R100 : 3.77 k $\Omega$  (Tolerance 2.4 %)  
 B0/100 : 3979 K (Tolerance 1 %)

t [°C]	Rmin. [k $\Omega$ ]	Rnom. [k $\Omega$ ]	Rmax. [k $\Omega$ ]
-30	904.1	979.3	1060
-29	851.7	922.0	997.4
-28	802.7	868.3	938.8
-27	756.7	818.2	884.1
-26	713.7	771.2	832.8
-25	673.4	727.2	784.8
-24	635.6	685.9	739.8
-23	600.1	647.2	697.7
-22	566.8	611.0	658.3
-21	535.5	577.0	621.2
-20	506.2	545.0	586.5
-19	478.6	515.0	553.9
-18	452.7	486.8	523.3
-17	428.3	460.4	494.6
-16	405.4	435.5	467.6
-15	383.8	412.1	442.2
-14	363.5	390.1	418.4
-13	344.4	369.4	395.9
-12	326.4	349.9	374.8
-11	309.4	331.5	354.9
-10	293.4	314.2	336.2
-9	278.4	297.9	318.6
-8	264.1	282.5	302.0
-7	250.7	268.0	286.4
-6	238.1	254.4	271.6
-5	226.1	241.5	257.7
-4	214.8	229.3	244.6
-3	204.1	217.8	232.2
-2	194.1	206.9	220.5
-1	184.5	196.7	209.5
0	175.5	187.0	199.0
1	166.9	177.7	189.1
2	158.8	169.0	179.7
3	151.2	160.8	170.9
4	143.9	153.0	162.5
5	137.0	145.6	154.6
6	130.5	138.6	147.1
7	124.4	132.0	140.0
8	118.6	125.8	133.3
9	113.0	119.8	127.0
10	107.8	114.2	121.0
11	102.8	108.9	115.3
12	98.08	103.9	109.9
13	93.61	99.09	104.8
14	89.37	94.56	100.0
15	85.34	90.26	95.40
16	81.52	86.17	91.04
17	77.89	82.30	86.91
18	74.44	78.62	82.98

Part No. ;

t [°C]	Rmin. [kΩ]	Rnom. [kΩ]	Rmax. [kΩ]
19	71.16	75.12	79.25
20	68.04	71.80	75.71
21	65.08	68.64	72.35
22	62.26	65.64	69.15
23	59.58	62.78	66.12
24	57.03	60.06	63.23
25	54.60	57.48	60.48
26	52.28	55.02	57.87
27	50.08	52.68	55.38
28	47.98	50.45	53.01
29	45.98	48.32	50.76
30	44.07	46.30	48.61
31	42.25	44.37	46.56
32	40.52	42.53	44.62
33	38.87	40.78	42.76
34	37.29	39.11	40.99
35	35.78	37.51	39.30
36	34.35	35.99	37.69
37	32.97	34.54	36.15
38	31.66	33.15	34.69
39	30.41	31.83	33.29
40	29.21	30.56	31.95
41	28.07	29.35	30.68
42	26.98	28.20	29.46
43	25.93	27.10	28.29
44	24.93	26.04	27.18
45	23.98	25.03	26.12
46	23.06	24.07	25.10
47	22.19	23.14	24.13
48	21.35	22.26	23.20
49	20.55	21.42	22.31
50	19.78	20.61	21.46
51	19.04	19.83	20.64
52	18.33	19.09	19.86
53	17.66	18.38	19.11
54	17.01	17.70	18.40
55	16.39	17.04	17.71
56	15.79	16.42	17.06
57	15.22	15.82	16.43
58	14.68	15.24	15.82
59	14.15	14.69	15.25
60	13.65	14.16	14.69
61	13.16	13.66	14.16
62	12.70	13.17	13.65
63	12.26	12.71	13.16
64	11.83	12.26	12.70
65	11.42	11.83	12.25
66	11.02	11.42	11.82
67	10.64	11.02	11.40
68	10.28	10.64	11.00
69	9.928	10.27	10.62
70	9.592	9.923	10.26

Part No. ;

t [°C]	Rmin. [kΩ]	Rnom. [kΩ]	Rmax. [kΩ]
71	9.269	9.586	9.907
72	8.959	9.261	9.569
73	8.660	8.949	9.243
74	8.373	8.650	8.931
75	8.096	8.361	8.630
76	7.830	8.084	8.341
77	7.574	7.817	8.063
78	7.328	7.560	7.795
79	7.091	7.313	7.538
80	6.862	7.075	7.290
81	6.642	6.846	7.051
82	6.430	6.625	6.822
83	6.226	6.412	6.601
84	6.029	6.208	6.388
85	5.839	6.010	6.183
86	5.656	5.820	5.985
87	5.480	5.637	5.795
88	5.310	5.461	5.612
89	5.146	5.290	5.435
90	4.988	5.126	5.265
91	4.836	4.968	5.101
92	4.688	4.815	4.942
93	4.546	4.668	4.789
94	4.409	4.525	4.642
95	4.277	4.388	4.500
96	4.149	4.256	4.363
97	4.026	4.128	4.230
98	3.906	4.004	4.102
99	3.791	3.885	3.979
100	3.680	3.770	3.860
101	3.570	3.659	3.747
102	3.464	3.551	3.638
103	3.362	3.447	3.533
104	3.263	3.347	3.431
105	3.168	3.250	3.333
106	3.076	3.156	3.237
107	2.986	3.066	3.145
108	2.900	2.978	3.056
109	2.817	2.893	2.970
110	2.736	2.811	2.887
111	2.658	2.732	2.806
112	2.583	2.655	2.728
113	2.510	2.581	2.652
114	2.439	2.509	2.579
115	2.371	2.439	2.508
116	2.305	2.372	2.440
117	2.241	2.307	2.373
118	2.179	2.244	2.309
119	2.119	2.183	2.247
120	2.061	2.123	2.186
121	2.005	2.066	2.128
122	1.950	2.010	2.071



# ANNEX C. AT Compensation Curve

Table 1 Heating Low-Temp. Curve (Heating Ambient Temp. - Target Temp. Table) Unit: °C


AT	≤-20	-19	-18	-17	-16	-15	-14	-13	-12	-11	-10	9	-8	-7	-6	-5	-4	-3	-2	-1	0
Low-Temperature Curve 1	38	38	38	38	38	37	37	37	37	37	37	36	36	36	36	36	36	35	35	35	35
Low-Temperature Curve 2	37	37	37	37	37	36	36	36	36	36	36	35	35	35	35	35	35	34	34	34	34
Low-Temperature Curve 3	36	36	36	35	35	35	35	35	35	34	34	34	34	34	34	33	33	33	33	33	33
Low-Temperature Curve 4	35	35	35	34	34	34	34	34	34	33	33	33	33	33	33	32	32	32	32	32	32
Low-Temperature Curve 5	34	34	34	33	33	33	33	33	33	32	32	32	32	32	32	31	31	31	31	31	31
Low-Temperature Curve 6	32	32	32	32	31	31	31	31	31	31	31	31	30	30	30	30	30	30	30	30	29
Low-Temperature Curve 7	31	31	31	31	30	30	30	30	30	30	30	30	29	29	29	29	29	29	29	29	28
Low-Temperature Curve 8	29	29	29	29	28	28	28	28	28	28	28	28	27	27	27	27	27	27	27	27	26
AT	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	≥20	
Low-Temperature Curve 1	35	35	34	34	34	34	34	34	33	33	33	33	33	33	32	32	32	32	32	32	
Low-Temperature Curve 2	34	34	33	33	33	33	33	33	32	32	32	32	32	32	31	31	31	31	31	31	
Low-Temperature Curve 3	32	32	32	32	32	32	31	31	31	31	31	31	30	30	30	30	30	30	29	29	
Low-Temperature Curve 4	31	31	31	31	31	31	30	30	30	30	30	30	29	29	29	29	29	29	28	28	
Low-Temperature Curve 5	30	30	30	30	30	30	29	29	29	29	29	29	28	28	28	28	28	28	27	27	
Low-Temperature Curve 6	29	29	29	29	29	29	28	28	28	28	28	28	27	27	27	27	27	27	26	26	
Low-Temperature Curve 7	28	28	28	28	28	28	27	27	27	27	27	27	26	26	26	26	26	26	25	25	
Low-Temperature Curve 8	26	26	26	26	26	26	26	25	25	25	25	25	25	25	25	24	24	24	24	24	

Table 2 Heating High-Temp. Curve (Heating Ambient Temp. - Target Temp. Table) Unit: °C

AT	≤ -20	-19	-18	-17	-16	-15	-14	-13	-12	-11	-10	9	-8	-7	-6	-5	-4	-3	-2	-1	0
High-T emp. Curve 1	55	55	55	55	54	54	54	54	54	54	54	54	53	53	53	53	53	53	53	53	52
High-T emp. Curve 2	53	53	53	53	52	52	52	52	52	52	52	52	51	51	51	51	51	51	51	51	50
High-T emp. Curve 3	52	52	52	52	51	51	51	51	51	51	51	51	50	50	50	50	50	50	50	50	49
High-T emp. Curve 4	50	50	50	50	49	49	49	49	49	49	49	49	48	48	48	48	48	48	48	48	47
High-T emp. Curve 5	48	48	48	48	47	47	47	47	47	47	47	47	46	46	46	46	46	46	46	46	45
High-T emp. Curve 6	45	45	45	45	44	44	44	44	44	44	44	44	43	43	43	43	43	43	43	43	42
High-T emp. Curve 7	43	43	43	43	42	42	42	42	42	42	42	42	41	41	41	41	41	41	41	41	40
High-T emp. Curve 8	40	40	40	40	39	39	39	39	39	39	39	39	38	38	38	38	38	38	38	38	37

AT	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	≥ 20
High-T emp. Curve 1	52	52	52	52	52	52	52	51	51	51	51	51	51	51	51	50	50	50	50	50
High-T emp. Curve 2	50	50	50	50	50	50	50	49	49	49	49	49	49	49	49	48	48	48	48	48
High-T emp. Curve 3	49	49	49	49	49	49	49	48	48	48	48	48	48	48	48	47	47	47	47	47
High-T emp. Curve 4	47	47	47	47	47	47	47	46	46	46	46	46	46	46	46	45	45	45	45	45
High-T emp. Curve 5	45	45	45	45	45	45	45	44	44	44	44	44	44	44	44	43	43	43	43	43
High-T emp. Curve 6	42	42	42	42	42	42	42	41	41	41	41	41	41	41	41	40	40	40	40	40
High-T emp. Curve 7	40	40	40	40	40	40	40	39	39	39	39	39	39	39	39	38	38	38	38	38
High-T emp. Curve 8	37	37	37	37	37	37	37	36	36	36	36	36	36	36	36	35	35	35	35	35

Heating curve 9 is an automatically generated curve (a linear curve created by setting parameters), calculated as follows:



Among these,

Tenv\_ht\_max: MAX([Heating Ambient Temperature Compensation 1 for Curve 9], [Heating Ambient Temperature Compensation 2 for Curve 9])

Tenv\_ht\_min: MIN([Heating Ambient Temperature Compensation 1 for Curve 9], [Heating Ambient Temperature Compensation 2 for Curve 9])

ThS\_end: MIN([Heating Outlet Water Temperature 2 for Curve 9], [Heating Outlet Water Temperature 1 for Curve 9])

ThS\_start: MAX([Heating Outlet Water Temperature 2 for Curve 9], [Heating Outlet Water Temperature 1 for Curve 9])

Note: MAX(A,B) denotes the larger value between A and B;

MIN(A,B) denotes the smaller value between A and B.


Table 3 Cooling Low-Temperature Curve (Cooling Ambient Temperature - Target Temperature Table) Unit: °C

AT	-10≤TA<15	15≤TA<22	22≤TA<30	30≤TA
Low-Temperature Curve 1	16	11	8	5
Low-Temperature Curve 2	17	12	9	6
Low-Temperature Curve 3	18	13	10	7
Low-Temperature Curve 4	19	14	11	8
Low-Temperature Curve 5	20	15	12	9
Low-Temperature Curve 6	21	16	13	10
Low-Temperature Curve 7	22	17	14	11
Low-Temperature Curve 8	23	18	15	12

Table 4 Cooling High-Temperature Curve (Cooling Ambient Temperature - Target Temperature Table) Unit: °C

AT	-10≤TA<15	15≤TA<22	22≤TA<30	30≤TA
High-Temp. Curve 1	20	18	17	16
High-Temp. Curve 2	21	19	18	17
High-Temp. Curve 3	22	20	19	17
High-Temp. Curve 4	23	21	19	18
High-Temp. Curve 5	24	21	20	18
High-Temp. Curve 6	24	22	20	19
High-Temp. Curve 7	25	22	21	19
High-Temp. Curve 8	25	23	21	20

Cooling Curve 9 is an automatically generated curve (a linear curve created by setting parameters), calculated as follows:



Among these,

$Tenv\_cl\_max$ :  $MAX([Cooling\ Ambient\ Temperature\ Compensation\ 1\ for\ Curve\ 9], [Cooling\ Ambient\ Temperature\ Compensation\ 2\ for\ Curve\ 9])$

$Tenv\_cl\_min$ :  $MIN([Cooling\ Ambient\ Temperature\ Compensation\ 1\ for\ Curve\ 9], [Cooling\ Ambient\ Temperature\ Compensation\ 2\ for\ Curve\ 9])$

$TcS\_end$ :  $MIN([Cooling\ Outlet\ Water\ Temperature\ 1\ for\ Curve\ 9], [Cooling\ Outlet\ Water\ Temperature\ 2\ for\ Curve\ 9])$

$TcS\_start$ :  $MAX([Cooling\ Outlet\ Water\ Temperature\ 2\ for\ Curve\ 9], [Cooling\ Outlet\ Water\ Temperature\ 1\ for\ Curve\ 9])$

Note:  $MAX(A,B)$  denotes the larger value between A and B;

$MIN(A,B)$  denotes the smaller value between A and B.





# iGarden

[www.igarden.ai](http://www.igarden.ai)

Version: Manual-V1

Thank you for choosing our ATW Heat Pump.